


# WORK SHOP MANUAL

**12LD 435-2**  
**12LD 435-2/B1**  
**12LD 475-2**



Refilling/Reccomended oil type .....	3
Maintenance .....	3
Torque specification .....	4
Disassembly/Reassembly .....	5
Aircleaner .....	5
Alternator .....	6
Bearing supports .....	10
Bearings .....	12
Camshaft .....	13
Camshaft timing .....	13
Connecting rod .....	10
Crankshaft .....	11
Cylinder .....	8
Cylinder head .....	7
Flywheel .....	5
Hydraulic pump p.t.o .....	13
Injector .....	7
Piston .....	9
Piston clearance .....	9
Piston rings .....	9
Rockerarm clearance .....	6
Speed governor .....	14
Valve guides .....	7
Valves .....	7
Lubricating system .....	15
Fuel filter .....	16
Fuel system .....	16
Oil pressure .....	15
Oil pump .....	15
Fuel system .....	17
Injector .....	18
Electric system .....	19
Alternator .....	19
Starting motor .....	21
Voltage regulator .....	20
Setting .....	22
Storage .....	24

## CHARACTERISTICS OF MODELS 12LD435-2, 12LD435-2/B1, 12LD475-2



ENGINE TYPE		12LD435-2	12LD435-2/B1	12LD475-2
Number of cylinders	N.	2	2	2
Bore	mm	86	86	90
Stroke	mm	75	75	75
Displacement	cm <sup>3</sup>	871	871	954
Compression ratio		18,0:1	18,0:1	18,0:1
R.P.M.		3000	3600	3000
	N DIN 70020 - 80/1268/CEE - ISO 1585	14	14,7	15,8
Power kW	NB DIN 6270	12,7	13,2	14,85
	NA DIN 6270	11,4	12,0	13,53
Max. torque	Nm	49	49	57
		@ 2000	@ 2000	@ 2100
Max. torque at 3rd p.t.o.	Nm	25	25	25
Specific fuel consumption *	g/kWh @ r.p.m.	260 @ 3000	280 @ 3600	245 @ 3000
Tank capacity	l.	7	7	7
Oil consumption **	Kg/h	0,020	0,020	0,025
Oil sump capacity	l.	2,5	2,5	2,5
Dry weight	Kg.	80	80	80
Combustion air volume at 3000 r.p.m.	l/l <sup>1</sup>	1050	1250 ***	1150
Cooling air volume at 3000 r.p.m.	l/l <sup>1</sup>	13300	16200 ***	15500
Max. permissible driving shaft axial load in both directions	Kg.	300	300	300
	momentary	α	35°	35°
Max. inclination	lasting up to 1 h.	α	25°	25°
	permanent	α	****	****

\* Referred to max. NB power

\*\* At 3000 r.p.m.


\*\*\* At 3600 r.p.m.

\*\*\*\* Depending on the application


# SPECIFICATIONS

## CHARACTERISTIC POWER, TORQUE AND SPECIFIC CONSUMPTION CURVES


12LD435-2



12LD435-2/B1



12LD475-2



**N (80/1269/CEE - ISO 1585) AUTOMOTIVE RATING:** Intermittent operation with variable speed and variable load.

**$N_B$  (ISO 3046 - 1IFN) RATING WITH NO OVERLOAD CAPABILITY:** Continuous light duty operation with constant speed and variable load

**$N_A$  (ISO 3046 - 1ICXN) CONTINUOUS RATING WITH OVERLOAD CAPABILITY:** Continuous heavy duty with constant speed and constant load.

**$M_N$  Torque curve (N curve) -  $M_B$  ( $N_B$  curve) -  $M_A$  ( $N_A$  curve).**

**C Specific fuel consumption curve**

The above power values refer to an engine fitted with an air cleaner and standard muffler; after run-in and at the environmental conditions of 20°C and 1 bar.

Max. power tolerance is 5%. Power decreases by approximately 1% every 100 m altitude and by 2% every 5°C above 25°C.



**MAINTENANCE**

OPERATION	COMPONENT	INTERVAL (HOURS)							
		10	50	125	250	500	1000	2500	5000
CLEANING	(OIL BATH) AIR CLEANER (*)	●							
	FEED PUMP FILTER				●				
	HEAD AND CYLINDER FINS (*)				●				
	FUEL TANK						●		
	INJECTORS					●			
	INTERNAL OIL FILTER						●		
CHECK	AIR CLEANER OIL LEVEL	●							
	CRANKCASE OIL	●							
	BATTERY FLUID		●						
	DELIVERY VALVE TIGHTNESS					●			
	VALVE AND ROCKER ARM CLEARANCE					●			
	INJECTOR SPRAY PATTERN					●			
REPLACEMENT	AIR CLEANER (**)(***)	●							
	CRANKCASE (***)		△		●				
	OIL FILTER CARTRIDGE		△		●				
	FUEL FILTER CARTRIDGE				●				
	DRY AIR CLEANER CARTRIDGE	(○)							
OVERHAUL INSPECTION	PARTIAL (****)						●		
	COMPLETE							●	

(\*) Under special working conditions clean daily.

(\*\*) Under extremely dusty conditions clean every 4-5 hours.

(\*\*\*) See recommended oil type.

(\*\*\*\*) Includes checking cylinders, piston rings, guides, springs, grinding valve seats, scaling heads and cylinders as well as checking injection pump and injectors.

(○) When clogging indicator shows the need for replacement.

△ First replacement

**RECOMMENDED OIL TYPE**

AGIP DIESEL SIGMA S SAE 30-40, specification MIL-L-2104 C


ESSOLUBE D3, specification

MIL-L-2104 D and UNIFARM specification

MIL-L-2104 C

In countries where AGIP and ESSO products are not available use diesel engine oil API SERVICE CD or a similar type complying with the military specification MIL-L-2104 C and MIL-L-2104 D.

**Suggested oil grades**



**CAPACITIES (LITERS)**

Standard fuel tank 10,0

Standard oil sump 2,8

Air cleaner oil tank 0,3

As for filters, tanks and special crankcases please refer to LOMBARDINI instructions.




**TORQUE SPECIFICATIONS****MAIN TORQUE SPECIFICATIONS**

POSITION	Picture No.	Diameter and pitch mm	Torque Nm
Connecting rod	31	8x1,25	40
Injection pump delivery valve union	59/61	18x1,5	40
Rocker arm cover	5	8x1,25	20
Center main bearing support	36	8x1,25	25
Intake manifold	—	8x1,25	25
Exhaust manifold	—	8x1,25	20
Air shroud	—	6x1,0	6
Accelerator cover	—	6x1,0	10
Oil filter housing	53	6x1,0	12,5
Internal oil filter cover	50 Nr. 16	6x1,0	10
Hydraulic pump flange	46 Nr. 5	8x1,25	25
Camshaft gear	44	10x1,5	60
Oil pump gear	51	10x1,5	35
Starting motor	76	10x1,5	45
Rocker arm shaft	9	8x1,25	25
Gear cover plate	—	8x1,25	25
Engine mounting foot	—	10x1,5	40
Fuel feeding pump	58	8x1,25	25
Injection pump	61	8x1,25	25
Oil pump	51	8x1,25	20
Nozzle holder	66 Nr. 9	6x1,0	10
Oil pan	—	8x1,25	28
Main bearing support, gear case side	33	8x1,25	25
Main bearing support, flywheel side	34	8x1,25	25
Center main bearing support	35	10x1,5	30
Hydraulic pump gear support	46 Nr. 7	8x1,25	25
Governor fork support	—	8x1,25	25
Fuel tank bracket	—	8x1,25	40
Cylinder head	11	10x1,5	50
Flywheel	3	16x1,5	180



**DISASSEMBLY AND REASSEMBLY**

Besides disassembly and reassembly operations this chapter also includes checking and setting specifications, dimensions, repair and operating instructions. Always use original LOMBARDINI spare parts for proper repair operations.  
All dimensions in mm.




**Oil-bath air cleaner**

Check gaskets and replace if necessary.  
Check that flange weld is free of porosity or defective spots.  
Carefully clean bowl and filtering element with Diesel oil and blow through with compressed air.  
Top up with engine oil to the mark.  
When refitting tighten nuts at 25 Nm.  
See page 3 for periodic maintenance details.

Components:


- |                     |                      |
|---------------------|----------------------|
| 1 Bowl              | 5 Internal seal ring |
| 2 Oil level mark    | 6 Cover              |
| 3 Filtering element | 7 Clamp              |
| 4 Seal ring         | 8 Prefilter          |



**Dry air cleaner**

- 1 Hand wheel
- 2 Cover
- 3 Cartridge
- 4 Seal ring
- 5 Bracket
- 6 Clogging indicator

**Note:** Replace cartridge immediately when indicator shows that is clogged.




**Flywheel**

Remove flywheel with puller (part. No. 7271-3595-048).  
Check starter ring gear and tapered crankshaft mating surfaces.  
When refitting tighten bolt to 180 Nm.

**Note:** To replace starter ring gear heat it up to 200 ÷ 250°C and rapidly drive it onto the flywheel.


**Attention:** Unscrew bolt 1 clockwise.



4

**Alternator**

Remove stator and place it inside the rotor to prevent metal particles from being attracted by the magnets.  
When refitting tighten rotor screws and stator bolts at 10 Nm.  
See page 19, 20 for alternator characteristics.




5

6

**Valve / rocker arm clearance**


Remove rocker arm cover and check gaskets for breakage.  
Setting should be performed when the engine is cold: bring each cylinder piston to top dead center on the compression stroke and set clearance **A** at  $0.15 \div 0.20$  mm.  
When refitting tighten cover screws to 20 Nm.



7

**Compression release (optional)**

Bring piston to top dead center on the compression stroke.  
Unscrew rocker arm cover side plug and measure clearance **A**. It must be  $0.30 \div 0.40$  mm.  
For setting purposes remove rocker arm cover, unscrew lock nut and set clearance **A**, by adding or removing shims under steel plate (point **B**).



8

9

**Rocker arm assembly**

- Components:  
1 Bore  
2 Lubrication tube

Dimensions (mm):

**A** =  $18.032 \div 18.050$


**B** =  $17.989 \div 18.000$

If clearance (A-B) exceeds 0.135 mm. replace shaft and rocker arms.  
When refitting check that lubrication tube perfectly matches with the journal bore.

Tighten screws to 25 Nm.








10

**Injector projection**

The end of nozzle **A** should project  $3.0 \div 3.5$  mm. from the cylinder head plane.

Adjust injector projection by means of copper shims **B** measuring 1.5 and 1.00 mm. in thickness.



11

**CYLINDER HEAD**


Do not remove it when hot to avoid deformation.

If cylinder head is deformed level it off by removing a maximum of 0.3 mm.

When refitting tighten only if sure that rocker arm lubrication tube is well inside its holes and that both heads are in line by fitting the inlet and exhaust manifolds before tightening the cylinder head nuts.

Always replace copper head gasket: see page 7 for choosing the right thickness.

Progressively tighten nuts in the **1, 2, 3, 4** sequence at 50 Nm.



12

13


**Valves**

Components:

- 1 Intake valve
- 2 Spring seat
- 3 Valve stem oil seal
- 4 Spring
- 5 Retainer
- 6 Half collets

To remove half collets firmly press down as shown in the figure.

**Note:** Valve stem oil seal, **3** must be fitted to the intake valve only.



14

**Valve guides and valve guide housings**

Starting from engine No. 2883619 intake and exhaust valve guides are both made of phosphoric cast iron.


Components:

- 1 = Exhaust valve guide
- 2 = Intake valve guide

Dimensions (mm):

- A** = 42,0
- B** = 48,5
- C** =  $14,000 \div 14,018$
- D** =  $14,050 \div 14,060$

Valve guides with outside diameter increased by 0.5 mm. are also available; in such cases valve guide bore **C** should also be increased by 0.5 mm.



15

## Valve guide insertion

Heat cylinder head up to  $160 \div 180^{\circ}\text{C}$

Press guides considering the **A** and **B** distances from the head plane.

Dimensions (mm):

**A** =  $30.80 \div 31.20$

**B** =  $24.80 \div 25.20$

**C** =  $20.3 \div 20.7$


**Note:** If guides are seated with stop ring **C**, first locate the ring in place and then position guides without considering **A** and **B**.

## Dimensions and clearance between guides and valves (in mm)

**D** =  $8.030 \div 8.045$

**E** =  $7.985 \div 8.000$

**(D-E)** =  $0.030 \div 0.060$       **(D-E)** limit of wear = 0.15



16

## Valve seats and housings

Dimensions (mm.):


**A** =  $40.000 \div 40.016$  (intake valve housing dia.)

**B** =  $40.120 \div 40.140$  (intake valve seat dia.)

**C** =  $34.000 \div 34.016$  (exhaust valve housing dia.)

**D** =  $34.120 \div 34.140$  (exhaust valve seat dia.)

Press valve seats into the housings and cut  $\alpha$  at  $45^{\circ}$



17


18

## Valve seat grinding

After cutting grind valve seats with fine emery paste in oil suspension.

The sealing surface **S** should not exceed 2 mm.

Valve recess after grinding **D** =  $0.75 \div 1.25$  mm; maximum worn limit 1.65 mm.



19

20

## CYLINDER

Measure diameter size between two diametrically opposed points at three different heights.

For 12LD435-2 and 12LD435-2B1  $\varnothing = 86,00 \div 86,02$  mm (new)

For 12LD475-2  $\varnothing = 90,00 \div 90,02$  mm. (new)


In case wear exceeds 0.10 mm, bore the cylinder and fit oversize piston and rings. In case of less wear replace piston rings only.

## Cylinder roughness

Inclination of the machined cross-hatch should range between  $45^{\circ}$  and  $55^{\circ}$ ; the cross-hatch should be uniform and clear in both directions. Mean roughness should range between 0.5 and  $1 \mu\text{m}$ . The entire surface of the cylinder which contacts piston rings should be honed.

**Warning:** Do not use emery cloth on the cylinder or attempt to create the cross-hatch by hand motion.





21

22

**PISTON**

Remove circlips and remove piston pin.  
Remove piston rings and clean grooves.  
Measure diameter at 12 mm (like drawing) from the bottom of the piston.

**Diameter in mm (new)**


12LD435-2 and 12LD435-2B1 = 85,920 ÷ 85,940

12LD475-2 = 89,925 ÷ 89,940

**Note:** Oversize pistons of 0.5 and 1.0 mm are available.

**Piston weight**

Weigh pistons when replacing them in order to avoid unbalance.  
The difference in weight should not exceed 6 g.



23

24

**Piston rings - End gaps (mm)**

Place piston rings squarely into the unworn part of the lower cylinder and measure the end gap.


A = 0,30 ÷ 0,50 (new)

**Piston rings - Clearance between grooves**

A = 0,060 ÷ 0,065      limit of wear = 0,12

B = 0,030 ÷ 0,035      limit of wear = 0,07

C = 0,020 ÷ 0,025      limit of wear = 0,05



25

26

**Piston rings - Fitting sequence**

A = 1° Chromium-plated ring

B = 2° Torsional (internal tapered) ring

C = 3° oil control ring


**Note:** Before fitting the piston into the cylinder stagger the ring gaps at 120°.

**Piston - Refitting**

Connect piston to connecting rod in a way that the combustion chamber centre **b** is at right angle under nozzle tip **a**.

Lubricate piston pin and introduce it into the piston by exerting pressure with your thumb.

Check that both circlips are well inside their seats.



27

28


**Piston clearance**

A = Piston clearance

B = Copper head gasket

A (0.65 ÷ 0.70 mm) is determined by placing the piston at top dead center and measuring with a feeler gauge and straight edge, the distance the piston is below or above the cylinder face. A copper gasket (available in various thicknesses) is then selected to ensure the clearance is correct.

Gaskets are available in the following thicknesses 0.5, 0.55, 0.6, 0.65, 0.7, 0.75, 0.8, 0.85, 0.9, 0.95 mm.



## Connecting rod small end bushing

Dimensions and clearance (mm):

**A** = 117.95 ÷ 118.05


**C** = 22,015 ÷ 22,025 (with machined bushing in place)

**D** = 21,995 ÷ 22,005

**(C-D)** = 0,010 ÷ 0,030

**(C-D)** limit of wear = 0.070

29



## Connecting rod big end bearing

Both centering notches **A** and **B** must be on the same side when refitting.

Tighten bolts to 40 Nm.

See page 12 for dimensions.


## Connecting rod weight

Weigh connecting rods when replacing them in order to avoid unbalance.

The difference in weight should not exceed 10 g.

30


31



## Crankshaft timing gear

Use tool **1** (Part No. 7560-4000-052) and puller **2** (Part No. 7271-3595-048) to remove the gear.

32



## Main bearing support, gear side


Remove main bearing by means of two M8x1.25 screws with fully threaded length of 40 mm or a puller (Part No. 7271-3595-048).

**Note:** To avoid deformation it is not recommended to replace the bearing bushing, complete assembly's of bushing and support are available in standard, 0.25 mm and 0.50 mm undersize configurations as spare parts.

See page 12 for dimensions.

33






34

**Main bearing support, PTO-Side**

Remove it by means of two M8x1.25 screws with fully threaded length of 40 mm.  
 Check oil seal ring and replace if warped, hardened or worn-out.  
 When refitting, tighten nuts to 25 Nm.  
 See page 12 for dimensions.



35

35a


**CRANKSHAFT**

**Center main bearing support, locating bolt.**

Straighten plate 1 and unscrew bolt 2 before removing crankshaft.  
 When refitting, tighten screw 2 to 30 Nm.

**Crankshaft end play**


When refitting crankshaft check end play by means of a feeler gauge; this value should be  $0.08 \div 0.38$  mm and can be set by changing the thickness of gasket A which is located on the flywheel-side main bearings.  
 Gaskets with thickness of 0,30 and 0,50 mm can be supplied.



36

**Crankshaft center main bearing support**

When refitting, both centering notches A and B must be located on the same side.  
 Tighten screws to 25 Nm.  
 See page 12 for dimensions.



37

38


**Crankshaft lubrication ducts**

Remove plugs, clean duct A with a pointed tool and blow in compressed air.  
 Replace the plugs, and check for sealing.

**Crankshaft journal radii**

The radius R connecting journals to shoulders is  $2.8 \div 3.2$  mm.

**Note:** When grinding main journals or crank pins restore the R value to original specification.



**Main journal and crank pin diameter (mm)  
Main bearing and connecting rod big end bearing inside diameter**


Dimensions (mm):

<b>E</b> = 72.070 ÷ 72.090	<b>A</b> = 71.981 ÷ 72.000
<b>F</b> = 40.045 ÷ 40.076	<b>B</b> = 40.004 ÷ 40.020
<b>G</b> = 55.404 ÷ 55.435	<b>C</b> = 55.340 ÷ 55.350
<b>H</b> = 55.000 ÷ 55.020	<b>D</b> = 54.931 ÷ 54.950

The above dimensions refer to driven in or tightened bearings.

**Note:** Both main bearings and connecting rod big end bearings are available with inside diameter size measuring 0.25 and 0.50 mm less than the standard version.


39



**Clearance between main journals/crank pins and connecting rod bearings (mm)**

<b>(E-A)</b> = 0.070 ÷ 0.109;	limit value = 0.195
<b>(F-B)</b> = 0.025 ÷ 0.072;	limit value = 0.150
<b>(G-C)</b> = 0.051 ÷ 0.095;	limit value = 0.190
<b>(H-D)</b> = 0.050 ÷ 0.089;	limit value = 0.180

40




**Main bearing supports**

- 1 PTO-side
- 2 Central
- 3 Gear side

Dimensions (mm):

<b>I</b> = 130.000 ÷ 130.020
<b>L</b> = 76.980 ÷ 77.020
<b>M</b> = 128.000 ÷ 128.018
<b>N</b> = 59.074 ÷ 59.092
<b>O</b> = 75.990 ÷ 76.010
<b>P</b> = 60.000 ÷ 60.020

41




**Main bearing housings**

Dimensions (mm):

<b>A</b> = 130.000 ÷ 130.020
<b>B</b> = 128.000 ÷ 128.020
<b>C</b> = 76.000 ÷ 76.020

42





**Dimensions of camshaft journals and housings (mm)**

- A = 41.940 ÷ 41.960
- B = 27.940 ÷ 27.960
- C = 42.000 ÷ 42.025
- D = 28.000 ÷ 28.020


**Clearance (mm)**

- (C-A) = 0.040 ÷ 0.085; (C-A) limit value = 0.160
- (D-B) = 0.040 ÷ 0.080; (D-B) limit value = 0.150

**How to measure intake/exhaust cam height**

A<sub>1</sub> = 1st cylinder intake cam    A<sub>2</sub> = 2nd cylinder intake cam  
 S<sub>1</sub> = 1st cylinder exhaust cam    S<sub>2</sub> = 2nd cylinder exhaust cam  
 Exhaust and intake cams feature the same height H = 33,62 ÷ 33,65.  
 Replace camshaft if H is 0.1 mm below the given value.

43




**Camshaft timing**

Fit camshaft gear by making timing mark 1 coincide with timing mark 2 on the crankshaft timing gear.  
 Tighten camshaft bolt to 60 Nm.

**Camshaft end play**

End play should be 0.10 ÷ 0.26 mm; check by means of a dial gauge pushing or pulling camshaft as required.


44



**Valve timing without considering timing marks**

Locate piston 1 (on flywheel side) at the top dead centre.  
 Position two small cylinders A of the same height onto the tappets. Rotate camshaft stopping when cylinder 1 tappets are in overlap position (intake open, exhaust closed).  
 By means of ruler B check that tappets are at the same height.  
 Engage camshaft gear with crankshaft gear.

45



**Hydraulic pump p.t.o. (1P)**


Components:

- 1 Seal ring
- 2 Centering ring
- 3 Coupling
- 4 Half coupling
- 5 Flange
- 6 Gear
- 7 Bracket
- 8 Thrust washer
- 9 Stop ring
- 10 Cover

The maximum torque is 27 Nm corresponding to 7,64 kW at 3000 r.p.m..

46






47

## Mechanical speed governor

Components:

- |                      |                   |
|----------------------|-------------------|
| 1 Gear               | 2 Weight          |
| 3 Mobile bell        | 4 Stop ring       |
| 5 Yoke               | 6 Lever           |
| 7 Drive rod          | 8 Governor spring |
| 9 Rack control lever |                   |

Weights are moved to the periphery by the centrifugal force and thus axially shift a mobile bell connected to the injection pump rack control lever by a linkage. A spring placed under tension by the accelerator control offsets the weights centrifugal force. Balance between the two forces keeps speed at an almost constant level in spite of load variations. See page 17 for timing.




48

## Governor springs with rocker arm

Components:

- |                                   |
|-----------------------------------|
| 1 Rocker arm for spring anchoring |
| 2 Governor springs                |
| 3 Plate                           |
| 4 Link                            |
| 5 Lever                           |



49

## Spring for extra fuel supply at starting


Components:

- |                               |
|-------------------------------|
| 1 Extra fuel spring           |
| 2 Injection pump control yoke |
| 3 Governor spring.            |

The device is operated automatically: when the engine is stopped spring 1 acts on injection pump control yoke 2 providing maximum fuel delivery, until the engine starts and the governor controls the injection pump rack.








50

**Components:**

- |                                      |                                      |
|--------------------------------------|--------------------------------------|
| 1 Oil pressure switch                | 9 Oil fill plug                      |
| 2 Breather                           | 10 Rocker arm shifts                 |
| 3 Connecting rod big end bearing     | 11 Pushrod protection tube           |
| 4 Crankshaft main bearing, gear side | 12 Hydraulic pump gear               |
| 5 Oil pressure relief valve          | 13 Camshaft journal on flywheel side |
| 6 Fitting for pressure gauge         | 14 Oil dipstick                      |
| 7 Cartridge filter                   | 15 Drain plug                        |
| 8 Oil pump                           | 16 Internal filter                   |

**Oil pressure check**

Once the engine is filled with oil and fuel; connect a 10 bar pressure gauge to the oil filter fitting. Start the engine and check pressure as a function of the oil temperature




51

52

**Oil pump**

Check that gear teeth are intact and that clearance between gear edge and pump body does not exceed 0.15 mm. Further more check that control shaft is free to rotate with end float not exceeding 0.15 mm. Oil pump delivery at 3000 r.p.m. is 9 liters/min.



53

54

**Oil filter cartridge (internal)**

Components:

- |             |             |
|-------------|-------------|
| 1 Plug      | 3 Spring    |
| 2 Seal ring | 4 Cartridge |

Features:

Type of filtration: 70  $\mu$   
 By-pass valve opening pressure: 0.60 ÷ 0.75 bar.  
 Max. working pressure: 4.5 bar.


**Oil pressure relief valve**

Components:

- |          |          |
|----------|----------|
| 1 Plug   | 3 Spring |
| 2 Gasket | 4 Valve  |

A = 37 mm

Carefully clean all components and check spring A length.



55

**Oil pressure curve at idling speed (A)**

The curve is obtained at the oil filter level with constant engine speed of 1200 r.p.m. in no-load conditions and at a room temperature of +25°C.

Pressure is given in bar and temperature in centigrade.


**Oil pressure curve at full speed (B)**

The curve is obtained at the oil filter level with engine working at 3000 r.p.m.

Pressure is given in bar and temperature in centigrade.



## FUEL SYSTEM




56

### Fuel feeding/injection circuit

Components:

- 1 Tank
- 2 Filter
- 3 Fuel feeding tube
- 4 Fuel feeding pump
- 5 Injection pump
- 6 Injection line
- 7 Injector
- 8 Injector leak off line and self bleeding system




57

### Fuel filter (inside fuel tank)

Components:

- 1 Spring
- 2 Disc
- 3 Ring
- 4 Cartridge
- 5 Gasket
- 6 Gasket
- 7 Cap
- 8 Ring
- 9 Bolt



58

### Fuel feeding pump drive rod protrusion


Components:

- 1 Drive rod
- 2 Gasket
- 3 Camshaft eccentric

Drive rod **A** protrudes 0.8-1.2 mm from the crankcase; it can be adjusted by means of gaskets.

Gaskets are supplied in the following thicknesses: 0.50, 0.80 and 1.0 mm.

**Note:** This setting is performed when the rod is on the base of the cam lobe (i.e. minimum protrusion).




59

### Injection pump

Components:

- |                   |                   |
|-------------------|-------------------|
| 1 Pump body       | 2 Fitting         |
| 3 Seal ring       | 4 Filler          |
| 5 Shim            | 6 Spring          |
| 7 Delivery valve  | 8 Seat            |
| 9 Gasket          | 10 Plunger        |
| 11 Barrel         | 12 Rack rod       |
| 13 Sector gear    | 14 Spring         |
| 15 Upper retainer | 16 Lower retainer |
| 17 Tappet         | 18 Tappet roller  |






**Test data for injection pump delivery**

Control rod max. force	Rod stroke from max deliv. point	R.P.M.	Delivery	Max. plunger difference
Newton	mm		mm <sup>3</sup> · stroke	mm <sup>3</sup> · stroke
0,50	10	1500	23 ÷ 26	3
	13	500	4 ÷ 8	3
	0	150	57 ÷ 65	—
	10	500	10 ÷ 14	3

60



**How to reassemble injection pump components**

After replacing the worn-out components, reassemble the pump as follows:

Introduce sector gears into the pump body by making reference points **C** match with the **B** points on the rack.

Fix barrels with the eccentric screws **F** on the pump body.


Fit valves with seats, springs, fillers and delivery unions tightening them at 3.5 ÷ 4 Kgm.

Fit plungers by making reference points **E** match with the sector gear **D** points.

Fix retainers and springs; lock tappet with special stop.

Check that both plungers have the same delivery by performing the necessary measurements at the test bed; if delivery is not the same set screw **F**.

61



**Injection pump/mechanical speed governor timing**


Loosen screw **1**

Move injection pump lever **2** to maximum delivery (to the right).

Check that drive rod **3** closes the speed governor; keeping lever **2** pressed to the right the drive rod should have no clearance.

Tighten screw **1**.

62



**Static injection timing**

Disconnect injection line cylinder **1** making sure not to loosen the pump delivery union. Attach the timing tool. (Spare part. no. 1460.024).

Top up the tank checking that fuel level is at least 10 cm above checking device.


Adjust injection pump rack rod half stroke.

Turn the flywheel according to the engine direction of rotation and check that fuel reaches the checking device.

Repeat this last operation during compression proceed slowly and stop immediately when the fuel is seen to pass through the checking device hole; bring flywheel back by 5 mm; this is the so-called static injection timing.

63





64


65

**Injection timing reference marks on crankcase and flywheel**

- A = Piston reference mark at the top dead centre
- B = Injection timing reference mark compared to A
- A ÷ B = Distance in mm.
- C = Piston reference mark in injection timing position.
- α = Reference angle in degrees.

Engine type	(A ÷ B) mm	α
12LD 435-2	67,6	26°
12LD 435-2/B1	67,6	26°
12LD 475-2	54,6	21°

**Note:** By adding or removing a 0.1 mm shim under the pump C is delayed or advanced by approximately 3 mm.



66

**INJECTOR**

Components:


- 1 Intake fitting
- 2 Nozzle holder
- 3 Shim
- 4 Spring
- 5 Pressure rod
- 6 Intermediate flange
- 7 Nozzle
- 8 Needle valve
- 9 Fixing flange
- 10 Taper pin
- 11 Gasket
- 12 System duct
- 13 Sump
- 14

**Injector setting**

Connect injector to a hand pump and check that setting pressure is 210 ÷ 220 bar; make the required adjustments, if any, by changing the shim over the spring.


When replacing the spring, setting should be performed at a 10 bar greater pressure (220 ÷ 230 bar) to allow for bedding during operation. Check needle valve sealing by slowly moving hand pump until approximately 180 bar.

Replace nozzle in case of dripping.



67






**Electrical starting layout with battery charging light**

Components:

- 1 Alternator
- 2 Starting motor
- 3 Voltage regulator
- 4 Battery
- 5 Pressure switch
- 6 Oil pressure warning light
- 7 Key switch
- 8 Battery charging light

**Note:** Battery, which is not supplied by Lombardini, should feature 12 V voltage and capacity not below 70 Ah.

68



**12.5 V, 14 A Alternator**

Features a fixed armature winding mounted on the air shroud bracket. The rotating permanent magnet inductor is located in the fan spindle.


Dimensions (mm):

A = 158.80 ÷ 159.20

B = 27.50 ÷ 27.90

**Note:** Clearance between armature winding and inductor (air gap) should be 0.48 ÷ 0.60 mm.

69



**Alternator battery charger curve (12.5 V, 14A)**

The curve was obtained at room temperature of +25°C with 12.5 V battery voltage

70



**OPTIONAL ELECTRIC EQUIPMENT**

**12 V, 18A Alternator**


Only two yellow cables are at output.

Dimensions (mm):

**A** = 158.80 ÷ 159.20

**B** = 27.50 ÷ 27.90


**Note:** Clearance between armature winding and inductor (air gap) must be 0.48 ÷ 0.60 mm.



71

**Alternator battery charger curve (12 V, 18 A)**

This curve is obtained at +25°C with 12.5 V battery voltage.



72

**VOLTAGE REGULATOR**


Type LOMBARDINI, supplied by SAPRISA and DUCATI: Voltage 12 V, max. current 26A. References for SAPRISA connections with the corresponding DUCATI connections.

SAPRISA	DUCATI
~	G
R	R
+	B
LE	L
⚡	C

To avoid wrong connections 3 different sizes are supplied.

SAPRISA	DUCATI	CONNECTION SIZE (mm)	
		WIDTH	THICKNESS
~	G	6.25	0.8
R	R	9.50	1.2
+	B	9.50	1.2
LE	L	4.75	0.5
⚡	C	6.25	0.8


The voltage regulator fits to both circuits with and without battery charging light; in the latter case connections LE (SAPRISA) and L (DUCATI) are not used.



73

74






75

**How to check voltage regulator for proper operation**

Check that connections correspond to the layout.  
 Disconnect the terminal from the battery positive pole.  
 Connect a d.c. voltmeter between the two battery poles.  
 Fit an ammeter between the positive pole and the corresponding cable 1 terminal.  
 Start a couple of times until battery voltage drops below 13 V.  
 When battery voltage reaches 14.5 V the ammeter current suddenly drops down to almost zero.  
 Replace regulator if recharge current is zero with voltage below 14 V.

**Warning:** When the engine is running do not disconnect battery cables or remove the key from the control panel.  
 Keep regulator away from heat sources since temperatures above 75°C might damage it.  
 No electric welding on engine or application.




76

**Starting motor type Bosch DWL 12 V, 1.7 kW**

- A = 29.5 ÷ 31.5 mm
- B = Ring gear plane
- C = Flange plane

**Warning:** Flywheel should not project from ring gear plane B.




77

**Characteristic curves for starting motor type Bosch DWL 12 V, 1.7 kW**

Curves were obtained at the temperature of +20°C with 88 Ah battery.

- V = Motor terminal voltage in Volt
- P = Power in kW
- C = Torque in N/m
- N = Motor speed in r.p.m.
- J (A) = Absorbed current in Ampere.




78

**SETTINGS**

**1) Idling speed setting in no-load conditions**

After filling with oil and fuel, start the engine and let it warm up for 10 minutes.

Adjust idling speed at 1200 ÷ 1300 r.p.m. by turning setscrew 1; then tighten lock nut.




79

**2) Full speed setting in no-load conditions (standard)**

After setting idle speed turn screw 2 and set full speed in no-load conditions at 3200 r.p.m.; then tighten lock nut.

**Note:** When the engine reaches the pre-set power full speed stabilizes at 3000 r.p.m.



80

**Injection pump delivery setting**

This setting should be performed at the torque dynamometer. If not, setting is only approximate.


The following steps are required:

Loosen delivery limiting device **C** by 5 turns.

Bring engine to full speed in no-load conditions i.e. 3200 r.p.m.. Tighten limiting device until the engine shows a drop in r.p.m..

Unscrew limiting device **C** by 1½ turn. Tighten lock nut.

**Note:** If the engine, under full load, generates too much smoke tighten **C**; if no smoke is observed at the exhaust and the engine cannot reach its full power unscrew **C**.



81

**Injection pump delivery limiting and extra fuel device**

Limiting device **C** limits the injection pump maximum delivery. It also acts as a torque setting device since spring **N** opposes the resistance of spring **M** inside the cylinder through lever **L**.


The torque setting device allows lever **L** to move over stroke **H** corresponding to 0.15 ÷ 0.25 mm.

This consequently increases injection pump delivery with torque reaching its peak value.

**Note:** In generator sets and power welders, the torque setting device acts as a delivery limiter only. It therefore does not feature spring **M** or stroke **H**.








82

### Injection pump delivery setting with engine at the torque dynamometer

- 1) Bring engine to idling speed
- 2) Unscrew delivery limiting device **C** (see page 22)
- 3) Bring engine to the power and r.p.m. required by the manufacturer of the device.
- 4) Check that consumption falls within the table specifications (see below). If consumption is not as indicated change balance conditions at the torque dynamometer by varying the load and adjusting the governor.  
Under stable engine conditions check consumption again.
- 5) Tighten limiting device **C** until the engine r.p.m. decreases.  
Lock the limiting device by means of lock nut.
- 6) Release brake completely and check at what speed the engine becomes stable.  
Speed governor should comply with the requirements of the class indicated by the manufacturer of the device.
- 7) Stop the engine
- 8) Check valve clearance when the engine has cooled down.

### Required settings (as most commonly applies)

Engine	R.P.M.	Power kW (HP)	Specific fuel consumption *	
			Time (sec.) per 100 cm <sup>3</sup>	g/kWh (g/HPH)
12LD435-2	3000	N 13.97 (19)	74-76	290-282 (213 ÷ 208)
		NB 12.72 (17.3)	91-93	259-254 (191 ÷ 186)
12LD435-2/B1	3600	N 14.7 (20)	66-68	309-300 (227 ÷ 221)
		NB 13.23 (18)	78-80	291-283 (214 ÷ 208)
12LD475-2	3000	N 15.8 (21.5)	73-75	260-253 (191 ÷ 186)
		NB 14.85 (20.2)	82-84	246-240 (181 ÷ 177)




83


### Stop setting

- 1) Completely turn lever **C** counterclockwise and keep it in this position. Retainer **F** should not be in contact with lever **C**.
- 2) Unscrew nut **G** and bring retainer **F** in contact with lever **C**
- 3) Push retainer **F** so that lever **C** is moved backwards clockwise by 1.0 ÷ 1.5 mm.
- 4) Lock retainer **F** by screwing nut **G**


**Note:** Under these conditions no damage can be caused to the injection pump rack rod stops by sudden impacts due to the available electric stops.




84



85



86



87

**STORAGE**

Prepare engines as follows for storage over 30 days:

**Temporary protection (1 ÷ 6 months).**

- Let engine work at idling speed in no-load conditions for 15 minutes.
- Fill crankcase with protection oil MIL-1-644-P9 and let engine run at 3/4 full speed for 5 ÷ 10 minutes.
- When engine is warm empty oil pan and fill with standard new oil.
- Remove fuel tube and empty the tank.
- Remove fuel filter, replace cartridge if dirty and refit.
- Carefully clean cylinder fins, heads and fan.
- Seal all openings with tape.
- Remove injectors, pour a spoonful of oil type SAE 30 into the cylinders and rotate manually to distribute the oil. Refit injectors.
- Spray oil type SAE 10W into exhaust and intake manifolds, rocker arms, valves, tappet etc. Grease all unpainted parts.
- Loosen belt.
- Wrap the engine in a plastic film.
- Store in a dry place, if possible not directly on the soil and far from high voltage electric lines.

**Permanent protection (over 6 months)**

The following is recommended apart from the above instructions:

- For the lubrication and injection system as well as for moving parts use rustproof oil type MIL-L-21260 P10, grade 2, SAE 30 (Ex. ESSO RUST - BAN 623 - AGIP, RUSTIA C. SAE 30). Let the engine run with rustproof oil and drain any excess.
- Coat external unpainted surfaces with antirust type MIL-C-16173D, grade 3 (Ex. ESSO RUST BAN 398 - AGIP, RUSTIA 100/F).

**How to prepare the engine for operation**

- Clean engine outside
- Remove protections and covers.
- Remove antirust by an appropriate solvent or degreaser.
- Remove injectors, fill with standard oil, turn crankshaft by a few revolutions, remove oil pan and drain the protective oil.
- Check injectors, valve clearance, belt tension, head tightening, oil filter and air cleaner for proper setting. If the engine is stored over a long period of time (over 6 months) check one of the bushings for corrosion.

