### Citymaster 1650 1491.15



# 6.0.10 3-Broom-System

# 3-Broom-System, Table of contents

Inhalt/ Contents	Seite/ Page
Function of 3-Broom-system	2
3-Broom-System	3 - 5
Valve block	6
Water system	7
Concept of operation	8 - 10
Programming and adjustment	11 - 12




#### **Function of the 3-Broom-Controller**

By turning of the ignition key the system is energized. If power is applied at A08 X1PIN64 and PIN78 the 3-Broom-Controller is activated (presupposed the ground connection is correct). By this a CAN-Bus message is sended to the work-hydraulic-controller A04. Through this the machine detect the 3-Broom-Systems. You could see it in the display, by the relevant symbol. The detection is not done, like other tools, by a coding at the plug X63. This plug is only used for the communication with the machine. By pushing the "Green Button" the sweep mode is activated. In the machine is now the relay K07 energized (+12V at PIN 86). By this the working power supply for the 3-Broom-Controller (Fuses F25 und F26) is energized.

If the front attachment sensor (B16) isn't applied, the 3-broom-system is still activated, but the proportional valves broom speed will be not energized. All other 3-broom functions will work.




### 3 Broom-System






# 3 Broom-System






# 3 Broom-System






### Valveblock





#### Water-System





Concept of operation



Begin of work mode with green button, menue level 1 activ

Two menue levels:

Menue 1: Pulled brooms


Menue 2: 3rd broom

- Change by the last used function
- Notification of the current menue level in the display, Adaption of the working functions (A-Menue) by means of the menue level



Concept of operation

After change to work mode: Menue level "pulled brooms":



Into floating position: start brooms

Leave of floating position: stopp brooms

#### Citymaster 1650 1491.15



# 6.0.10 3-Broom-System


























#### Programming and adjustment

- Controller did have flashed software
- Controller is parametrized in Glindow factory
- Parametrizing is memory buffered on the work hydraulic controller. That means after change of 3-broom-controller parametrizing is write back to controller; only need to be saved
- In case of new software flashing is possible. Procedure is describted
- Parametrizing at machine is possible with diagnose tool



#### Programming and adjustment

- Pulled brooms min 10% => 30 rpm; max 100% 140 rpm - 3rd broom min 10% => 30 rpm; max 100% 120 rpm

- Pulled brooms min 10% => 20 kg; max 100% => 8 kg - 3rd broom min 10% => 29 kg; max 100% => 8 kg

"Attention! Weight of broom(s) at ground"