

# SERVICE MANUAL

**Minuteman**<sup>®</sup>  
*Excellence Meets Clean*



For E Series Scrubbers  
Models: E24, E26, E28,  
E30, E33, E33XL,  
E30ECO, E2830, E3030,  
E3330 and H26

For:  
Training  
Troubleshooting  
Adjustments

Rev 07/17/2015

# Contents

<b>1</b>	<b>Warnings</b>	<b>Page 6</b>
<b>2</b>	<b>General Information</b>	<b>Page 7</b>
<b>3</b>	<b>Maintenance Intervals</b>	<b>Page 8</b>
	<b>3.1 Minuteman System Maintenance K (Customer)</b>	<b>Page 9</b>
	<b>3.2 Minuteman System Maintenance I (125 hours of operation)</b>	<b>Page 10</b>
	<b>3.3 Minuteman System Maintenance II (250 hours of operation)</b>	<b>Page 11</b>
	<b>3.4 Minuteman System Maintenance S (500 hrs of operation, at least yearly)</b>	<b>Page 12</b>
<b>4</b>	<b>Squeegee Cable and Recovery Tank Gasket</b>	<b>Page 13</b>
	<b>4.1 Squeegee Adjustment (First Version)</b>	<b>Page 14</b>
	<b>4.2 Squeegee Adjustment (new Style)</b>	<b>Page 15</b>
	<b>4.3 Squeegee Lift Cable, Micro Switch, Vacuum Motor</b>	<b>Page 16</b>
	<b>4.4 Squeegee Wheel Adjustment</b>	<b>Page 17</b>
<b>5</b>	<b>Brush Head (Disk Brushes) Connections</b>	<b>Page 18</b>
	<b>5.1 Brush Motor Information</b>	<b>Page 19</b>

# Contents

<b>6</b>	<b>Brush Head Transport Position</b>	<b>Page 21</b>
	<b>6.1 Brush Switch</b>	<b>Page 22</b>
	<b>6.2 Brush Pressure Adjustment on the Disk Models</b>	<b>Page 23</b>
	<b>6.3 Brush Pressure (Disk Decks)</b>	<b>Page 24</b>
	<b>6.4 Cylindrical Brush Head Electrical Connections</b>	<b>Page 25</b>
	<b>6.5 Cylindrical Brush Head Adjustment</b>	<b>Page 26</b>
<b>7</b>	<b>Drive and Wheels - General Data</b>	<b>Page 27</b>
	<b>7.1 Electric Brake</b>	<b>Page 27</b>
	<b>7.2 Transaxle Motor</b>	<b>Page 28</b>
	<b>7.3 Carbon Brushes</b>	<b>Page 29</b>
	<b>7.4 Drive Potentiometer</b>	<b>Page 30</b>
<b>8</b>	<b>Water Supply</b>	<b>Page 31</b>
	<b>8.1 Solenoid</b>	<b>Page 31</b>
	<b>8.2 Solution Filter</b>	<b>Page 31</b>
	<b>8.3 Solution Tank Cleanout</b>	<b>Page 32</b>
	<b>8.4 Solution Flow Rates</b>	<b>Page 33</b>
	<b>8.5 Water Pump</b>	<b>Page 34</b>
<b>9</b>	<b>The Last Error</b>	<b>Page 35</b>
<b>10</b>	<b>Table of Error Codes and Information</b>	<b>Page 36</b>

# Contents

<b>11</b>	<b>Battery Charger</b>	<b>Page 38</b>
	11.1 Operating Instructions	Page 40
	11.2 Charger Error Codes	Page 40
	11.3 Charger Trouble Shooting	Page 44
	11.4 Charger Maintenance Points	Page 45
	11.5 Programming The Charger	Page 46
	11.6 Replacing The Charger Harness	Page 49
<b>12</b>	<b>Batteries</b>	<b>Page 50</b>
	12.1 Maintaining Wet Lead Acid Batteries	Page 50
	12.2 Load Testing Batteries	Page 52
	12.3 Hydrometer Testing	Page 53
<b>13</b>	<b>Fuse Locations Version 2</b>	<b>Page 56</b>
	13.1 Controller Version 3	Page 57

# Contents



<b>14</b>	<b>Controller Connections</b>	<b>Page 58</b>
	<b>14.1 Controller/Charger Connections</b>	<b>Page 60</b>
<b>15</b>	<b>Trouble Shooting Controller</b>	<b>Page 61</b>
<b>16</b>	<b>Contactor Harness</b>	<b>Page 62</b>
<b>17</b>	<b>Contactor Wiring</b>	<b>Page 62</b>
<b>18</b>	<b>Testing the Main Power Relay</b>	<b>Page 64</b>
<b>19</b>	<b>Wiring Diagram Models with 19 Gallon Tanks</b>	<b>Page 69</b>
<b>20</b>	<b>Wiring Diagram Models with 24 Gallon Tanks</b>	<b>Page 74</b>
<b>20</b>	<b>Wiring Diagram Models with 30 Gallon Tanks</b>	<b>Page 79</b>
<b>21</b>	<b>Notes</b>	<b>Page 84</b>

# 1. Warnings

- **Disconnect the A.C. Cord from the outlet and and D.C. Cord from the battery pack before servicing the machine. Except for making voltage and current measurements.**
- **Before replacing the main fuses, only loosen the nuts. Do not remove them completely. Failure to do so could cause a short circuit.**
- **Place the new stripe fuse fully and evenly under the nuts and washers and make sure not to twist the end tabs, they can easily be torn.**
- **After any repair work is done, test the machine for proper operation.**
- **When servicing the machine always observe the general safety and accident prevention guidelines.**

## 2. General Information

•The display offers a service indication. Upon turning on the key switch, a four digit number describing the software version (e.g. 1.0.0.2) appears for about 3 seconds, followed by another 4-digit code indicating the last error recorded, then followed by the hour meter.

•If a failure occurs, the code appears in the control panel and an acoustic signal sounds. The current error code appears as 4-digit alpha-numerical code with flashing dots in the service display. Only if these criteria are met, the error is a current one!

The error codes are listed in a tables in chapter 10.

---

•When raising the machine with a car jack use the area of the frame in front of the caster wheels on the left or the right.



### 3. Maintenance Intervals



In a modular structure, the Minuteman System Maintenance determines the specific technical procedures to be performed and sets the time interval between the two maintenance cycles.

For each of the maintenance cycle, the replaceable parts are determined as well. Further details described in the specific chapters.

•**Minuteman System Maintenance K:**

To be performed by the customer (in daily or weekly intervals) according to the maintenance and care instructions as specified in the operating instructions.

The operator must be professionally instructed after delivery of the machine by selling dealer.

•**Minuteman System Maintenance I:** (after every 125 hours of operation)

To be performed by an authorized Minuteman Service Center in accordance with the machine-specific system maintenance.

•**Minuteman System Maintenance II:** (after every 250 hours of operation)

To be performed by an authorized Minuteman Service Center in accordance with the machine-specific system maintenance.

•**Minuteman System Maintenance S:** (after every 500 hours of operation, safety check) To be performed by an authorized Minuteman Service Center in accordance with the machine-specific system maintenance.



# 3.1 Minuteman System Maintenance K



To be performed by the customer/user	Interval	
	Daily	Weekly
Fill the clean water tank and mix the proper amount and type of cleaning solution.	O	
Charge the batteries.	O	
Check the brush head, Clean if needed with a damp cloth. Do not get water inside the motor.	O	
Check the squeegee, clean if needed	O	
Check the lid gasket on the recovery tank.	O	
Empty and flush the recovery tank with clean water.	O	
Clean the filter/float inside the recovery tank.	O	
Check the water levels of all the batteries. Add distilled water, if needed. Do not over fill.	O	
Check the pads and brushes for wear. Replace if needed.		O
Check the squeegee hose for clogs, damage and wear. Replace if needed		O
Check the squeegee rubbers for cuts and wear. Flip the blade(s) over or replace.		O
Check the solution filter. Clean if needed.		O
Flush the clean water solution tank with warm water.		O
Test all the functions of the machine.		O

## 3.2 Minuteman System Maintenance I



<b>To be performed by the authorized service center</b>	<b>Interval</b>
	Every 125 hours of operation
Check the battery charger. Make sure it is functioning properly	0
Check the recovery lid gasket. Replace if needed	0
Lubricate the brush lift linkages with grease. Use a small brush.	0
Check for loose hardware, tighten if needed.	0
Check the tire pressure on pneumatic wheels at 65 PSI, if equipped.	0
Lubricate the squeegee linkages with grease. Use a small brush.	0
Inspect the entire machine for damage, wear and proper operation.	0

## 3.3 Minuteman System Maintenance II



<b>To be performed by the authorized service center</b>	<b>Interval</b>
	Every 250 hours of operation
Inspect the caster wheels for wear and damage. Repair, if needed.	0
Inspect the carbon brushes for wear in the transaxle. Replace, if needed.	0
Inspect the recovery drain hose for wear or damage. Replace, if needed.	0
Inspect the brush bumper rollers for wear or damage. Replace, if needed.	0
Inspect the carbon brushes for wear in the brush motors for wear. Blow out with compressed air.	0
Inspect the recovery hose for damage or wear. Replace, if needed.	0
Inspect the squeegee assembly for proper adjustment. Repair, if needed.	0
Test the machine for proper operation.	0

## 3.4 Minuteman System Maintenance S



### ***(Safety Check)***

<b>To be performed by the authorized service center</b>	<b>Interval</b>
	Every 500 hours of operation
Replace the carbon brushes in the transaxle.	0
Replace the carbon brushes in the brush motors.	0
Test the machine for proper operation.	0

## 4. Squeegee Cable And Gasket

**4. The squeegee cable** is attached to the lift lever (top) via a spring (Fig. 5/5). The bottom is attached to the eyebolt at the squeegee mechanism (Fig. 5/6). The squeegee lift cable can be accessed after opening the electronic module cover at the rear of the machine.

**The vacuum motor** is connected to the A1 at A1.X34:5+6 on the controller. Current consumption of the vacuum motor amounts to approx. 25A max.

The vacuum water lift in the closed tank is at least 65 inches (150mbar).

### Recovery Lid Gasket

Insert the recovery tank cover gasket (Fig. 5/7) so that the seam is positioned at the front center with a gap of approx. 1mm. The dirty drip water on the top sealing surface will be drawn into the recovery water tank.



Fig. 5/5



Fig. 5/6



Fig. 5/7

## 4.1 Squeegee Adjustment


### Version one

#### 4.1 Squeegee Adjustment

Correct squeegee adjustment is prerequisite for optimal suction results.

Before adjustment first check the pitch of the squeegee and re-adjust if required.

1. Place machine on level ground.
2. Loosen nut of the adjustment screw (pos. 3, Fig. 5/1) and adjust sealing strips in parallel to the floor. Turn adjustment screw clockwise: clearance between squeegee blade and floor broadens in the center. Turn adjustment screw counter-clockwise: clearance between squeegee blade and floor narrows in the center.
3. Turn machine on, lower squeegee and check drying pattern.



- 1 Squeegee
- 2 Star-shaped knob
- 3 Adjustment screw
- 4 Suction hose
- 5 Toggle-type fastener

Fig. 5/1

## 4.2 Squeegee Adjustment



### Version Two

#### 4.2 Squeegee Adjustment

Correct squeegee adjustment is prerequisite for optimal suction results.

Before adjustment first check the pitch of the squeegee and re-adjust if required.


1. Place machine on level ground.
2. Loosen the two bolts, located on each side (Fig 5/2A) with the squeegee attached while holding another wrench on the location shown on Fig 5/2B. Adjust squeegee rubbers so that they are parallel to the floor, by turning the long adjustment shaft on the right side with an open end or adjustable wrench (Fig 5/2B). Adjust until the rear squeegee blade folds equally accross the entire length, while moving the machine slightly forward.
3. Tighten the two bolts on the ends while holding the center shaft with the wrench.
4. Turn machine on, lower squeegee and check drying pattern.



## 4.3 Squeegee Wheel Adjustment

**4.3** The clearance between the support roller and floor with squeegee unfolded (Factory setting) is: 0.1181099 Inches  $\pm$  0.01968498 inches (3 mm  $\pm$ 0.5).


Note: Some floor surfaces may require adjusting the caster washers for optimum performance. See following page.





## 4.4 Squeegee Wheel Adjustment

**4.4 Note:** When adjusting the wheel height, there should always be 5 washers on each wheel assembly position # 15 in order fully tighten bolts. Move washers from the top to the bottom of the bracket or visa versa when making adjustments. The caster controls the pressure on the squeegee blade.



Pos 1 – Hexagon screw M8x25 A2  
PN 01059530

Pos 5 – Hexagon screw M8x16 A2  
PN 01071740

Pos 6 – Washer B8,4  
PN 00101550

Pos 7 – fixed Roller  
PN 01077810

Pos 8 – Angle with fixed roller, complet  
PN 01079070

Pos 15 – Distance Washer  
PN 01079080

Fig. 5/3

## 4.5 Squeegee Lift Cable, Switch & Motor

### 4.5 Squeegee Lift Cable, Lever, Micro Switch and Vacuum Motor

- The vacuum motor **micro switch** is mounted behind the squeegee lift lever (Fig. 5/4). Adjust the micro switch so that the vacuum motor can be turned off by lifting the squeegee by the lever. Loosen the screws on the switch to adjust.
- Vacuum motor is switched on upon lowering of the squeegee.
- The micro switch is a *normally open* switch which is terminated to input A1.X9:3+9 on the controller. When the squeegee is lowered, there should be continuity between both contacts (with the plug A1.X9 being disconnected).

**NOTE:** The squeegee lift cable spring will need to be disconnected from the silver lever before the squeegee lift lever plate can be removed from the machine. Access can be made from the controller/charger area in the rear of the machine. See Chapter 4.



Fig. 5/4

# 5. Brush Head (Disk) Connections


## 5. Connection of Brush Motors to Disk Brush Head

Connect the brush motors of the disk brush head in accordance with the electric diagrams. Find the assignment of connecting stud of the motors listed in the below table. Then check the correct direction of brush motor rotation.

The left-hand motor seen in direction of travel is M3, the right-hand one is M4.

Cable Harness	Motor connection Disk brush
-M3:1	-M3:N
-M3:2	-M3:P
-M4:1	-M4:P
-M4:2	-M4:N

Connectors at the motor -M3/4
Stud bolt above Connection N
Stud bolt below Connection P



## 5.1 Brush Motor Information



### 5.1 Brush Motors

The brush motors are switched on and off by a micro-switch located at the rear at the brush head lift-out system. This switch is realised as NO (normally open) switch. To attain safe function of the brush motors, correct adjustment of this switch is required.

Electric connection of the switch is realised at the central control at A1.X9:4 + 10.

Maximum current consumption of the brush motors (in practical use) must not exceed 30A per motor on the 26 and 30" disk brush decks. The maximum amperage for the 33" disk decks is 40A.

Lower settings are recommended for longer motor life, run time and traction.

When checking the carbon brushes make sure that the scroll spring is pressing the carbon brush against the commutator, does not contact the guide and that distance to carbon brush guide is sufficient.

Replace the carbon brushes, if required.

## 6. Brush Head

### 6. Brush Head Transport Position

- The lever provided is for lifting up the brush head. It features 3 positions for adjusting the lift linkage (Fig. 6/1). The top hole is the transporting and ramp climbing position. In this position, the lift linkage is to be adjusted so that a 1mm gap appears between the lever and the screw head at the chassis (Fig. 6/2).
- The middle hole position is for scrubbing with pads.
- The bottom hole (Fig. 6/1) is the normal scrubbing position of the brush head.




Fig. 6/1



Fig. 6/2

## 6.1 Brush Switch

### 6.1 Brush Switch

- The brush motors are switched on and off by a micro-switch located at the rear at the brush head lift-out system Figure 6/3. This switch is a NO (normally open) switch. To attain safe function of the brush motors, the correct adjustment of this switch is required.
- Electric connection of the switch is connected to the central control circuit board at A1.X9:4 + 10 connector. In the lifted-up position, the switch should open and close when brush head is lowered.





Fig. 6/3

## 6.2 Brush Pressure Adjustment (Disk Models) **Minuteman**<sup>®</sup> *Excellence Meets Clean*

### Brush Pressure Setting on Disk models.

- The bolt on the left can be adjusted to increase or decrease the brush pressure.
- Models with 19 gallon tanks** This pressure adjustment will affect the models in the normal scrubbing mode. (no extra pressure option)
- Models with 30 gallon tanks.** This pressure adjustment will only affect the models in the heavy pressure mode only (second foot lever activated).
- The indicator on the right should never be set past the second notch.
- NOTE:** When making changes, the current draw should be less than 30 amps. per motor on the 26 and 30" disk decks under load maximum. 40 amps max on 33" decks.
- Lower settings are recommended for longer motor life, longer run time and traction.
- Verify the current with brushes under load, with a digital clamp-on meter.
- Only an authorized Minuteman Service Center should make changes to the brush pressure setting.



**Note: The factory setting set at the second notch**

## 6.3 Brush Pressure (Disk Models)

<b>Model</b>	<b>Area Per Brush</b>	<b>Brush Pressure</b>	<b>Heavy Brush Pressure (2nd Foot Pedal Engaged)</b>	<b>Specific Surface Pressure</b>	<b>Specific Surface Pressure with Heavy Brush Pressure</b>
<b>E3330</b>	1055 cm <sup>2</sup> 163.525 inch <sup>2</sup>	400 N = 90 lb	600 N = 135 lb	0.19 N/cm <sup>2</sup> = .275 lbs per inch <sup>2</sup>	0.28 N/cm <sup>2</sup> = .406 lbs per inch <sup>2</sup>
<b>E3030</b>	761 cm <sup>2</sup> 117.955 inch <sup>2</sup>	320 N = 72 lb	600 N = 135 lb	0.21 N/cm <sup>2</sup> = .35 lbs per inch <sup>2</sup>	0.39 N/cm <sup>2</sup> = .565 lbs per inch <sup>2</sup>
<b>E2830</b>	280 cm <sup>2</sup> 43.400 inch <sup>2</sup>	240 N = 54 lb	NA	0.43 N/cm <sup>2</sup> = .623 lbs per inch <sup>2</sup>	NA
<b>E24</b>	240 cm <sup>2</sup> 37.200 inch <sup>2</sup>	260 N = 58 lb	NA	0.54 N/cm <sup>2</sup> = .783 lbs per inch <sup>2</sup>	NA
<b>E26</b>	586.5 cm <sup>2</sup> 90.908 inch <sup>2</sup>	350 N = 79 lb	NA	0.3 N/cm <sup>2</sup> = .435 lbs per inch <sup>2</sup>	NA




## 6.4 Brush Head (Cylindrical)

### 6.4 Electric Connections

- Connect the brush motors of the cylindrical broom head in accordance with the electric diagrams. Find the assignment of connecting stud of the motors listed in the below table. Then check the correct direction of brush motor rotation.
- The left-hand motor seen in direction of travel is M3, the right-hand one is M4.

Cable Harness	Motor connection Cyl. brush head
-M3:1	-M3:N
-M3:2	-M3:P
-M4:1	-M4:P
-M4:2	-M4:N

Connectors at the motor -M3/4
Stud bolt above Connection N
Stud bolt below Connection P



# 6.5 Adjusting Cylindrical Deck

### Adjust Brush Head

Prerequisites:

- Cylindrical broom head is mounted to the machine
- Machine is equipped with batteries
- Spacer blocks are positioned under the lateral lids

Use adjustment screw (Fig. 5/1) for brush head adjustment. Use a reference gauge (Fig. 5/2) to check the dimension.

1. Position the reference gauge straight between guide (Fig. 5/3) and washer (Fig. 5/4) onto the slider (Fig. 5/5).
2. Ideal adjustment is attained if the central edge (Fig. 5/A) of the reference gauge is flush with the top edge of the guide. If required, modify adjustment such that the upper edge of the guide on both sides does not exceed the + edge and does not fall below the - edge.
3. Counter-lock adjustment screw by nut.




Fig.5

Part number for the gauges are available by request.

## 7. Drive and Wheels

### 7. General Data

Torque of wheel bolts:	23 foot lbs
Torque of wheel nuts:	18 foot lbs
Wheel speed in max. drive potentiometer position:	
Forward: (3.1 mph) 110 min-1	Reverse: (1.55 mph) 55 min-1
Torque of setting for screws on caster mounting:	17 foot lbs

### 7.1 Electric Brake (E33 and 30 Gallon Tank Models Only)

•The drive motor is equipped with a electric brake on the transaxle. In the display, the brake is represented by the  symbol. The transaxle is locked (lever down) by brake as soon as the drive bail handle is in the neutral position.

Release the brake mechanically before pushing the machine. To release, unlock (lever up) the lever located on the drive motor behind the water filter on the left side of the machine directly behind the left-hand drive wheel.

•If the machine is powered up with the brake in the unlocked position the “flashing H” will appear in the hourmeter display. This will prevent the machine from operating for safety reasons.


• When this occurs the coil voltage will be interrupted on the K1 main relay.

Resistance of the electric brake coil amounts to approx. 37 to 41  $\Omega$ .

## 7.2 Transaxle Motor

### 7.2. Transaxle Drive Motor

- Drive motor, axle and differential are a single unit.
- The wheel drive is nearly maintenance-free. Check the carbon brushes of the drive motor at regular intervals during maintenance. Carbon brushes are worn if the scroll spring applying the carbon brushes to the armature, is approx. 1mm away from the guide. Contact of the spring and the guide must be avoided since otherwise the armature can be damaged. Before the check, remove battery and battery tray from the machine.



- The thermal switch of the drive motor is integrated in the motor and cannot be replaced. Such switches are NC (normally closed) switches which interrupt the circuit, if the motor temperature exceeds the limit. The thermal switch is connected to the control board at A1.X9:2+8.

## 7.3 Transaxle Motor Carbon Brushes

### 7.3 Carbon Brushes

Close the cover of carbon brushes again as shown in photos 7/2, 7/3 and 7/4. Make sure that the plastic lock is placed in a motor housing recess for brushes.



Fig. 7/2



Fig. 7/3



Fig. 7/4

# 7.4 Drive and Wheels


## 7.4 Drive Potentiometer Circuit

•Potentiometer Resistance

Value: 5.875 k  $\Omega$  +- 30%

•Assignment of connecting plug (A1.X4):

- Pin 1: Ground
- Pin 2: 24Volts
- Pin 3: Digital signal of drive direction 1
- Pin 4: Digital signal of drive direction 2
- Pin 5: Potentiometer wiper
- Pin 6: Potentiometer +
- Pin 7: Potentiometer -
- Pin 8: not assigned



## 8. Water Supply

**8.1 The solenoid valve releases or stops supply of water flowing to the brushes. The solenoid valve is located at the front pane of the battery compartment. The solenoid valve is electrically connected to the central controller A1 at A1.X11:1+2. See Fig. 8/1**

- Coil resistance of solenoid: approx. 47  $\Omega$
- Current consumption of solenoid: approx. 0.5 A
- Water amount is regulated by ball valve on all the 19 gallon and models.



Fig. 8/1

### 8.2 Solution Filter

The clear water supply line to the brushes is equipped with a filter screen. In case of problems with the supplied water amount, check the screen and the hoses from clear water tank and to the brushes. See Fig.8/2




Fig. 8/2

## 8.3 Water Supply (Solution Tank Clean out)

- The Models E33, E2830, E3030 and E3330 with the 30 tanks will be equipped with a clean out plug on the solution tank.
- The plug may be removed to clean out debris that is inside the tank.





## 8.4 Solution Flow rates



Water Setting		1	2	3	4	5	6
Disk Brush 30 & 33"	Gallons per min	.18	.29	.36	.52	.95	1.45
	Pump Voltage	2.68	3.46	4.61	5.84	9.82	15.43
Cyl. Brush 24"	Gallons per min	.39	.47	.55	.60	.68	.74
	Pump Voltage	4.69	5.99	6.85	7.47	8.45	9.24
Cyl. Brush 28"	Gallons per min	.39	.47	.55	.60	.68	.74
	Pump Voltage	4.32	5.86	6.77	7.15	8.00	9.86

**Note: Values are proportional to the drive speed except for position 6**  
 This information applies to models equipped with a solution pump only.  
 The E26 is manually controlled by the operator.

## 8.5 Water Pump

### 8.5 Solution Control

- **Models equipped with water pump**
- **The solution flow rate is affected by the speed of the drive system.**
- **The controller adjusts the voltage to the pump to regulate water volume.**
- **The faster the machine is driven the more water will flow to the brushes.**
- **The controller uses stand still recognition circuitry. The pump will be shut off, if the water supplied to the pump is too low or inefficient, when the voltage supplied to the pump is above the 5 volt level. This feature is disabled if voltage is below 5 volts.**

## 9. The Last Error



**9. All Minuteman E24, E26, E2830, E30ECO, E30, E28, E3030, E3330, E33XL, H26, H30 and 19, 24 and 30 gallon models are equipped with an error memory which will indicate the last error that occurred in the machine. This last error is displayed upon turning on the machine by key switch. The first numbers that appear will be the software version. The second will be the last error (if one had occurred). The third will be the hour meter.**

**•If four digit error code is displayed continuously with blinking dots and the alarm is sounding, the controller has detected a problem in the system. The machine will be inoperable. See error codes for details.**

# 10. Table of Error Codes



Error code	Error source	Remarks
1.2.5.2.	Thermal switch Brush 1/2	Check temperature of brush motors; check current consumption of brush motors; check wiring of thermal switch (X8 and X9 plugs) of the brush motors (series connection). Input A1.X9:1 and 7
1.2.6.1.	Blocking protection Brush 1/2 Electronic protection of brush	Brush motors smooth running? Check current consumption? 30A max. per motor
3.1.6.E.	Fuses of power unit	Check all fuses, batteries and connections & main relay (voltage has dropped below 15 volts)
3.2.1.1.	LDS defective	Is battery voltage identical to voltage at A1:X1 and A1.X2? (idle run and under load)
3.4.1.1.	Drive rheostat (potentiometer)	Check drive rheostat and wiring, is drive rheostat detected at the controllers A1X4 connection?
3.4.1.2.	Off isle switch on during start up or Drive control defective	Turn off off isle switch and restart machine, if equiped. Check for shorts in harnesses and motors, If error is permanent, replace controller.
3.4.5.1.	Drive motor overheated	Check thermal switch and wiring from drive motor, X10 plug

# 10. Table of Error Codes



Error code	Error source	Remarks
4.5.2.5.	Control panel not recognized	Check connecting cable between central controller and control panel. This error occurs upon switching on only.
4.5.3.5.	No response control panel (Timeout)	Check connecting cable between central controller and control panel. This error occurs upon switching on only.
4.6.1.2.	Internal controller error	If error is permanent and even after repeated switching on and off of the machine, replace central controller
5.1.4.1.	Main contactor does not switch	Does main contactor K1 switch? Check main contactor wiring. Contacts
5.4.6.1.	Error upon system start (signal states) Possible wire grounded to frame	Check for wires grounded to frame. If error is permanent and even after repeated switching on and off of the machine, replace controller
"H" "P"	Hand brake unlocked brake locked	Hand Magnet brake at drive motor

# 11. 24V - 22A Charger

## 10.1 Operating Instructions

Controlled battery charger for lead batteries with liquid and solid electrolyte in SNT technology

**controlled backup charging - reverse battery protection**  
**protection against short circuit - const. conservation of charge**  
**low AC-current**

### **General**

The battery charger is designed for automatic charging of single cell sulphuric acid batteries (12 cells) according to battery type, capacity and initial charging current indicated on the name plate.

The charging is done as per the IEB (di/dt - du/dt) characteristic curve. It is controlled and switched off by an electronic controlled charging switch device.

The housing of the battery charger is made of enclosed sheet metal steel.

Connection to wall outlet (plug socket) is made via an incorporated mains connection cable.

Mains fuse (F1): Micro fuse 5x20 mm. Back-up only through value resembles T 3,15 AH 250V.

The battery charger has to be connected to mains supply with a earthing contact outlet; it should be made safe by means of a 16 ampere inert fuse.

The battery charger is protected against short circuits and equipped with a reverse battery protection.

The battery charger should only be opened by qualified personnel.

**Attention: Non-rechargeable batteries can not be charged with this battery charger.**

The battery charger complies with the protection regulations of the low voltage guideline 72/23/EEC and the guideline for electro-magnetic compatibility 89/336/EEC



EN 60 335-1  
EN 60 335-2-29

# 11.1 24V - 22A Charger



## Installation

Keep the charger away from other heat radiating devices.  
The cooling system of the housing ensures better heat dissipation for the components and must not be covered. Use the battery charger in a dry and well-ventilated area.

## Sequence of connection:

The charger has to be disconnected from the mains supply before connecting/ disconnecting the charge plug/ cables to the battery.


## **Functional description and monitoring of charging process**


The battery charger begins charging automatically, if the mains power and the battery connection has been properly connected.

With load beginning the battery connection is checked, all LED 's light up briefly.

The lower charge icon  lights up.

When the preset gassing voltage has been reached this voltage is stabilized and the current drops slowly (U constant). After the current has reached a constant phase, the charger switches over to backup charging

and the middle and lower charge icon  lights up.

After the backup charge has been completed the charging electronic switch device changes to end of charging/const. conservation of charge. All three charge icons  lights up.

Do not interrupt the charging procedure until battery is adequately charged. An interruption may cause a loss of capacity and premature failure of the battery.

The driving-off protection is a potential-free contact preventing the use of the vehicle during the charging process.

**„Battery not connected“ is indicated by the red LED and is detected immediately when switching on the battery charger during operatin; at the latest 20 secs. after disconnection of the battery.**

**Please make sure that there is no reverse connection of the battery during this time!**

**When the battery is connected again, the charging set switches itself on.**

# 11.1 24V - 22A Charger

## Indication of operating status by external Display

operating status	LCD-/ LED- Indicator				
Main charging $U_{bat} < 1,9V/Z$	X				
Main charging		X			
Backup charging			X		
Conservation charging				X	
operating status during malfunction*					malfunction number
Battery malfunction	X				1..2
Time malfunction		X			3..4
Control malfunction			X		11..13
Temperature malfunction				X	6

\* If there is a malfunction the frame/under LED flashes once a second.




## 11.2 Charger Error Codes

**10.2 Note:** The following are error indicators that could occur during the battery charging process. All errors will be in the form of a blinking display picture of the battery.

The display indicator figure # 1 will display a blinking dotted square, if the battery malfunctions for the following reasons:

1. The battery has less than 1.25 volts per cell.
2. The battery has less than 15 volts after 30 minutes
3. The batteries are wired incorrectly (reversed polarity).
4. The batteries are missing.
5. The wrong battery type is installed.
6. The selected programming of the charger is incorrect for the batteries that are installed.


Fig.1



## 11.2 Charger Error Codes

The display indicator figure # 2 will blink, when the charger timer times out. This occurs when the battery voltage on a 24 volt battery pack does not reach 22.8 volts or higher after 30 minutes. The charger will shut off.


Fig. 2



The display indicator figure # 3 indicates that there is an error in the charger.

1. The charger needs repair or replacing.

Fig. 3




## 11.2 Charger Error Codes

The display indicator figure # 4 will blink when the charger is over heating:


1. The cooling air is restricted
2. The cooling fan is not working.
3. The cooling hose is not connected or is obstructed.

Fig. 4



Programming button depressed or stuck, while starting the charging operation.

Fig. 5



## 11.3 Trouble Shooting the Charger



- **Symptom - charger has no output.**  
Check for loose or burnt connections on the side of the charger.
- **Use a test cord by-pass the original AC power cord.**

**Note: Continuity and voltage tests may not be adequate for testing the condition of the AC cord.**



- **Power cords from a desk top computer will make a good test cord.**

### •10.4 Charger Maintenance Points

- Check the following, when servicing the machine:
- The charger unit should be secured by rubber strap.
- The wires going to and from the charger should be secured with plastic wire ties. They should be routed so that there are not any kinks, pinched or crushed wires.
- The charger housing must be **insulated** from all metallic machine parts. Use a multi-meter to measure the resistance between charger housing and the frame on the machine. There should not be continuity.
- Repeat the test by checking the resistance between the A.C. Cord ground pin of the charger and frame of the machine. There should not be continuity.
- The ground pin of the A.C. cord **must** conduct without resistance to the screws on the charger case.
- The charger ventilation hose must in place and without obstruction.

## 11.5 Programming the Charger

- 10.5** The automatic scrubbers are equipped with the new on board automatic charger. The charger will be programmed from the factory for the wet lead acid batteries. Machines that were purchased with gel maintenance free batteries installed at the factory will be programmed for gel.
- 1.** The charger can be programmed to charge either the gel type battery or wet lead acid batteries.
  - 2.** Follow the instructions below to change the charging mode.
  - 3.** Remove the two Allen head screws on the rear of the machine. Let the charger/controller-cover drop down. The charger is located on the rear of the housing.
  - 4.** Remove the nut and washer on the backside. Carefully lift the plastic cover off and set it to the side.
  - 5.** Plug the charger's A.C. power cord into the outlet. The charger will turn on.
  - 6.** Locate the small push button switch on the right side of the charger. Located near the rubber strap.



## 11.5 Programming the Charger Cont.



- 5. Push and hold the button in for 2 to 4 seconds and release. The charger will turn off.**
- 6. Push and hold the button in again for >10 seconds and release. This puts the charger into the programming mode. The picture on the machine's display will blink rapidly indicating which charging mode has been previously stored in the charger.**
- 7. Push the button for <1 (one) second at a time to select a different charging mode. The picture will blink slowly, indicating that you're in the selection mode. Push the switch repeatedly until the desired mode is displayed.**
- 8. The charger will show a total of 8 (eight) different charging modes. (See pictures below for the proper mode). The remaining settings do not have any additional functions.**

# 11.5 Programming the Charger Cont.



Mode # 0 is for the Trojan # 956752 260 Ah batteries for the charger 96137732 only.



Mode # 1 is for AGM batteries 956749 (260 Ah) & 956200 (200 Ah) for the charger 96137732 only.



Mode # 5 is for gel type batteries using chargers prior to charger serial 96117197 7 6992 6



Mode # 6 is for the wet lead acid batteries only. All chargers have this setting. This is the Default setting



Mode # 7 is for gel batteries only after charger serial 96117197 7 6992 6 and all 96137732 chargers.



Note 1: Settings 2 ,3 and 4 are the same as 5 on the 96137732 charger.


Note 2: Settings 2, 3, 4 and 7 are the same as 5 before serial number 96117197 7 6992 6.

Note 3: Do not use other settings on chargers after serial number 96117197 7 6992 6.



## 11.5 Programming the Charger Cont.

9. To save the desired mode, press and hold the button for more than 5 seconds and release. The picture on the display will blink rapidly indicating the setting has been stored.
10. To end the programming mode function, wait about 60 seconds. The charger will automatically return to its normal operation.
11. Unplug the X31 jumper connector on the main control board harness for the gel and AGM maintenance free batteries. Connect the X31 plug to the harness for the lead acid type batteries. Secure the X31 connector with a plastic tie in the control board area when not in use.
12. Install the plastic cover with the nut and washer.
13. Install the two screws and secure the charger/controller cover to the original position.



## 11.6 Replacing the Charger Harness



- When replacing the charger output harness (W8) 97094346 on 19 gallon models or 011722530 on 30 gallon models with the electric brake.
- Use the K-E24261668 Charger Retro fit kit in addition when either the harness or charger is being replaced.
- Inspect the receptacle on the charger for burnt or damage. Replace the charger if it is damaged.
- Use a coating of high temperature dielectric grease (NYOGEL 760G GREASE) or equivalent, on the pins of the plug of the harness, before connecting the new harness to the charger.

## 12. Batteries

### 12.1 Maintaining Wet Lead Acid Batteries

1. **Always keep the water levels above the plates**
2. **Fill cells with distilled water only. Tap water can cause an excessive build up of minerals and reduce the chemical reaction of the batteries. This will shorten the life and performance of the batteries.**
3. **Use an appropriate filling device, when filling the batteries. Do not use a garden hose. Flooding the batteries can flush the electrolyte out of the battery and shorten its life.**
4. **Fill cells 3/8 to 1/2 of an inch above the separators. Do not fill above the fill the marker of the batteries. Over filling can cause the electrolyte to percolate out onto the case while charging.**

## 12.1 Batteries

5. Check water level daily. Fill, if needed.
6. Keep all the battery cable connections tight.
7. Keep all the battery posts and cables clean. Clean the battery cases with a mixture of baking soda and water solution or commercial spray that neutralizes the acid. Spray the cases with a water displacement chemical or a silicone. This will help break the flow of current across the case and reduce the discharge rate .

**Note: The electrolyte on the surface of the case can cause:**

- A. The batteries to discharge faster even while sitting and have a shorter run time.
- B. The battery charger to stay on for extended periods. Thus causing an over charge condition and shortening the life of the batteries.
- C. Never leave batteries in a discharged state for long period of time.

## 12.2 Load Testing Batteries



### 12.2 Load Testing

**Load test battery with an automotive type load tester. This test puts an ampere load on the batteries and measures the voltage at the same time. If voltage drops more than 1 volt on the meter this would indicate that the batteries are weak or discharged.**

**Note: batteries must be fully charged and cooled (2 hours minimum). Hot batteries will have higher specific gravity readings, which may lead to incorrect diagnosis.**

**Note: Batteries that still have run time of more than 30 minutes may test good with load tester. If possible run the batteries down while monitoring the time. Load test again. Most machines will run for about 2 to 2.5 hours with good batteries.**

**Load testing can identify dead cells, broken or disconnected plates, and cells or charge status. This is good test however, it can only detect these types of failures. See Specific Gravity Test for additional tests.**

### 12.3 Hydrometer Testing on Lead Acid Wet Batteries

- Hydrometer testing can be used to measure the specific gravity of deep cycle batteries. This allows you to detect weak cells, which are causing loss of running time. It can only detect these types of problems. The hydrometer should have specific gravity markings such as 1.265, 1.250, 1.225, and so on.
- Hydrometers with the four balls are not accurate enough for this test and are not recommended.
- Fully charged batteries should read 1.265 or higher and will decrease as batteries are discharged until they reach 1.120. This test should be done when batteries are charged and cooled. Allow one hour or more to cool. It can also be done after batteries are partially discharged, if they are allowed to cool. However, you will not be able to detect the full capacity of the battery.

## 12.3 Hydrometer Testing Batteries Cont.



- **To do an accurate test, the battery water level must be high enough to extract enough electrolyte to fill hydrometer enough so that the indicator floats. If the water levels are low, water should be added prior to charging in order to let the electrolyte to mix.**
- **The greater the variation between cells readings, the greater the loss of run time. For example, if the readings are 1.265, 1.265 and 1.225 in one 6 volt battery. The low cell would be considered weak and greatly reduce the performance of the battery or shorter run time. This battery would have a point 40 variation. Batteries that have weakened cells in most cases it can still be used as long they continue provide adequate run time. A battery with a point 40 variation or more should be determined defective.**

## 12.3 Batteries (Wet Lead Acid)



- **Minuteman batteries are rated for 500 charge cycles.**  
**Every time the batteries are charged it uses one cycle.**  
**To insure getting the expected life, unnecessary charging should be avoided.**
- **The specific gravity will reflect the percentage of charge remaining in the battery.**
- **100% charge = 1.265 and above Specific Gravity**
- **75 % charge = 1.225 Specific Gravity**
- **50 % charge = 1.190 Specific Gravity**
- **25 % charge = 1.120 Specific Gravity**
- **Note : AGM & Gel maintenance free batteries can not be tested with the hydrometer.**  
**Do not attempt to open cell covers or caps. Doing so will destroy the battery.**



## 13. Fuse Locations (Version 2 Controller)

All the fuses are located on the main control circuit board.


### Part Numbers

00059580 Fuse 125 Amp 80 Volts (Brush & Vac. Motors)  
00972420 Fuse 100 Amp. 80 Volts (Brush & Vac. Motors)  
00733630 Fuse 10 Amp. 32 or 80 Volts (Pump & Water Sol.)  
00902440 Fuse 50 Amp. 80 Volts (Drive)  
00972430 Fuse 2 Amp. 32 Volts (Switch)

Note: If the 2 amp fuse blows, check the main contactor for bad contacts.

**Warning: Do not substitute the value of the 50, 100 and 125 amp fuses.**

**They must be correct voltage and amperage. Doing so will produce system errors. Fuses are used as shunts in the circuit.**



# 13.1 Fuse Locations (Version 3 Controller)


**10 Amp Fuse**  
**32 or 80 Volts**  
**00733630**

**125 Amp Fuse**  
**80 Volts**  
**00059580**

**2 Amp Fuse**  
**32 Volts**  
**00972430**

**50 Amp Fuse**  
**80 Volts**  
**00902440**


**5 Amp Fuse**  
**32 Volts**  
**00906120**



# 14. Controller Connections

## Controller Connections

For E24, E26, E28, E30, E33, E33XL, E2830, E3030 and E3330



A1 X 4			
Potentiometer wiper	5	1	Deadman switch left side
Potentiometer & deadman switch	6	2	No connection
Potentiometer	7	3	Drive switch forward
No connection	8	4	Drive switch reverse

A1 X 9			
Brush motor thermo switch	8	1	Brush motor thermo switch
Transaxle thermo switch	9	2	Transaxle thermo switch
Vacuum motor switch	10	3	Vacuum motor switch
Brush motor switch	11	4	Brush motor switch
Acoustic warning Switch	12	5	Acoustic warning Switch
Battery type X31 connector	13	6	Battery type X31 connector
No connection	14	7	No connection

A1 X 34				
5	6	4	3	2 1
Vac motor Rt br mtr		Left br mtr		

A1 X 20	
1 Red	2 Black
Transaxle	

A1 X 21			
To G2 X3 pin 1 (Charger) (org-white)	5	1	To G2 X 2 pin 1 (Charger) Relay (org-blue)
To G2 X3 pin 4 (Charger) (org-white)	6	2	To G2 X 2 pin 2 (Charger) Relay (org-blue)
To G2 X3 pin 2 (Charger) (black-red)	7	3	To G2 X3 pin 6 (Charger) (org-white)
To G2 X3 pin 5 (Charger) (red-black)	8	4	To G2 X3 pin 3 (Charger) (org-white)

A1 X 8			
To Contactor K1:1 (Contact Pos.)	2	4	To Contactor K1:3 (Contact Neg.)
To Contactor K1:A2 (Coil Neg.)	1	3	To Contactor K1:A1 (Coil Pos.)

A1 X 3  
Not Used


A1X22  
Ribon Cable (Display)

A1X11			
Acoustic Alarm Output	6	1	Acoustic Alarm Output
NC	7	2	NC
Water Solenoid	8	3	Water Solenoid
Water Pump	9	4	Water Pump
Electric Brake Coil (if Equipped)	10	5	Electric Brake Coil (if equipped)

# 14.1 Controller/Charger Connections

97101372 W6 Wire Harness

**Connections between the controller and the battery charger on model numbers: E24, E26, E28, E30, E30ECO, E33XL, E2830, E3030, E3330 and H26.**



All Views are shown from the back or wire side of connector

## 15. Trouble Shooting the Controller




**Note: If the 5 amp fuse on the controller blows, It could indicate:**

- 1. A faulty contactor (not closing on the negative side).**
  - 2. Poor connection on the battery negative side of the contactor.**
  - 3. Poorly crimped terminals on the contactor connections.**
  - 4. Incorrect wiring of the contactor. (See chapter 16-17)**
- NOTE - Always use a coating of high temperature dielectric grease (NYOGEL 760G GREASE) or equivalent on the motor connectors on the bottom of the controller when replacing the board or motor harnesses.**


**Caution: Connecting the battery pack polarity incorrectly will permanently damage the controller.**

# 16. Contactor Wiring – Harness



# 17. Contactor Wiring



Proper wiring of the contactor is critical



# 18. Testing the Main Power Relay




Digital Volt Meter



**Note:** Measure the voltage across the B+ and the B- coil terminals with the wires attached and the key switch turned on. It should be about 24 volts. If not, possible low battery condition. Inspect batteries.





# 18. Testing the Main Power Relay



# 18. Testing the Main Power Relay



Digital Volt Meter



Batteries

OR

B+  
From Battery

B-  
From Battery

B-  
Controlled


B+  
Controlled

Note: Measure the voltage from the battery positive source to the B- terminal of the main relay's coil to determine if the B- is being supplied to the coil. It should be 24 volts. If not, possible blown 5 amp fuse or relay or key switch circuit problem. Also check connections on the on-board charger

# 18. Testing the Main Power Relay




Note: Measure the voltage on the incoming battery side across the B+ & B- terminals when the machine is powered up and under load.



# 18. Testing the Incoming Contact Voltage on the Main Power Relay





**Note:** The voltage should be exactly the same as the battery side when the machine is under load.



**The relay is defective**

**Note:** The incoming voltage was 25.5 volts






variant E24  
 99-7061-31  
 99-7061-41

variant E26  
 99-7061-11  
 99-7061-21

**For models E24, E26, H26 and E30ECO**

=	1	Zx	0912-00	18.04.07	PK	2007	Datum	Name	VES-Nr. :	Benennung	91025890	Zählungs-Nr.
	+	Nr.	Zahl	Änd.-Nr.	Datum	Name	Gezeichnet	09.03.	Kupe			






motor connection		only E24	only E26	connection central brush at motor -M3/-4
cable marking	central brush	-M3.1	-M3.1	brush plug topside
		-M3.2	-M3.2	brush plug bottom
		-M3.3	-M3.3	connection P

notice:  
 loom of cables -W13 (97098503) and loom of cables -W14 (97097786) only for cylindrical screw brush. For central brush connect the wires of thermal switches direct at -X8 and -X9.

variant E24  
 99-7061-31  
 99-7061-41

variant E26  
 99-7061-11  
 99-7061-21



connector -X31  
 connected (state of deliver):  
 battery type G15 (wet)  
 disconnected:  
 battery type G1V (dry)

**For models E24, E26, H26 and E30ECO**

PLOT DATUM : 21.05.2007 B-Stand : 003 / Ri. / 03.05.07 1004 / Kupe / 03.05.07

0912-02	03.05.07	PL	2007	Datum	Name	VES-Nr. :	Benennung	Zuschnungs-Nr.	
				Gezeichnet	15.03. Kupe		wiring diagram	E24 / E26	91025882
				Geprüft					
				Änd.-Nr.	Datum	Name	Ersetzt Nr. -	G1.Nr.	
							0912-00		
100-Prozent Zeichnung behält sich alle Rechte vor (Artikel 1711 Z11)								Typ: 061-01/21/01/01	
								Blattzahl: 3 Blatt: 1	


ref.	designation	part no	path	ref.	designation	part no	path
-A1	controller E24 / E26	90532334	/1.20		only variant E24		
-A2	control panel	90487216	/1.26				
-G1	battery		/1.3	-A3	key board	90487232	/1.29
-G2	on-board-charger	97097679	/1.3	-B2	signal transmitter (option acoustic warning)	97094312	/1.6
-K1	main contactor	90331026	/1.9	-S10	acoustic warning on (option acoustic warning)	90224650	/1.4
-M1	drive motor	90531609	/1.36	-S11	spray tool on (OPTION spray tool)	90224650	/1.13
-M1.S1	thermal switch drive motor	to -M1	/1.37				
-M2	suction motor	97096200	/1.37				
-M3	conical brush motor left	90507476	/1.31				
or	cylindrical brush motor left	90472390					
-M3.S1	thermal switch brush motor left	to -M3	/1.33				
-M4	conical brush motor right	90507476	/1.31				
or	cylindrical brush motor right	90472390					
-M4.S1	thermal switch brush motor right	to -M4	/1.33				
-M7	water pump	97047310	/1.8				
-R1	speed giver	97099386	/1.34				
-S1	key switch	90323437	/1.26				
-S3	suction on	90306002	/1.37				
-S4	brush on	90306002	/1.35				
-S5	dead man switch left	90520446	/1.28				
-S6	direction switch	90516147	/1.30				
-S7	dead man switch right	90520446	/1.26				
-X1	battery connector 160A		/1.2				
-X8	connector 2 poles		/1.36				
-X9	connector 2 poles		/1.38				
-X10	connector 2 poles		/1.37				
-X12	connector 2 poles		/1.33				
-X18	connector 1 poles		/1.8				
-X19	connector 1 poles		/1.9				
-X24	connector 3 poles		/1.4				
-X25	connector 1 poles		/1.1				
-X26	connector 1 poles		/1.3				
-X31	connector 2 poles		/1.18				
-X32	connector 3 poles		/1.33				
-X101	connection virtual ground at chassis		/1.13				
-X102	connection virtual ground at direction switch		/1.13				
-Y1	water valve	90435595	/1.12				

**For Models E24, E26, H26 and E30ECO**


2	0912-02	./.	03.05.07	Ri.	2007	Datum	Name	VES-Nr. :	Hako	Benennung :	=	+	91025882	Blatt 2
					Gezeichnet	15.03.	kupe	Ersatz für : GL.Nr.						
Nr	Änd.-Nr.	Zahl kommt vor	Datum	Name	Normgepr.	Änd. Nr. :	0912-00		Hako-Werke GmbH					
									D-23840 Bad Oldesloe					




only variant E24  
-A3, -B2, -S10 and -S11




### machine with conical brush



### machine with cylindrical brush




**For Models E24, E26, H26 and E30ECO**

=	2	✓	0912-02	03.05.07	Ri.	2007	Datum	Name	VES-Nr. :	Benennung	E24 / E26	 Hako-Werke GmbH D-23840 Bad Oldesloe	Zeichnungs-Nr. 91025882
						Gezeichnet	15.03.	kupa	Ersatz für:				
+	Nr.	Zahl kommt vor	Änd.-Nr.	Datum	Name	Normgepr.			Änd. Nr. :	0912-00			Blatt: 3







cable marking	motor connection		connection conical brush at motor -M3/4
	conical brush	cylindrical scrub brush	
-M3:1	-M3:N	-M3:N	binder plug topside
-M3:2	-M3:P	-M3:P	connection N
-M4:1	-M4:P	-M4:N	binder plug below
-M4:2	-M4:N	-M4:P	connection P

notice:  
loom of cables -W13 (97098503) and loom of cables -W14 (97097786) only for cylindrical scrub brush. For conical brush connect the wires of thermal switches direct at -X8 and -X9.

connector -X31  
connected (state of delivery):  
battery type GiS (wet)  
disconnected:  
battery type GiV (dry)


**For Models E28 and E30 Only**

=	2	/	1174-00	19.12.07	Ri.	2007	Datum	Name	VES-Nr. :	Benennung	E2833	Hako-Werke GmbH D-23840 Bad Oldesloe Typ: 7062-12/15/18	Zeichnungs-Nr. 91026567
	Nr.	Zahl kommt vor	Änd.-Nr.	Datum	Name	Normgepr.	Gezeichnet	Geprüft	Änd. Nr. :	1066-00			


PLOTDATUM : 19.12.2007 B-Stand : 003 / Ri. / 19.12.07 [004 / kupe / 19.12.07]




### machine with conical brush



### machine with cylindrical brush





**For Models E28 and E30 Only**




2

top view of battery block



=	2	1x	1174-00	19.12.07	Ri.	2007	Datum	Name	VES-Nr. :	Benennung		 Hako-Werke GmbH D-23840 Bad Oldesloe	Zeichnungs-Nr.		
						Gezeichnet	07.06.	kupe	Ersatz für:	GI.Nr.	circuit diagram		E2833	91026567	
+	Nr. Zahl kommt vor		Änd.-Nr.	Datum	Name	Normgepr.			Änd. Nr. :	1066-00	Für diese Zeichnung behalten wir uns alle Rechte vor. (Gemaß DIN 34)		Typ: 7062-12/15/18	Blattzahl: 3	Blatt: 3



cable marking	motor connection	connection conical brush at motor -M3/4
-M3:1	-M3:N	binder plug topside connection N
-M3:2	-M3:P	binder plug below connection P
-M4:1	-M4:N	
-M4:2	-M4:P	

99-7036-50  
option  
spray tool

-S11  
spray tool on

connected (state of delivery):  
battery type G1s (wet)  
disconnected:  
battery type G1V (dry)


For models E2830, E3030, E33XL and E3330

=	0	Eingeführt It.	1177-02	12.12.07	Ri.	2007	Datum	Name	VES-Nr. :	Benennung	E33 / Ph 35	Hako-Werke GmbH D-23840 Bad Oldesloe Typ: 7311-23/-24	Zeichnungs-Nr. 91026906
									Ersatz für :	connec. scheme			
+	Nr.	Zahl kommt vor	Änd.-Nr.	Datum	Name	Normgepr.			Änd. Nr. :	Für diese Zeichnung behalten wir uns alle Rechte vor. (Gemäß DIN 34)	Blattzahl: 2	Blatt: 1	


PLOT DATUM : 12.12.2007 B-Stand : 001 / Ri. / 12.12.07 [002 / kupe / 12.12.07]







motor connection		connection conical brush at motor -M3/4	
cable marking	conical brush		
-M3:1	-M3:N		binder plug topside connection N
-M3:2	-M3:P		binder plug below connection P
-M4:1	-M4:P		
-M4:2	-M4:N		



connector -X31  
 connected (state of delivery):  
 battery type Gis (wet)  
 disconnected:  
 battery type Giv (dry)

99-7036-50  
 option  
 spray tool

Nr.	Zahl kommt vor	Änd.-Nr.	Datum	Name	Normengepr.	VES-Nr.:	Benennung	Blattzahl:	Blatt:
=	0		1177-02	12.12.07	Ri.	2007	Datum Name	36 / Ph 35	1
+									

For Models E2830, E3030, E330 and E33XL



ref.	designation	part no	path	ref.	designation	part no	path
-A1	controller E24 / E26	90541483	/1.20	-X102	connection virtual ground at direction switch		/1.13
-A2	control panel	90487216	/1.26	-Y1	water valve	90435595	/1.12
-A3	key board	90487232	/1.29				
-G1	battery		/1.3				
-G2	on-board-charger	97097679	/1.3				
-K1	main contactor	90529942	/1.9				
-M1	drive motor	90539750	/1.32				
-M1.S1	thermal switch drive motor	to -M1	/1.33				
-M1.S2	brake switch drive motor	to -M1	/1.37				
-M1.Y1	brake drive motor	to -M1	/1.35				
-M2	suction motor	97096200	/1.37				
-M3	conical brush motor left 850	90507484	/1.31				
-M3.S1	thermal switch brush motor left	to -M3	/1.33				
-M4	conical brush motor right 850	90507484	/1.31				
-M4.S1	thermal switch brush motor right	to -M4	/1.33				
-M7	water pump	97047310	/1.8				
-R1	speed giver	97100416	/1.34				
-S1	key switch	90323437	/1.26				
-S3	suction on	90306002	/1.37				
-S4	brush on	90306002	/1.35				
-S5	dead man switch left	90520446	/1.28				
-S6	direction switch	90516147	/1.30				
-S7	dead man switch right	90520446	/1.26				
-S11	spray tool on (OPTION spray tool)	90224650	/1.12				
-X1	battery connector 160A		/1.2				
-X8	connector 2 poles		/1.37				
-X9	connector 2 poles		/1.37				
-X10	connector 2 poles		/1.33				
-X12	connector 2 poles		/1.34				
-X17	connector 4 poles		/1.35				
-X18	connector 1 poles		/1.8				
-X19	connector 1 poles		/1.9				
-X24	connector 3 poles		/1.4				
-X25	connector 1 poles		/1.1				
-X26	connector 1 poles		/1.3				
-X27	connector 1 pole		/1.13				
-X31	connector 2 poles		/1.18				
-X32	connector 3 poles		/1.33				
-X101	connection virtual ground at chassis		/1.13				

**For Models E2830, E3030, E3330 and E33XL**


0	1177-02	Eingeführt lt.	12.12.07	Ri.	2007	date	name
					drawn by	09.11.	kupe
					checked		
no	modified no.	no. available	date	name			

indemnity for:  
modified no.:






top view of battery block



**For Models E2830, E3030, E3330 and E33XL Only**

=	0	Eingeführt lt.	1177-02	12.12.07	Ri.	2007	Datum	Name	VES-Nr. :	Benennung	E 33 / Ph 35	 Hako-Werke GmbH D-23840 Bad Oldesloe	Zeichnungs-Nr.		
	Ersatz für:		circuit diagram		91026898										
+	Nr.	Zahl kommt vor	Änd.-Nr.	Datum	Name	Normgepr.			Änd. Nr. :	Für diese Zeichnung behalten wir uns alle Rechte vor. (Gemaß DIN 34)		Typ: 7311-23/-24		Blattzahl: 3	Blatt: 3

# 21. Notes

