

Propane Testing

Honda co% = .01-.05 turn the Set screw in bottom regulator counterclockwise to lower co%.

Kawasaki co%= .01-.04. If the Kawasaki Doesn't Start turn the set Screw clockwise.

Rpm should be no Higher than 3700. No lower than 1800

