

MINUTEMAN X829 WET/DRY FILTER REPLACEMENT



****Always be sure to wear protective gear when working with critical filter vacuums and when handling hazardous materials****

1. Insert the 6 mil hazardous collection bag (part # 805037pkg) into the tank. Put as much of the bag inside the tank as possible, leaving only about 2" of bag to overhang on the outside of the tank.





2. Next, cut a 1" slit in the plastic recovery bag at the top of the tank directly across from the intake. This will prevent the vacuum from trying to suck the bag up into the vacuum motor.

3. Carefully place the uni-adaptor onto the tank, making sure the plastic recovery bag is still hanging over the tank. Fasten the 2 latches so the uni-adaptor is securely attached to the bottom tank.



4. Next, gently slide the filter protector (part # 805038pkg) over the cloth filter. Place the cloth filter with the filter protector into the uni-adaptor.

5. Next attach the pink impact filter (part # 110005pkg) to the H.E.P.A. filter which is mounted on the bottom of the lid assembly. Line up the black tabs on the impact filter with the raised notches on the H.E.P.A. filter and push into place.



6. Place the lid assembly onto the uni-adaptor and fasten the 2 clamps. Note the clamps have 2 positions for wet recovery or dry recovery. Even though you may be using the X829 for wet recovery, the latches should always go onto the dry side because you will always be using a bag filter in the X829 wet dry vacuum.



7. When you are through using the vacuum, remove the pre-filter from the cloth filter and put it into the plastic liner. This pre-filter should be changed every time you empty the vacuum. The pink impact filter should be changed every other time you empty the vacuum.

8. Bunch up the bag and secure it with a zip tie. Make sure that the zip tie is below the 1” cut that you made in the bag before starting. Tilting the tank to its side makes it easier to remove the bag.

