




REF.	CODE	DESCRIPTION	QT
1	GR23945-	WIRING	1
2	SL03210	GASKET	1
3	SL04176	SCREW	12
4	SL14229	SPACER	4
5	E86642	Pump Card	1
6	E86639	Traction Card	1
7	E88229	Washer	4
8	E86512	Spring	1
9	SL04178	SCREW	2
10	E86422	Micro Switch	1
11	E89214	Foil / Lamina	1
12	SL06016	WASHER	2
13	SL04148	SCREW	2
14	SL17166	COVER	1
15	E87876	Gasket	2
20	E86543	Fuse Cover for AS20	1
21	E86426	Screw for AS20	2
22	SL23209	FUSE TONGUE	1
23	E86647	Fuse 40A	2
24	E86825	Fuse 5 amp	2
25	E86827	Fuse 25 amp	1
26	E89468	Fuse Carrier	1

