




REF.	CODE	DESCRIPTION	QT
1	SL04116	SCREW	3
2	E89120	Washer	2
3	E86731	Return Spring	1
4	SL07361	BUSHING / BUSH	1
5	SL07362	PIN	1
6	E86409	Bearing, 6005 2RS	2
7	SL05050	NUT	1
8	E86462	AS20 Nut	1
9	E86870	Screw	1
10	E86879	Washer	3
11	SL09797	SUPPORT	1
12	E86427	Washer for AS20	2
13	E86486	Screw TE M8-45	1
14	E86861	Pin	1
15	SL07400	PIN	1
16	E86875	Self-Locking Nut	2
20	E86881	Washer	2
21	E86679	AS24 Squeegee Mount	1
22	SL07472	BEARING	2
23	E86672	Fork for AS24/28	1
24	SL06100	KNOB (o HANDWHEEL)	1
25	SL05081	NUT	2
26	SL09798	ARM	1
27	SL07253	BEARING	1
28	E86688	AS28 Bracket	1