




REF.	CODE	DESCRIPTION	QT
1	SL04074	SCREW	1
2	E86702	Cham Washer D8	1
3	E87862	Spacer WS20/24	1
4	E86451	AS20 Wheel	1
5	E86758	Washer	2
6	SL17285	CAP / SHELL	1
7	SL03499	RUBBER SHIM	2
8	E86607	Brush Motor	1
9	SL09613	PLATE	1
10	E86738	Nut M6 w/ Nylon Ring	1
11	E86427	Washer for AS20	2
12	E89485	Spacer	1
13	E89408	Stop Ring	2
14	E86666	AS28 Pin	1
15	E86667	Bearing, 6001 2RS	2
16	E86727	Neutral Pulley	1
17	E86665	AS28 Plate (Idler Bearing)	1
19	E87833	Screw WS20	1
20	E89220	Screw	2
21	E89183	Washer	4
22	E86879	Washer	6
23	E86555	spacer	2
24	E86631	Belt	1
25	E87768	Screw	1
26	E87757	Washer	1
27	E87756	Pulley	1
28	E86536	Key	1
29	E89182	Screw	2
30	E86853	Nyloc Hex Nut, M8 Zinc	2
31	E86881	Washer	2
32	SL13063	SPRING	1
33	E86683	AS24 Wheel Bushing	1
34	E86406	Wheel D 60	1
35	SL04067	SCREW	1
36	E86980	Washer PPL66 D13-24-2.5 Uni	2
37	E86975	Rubber Gasket D11.25 L=10	2
38	SL09629	BRACKET	2
39	SL19294	HOSE	1
40	SL18234	CONNECTOR	1
41	E86751	Clamp 10-16	3
42	SL19295	HOSE	1

