




| REF. | CODE    | DESCRIPTION            | QT |
|------|---------|------------------------|----|
| 1    | E89274  | Nut                    | 4  |
| 2    | E89275  | Washer                 | 4  |
| 3    | E86527  | Microswitch            | 2  |
| 4    | E86423  | Bipolar Switch         | 3  |
| 5    | E86837  | Potentiometer          | 2  |
| 6    | E86644  | Knob for Potentiometer | 1  |
| 7    | E86421  | Reflector              | 1  |
| 8    | SL06016 | WASHER                 | 2  |
| 9    | SL04148 | SCREW                  | 2  |
| 10   | SL04031 | SCREW                  | 2  |
| 11   | E86552  | nut                    | 4  |
| 12   | E86707  | Cham Washer D10        | 4  |
| 13   | E86597  | screw                  | 2  |
| 14   | E86823  | Micro Switch           | 1  |
| 15   | SL09616 | PLATE                  | 1  |
| 20   | SL13061 | SPRING                 | 1  |
| 21   | E89254  | Control lever AS28     | 2  |
| 22   | E86640  | Control Battery Light  | 1  |
| 23   | SL07224 | BUSHING / BUSH         | 1  |
| 24   | E86708  | Screw TE M 6-35        | 1  |
| 25   | SL23918 | WIRING                 | 1  |
| 26   | E86674  | AS28 Knob              | 2  |
| 27   | SL04001 | SCREW                  | 2  |
| 28   | E88091  | Washer                 | 4  |
| 29   | E86853  | Nyloc Hex Nut, M8 Zinc | 2  |
| 30   | E86988  | Operator D22           | 2  |
| 31   | E86988  | Operator D22           | 1  |
| 34   | E86700  | Cham Washer D6         | 1  |
| 35   | SL04182 | SCREW                  | 1  |

