

		CODE:		pl1041 aa SN from 96D673	
DESCRIPTION:	TANK-ACCESSORIES	TANK	RESERVOIR	TANQUE	SERB.: ACCESSORI
REF.	CODE	DESCRIPTION			QT
2	E86844	Gasket, Lid - Red			1
3	SL17363	LID			1
4	E89276	Screw			11
5	SL03275	SCREW			1
6	E86974	Sifter Room Cover			1
7	E89118	Washer			6
8	E89469	M4 - 15 Phil Pan Head Screw			6
9	E86806	Vacuum Filter			1
10	SL23464	FLASH-LIGHT (n.)			1
11	E86919	AS30/36 Bulb			1
12	E86750	Washer D5 UNI 6591 NOXA			3
13	E86902	AS30/36 Seat Anchorage Pla			1
14	E86901	AS30/36 Seat Back Screw			1
15	SL14191	SEAT BACK			1
20	SL14190	SEAT			1
21	SL03103	PLUG / STOPPER			4
22	E86707	Cham Washer D10			4
23	E86708	Screw TE M 6-35			6
24	SL05012	NUT			4
25a	SL23894	FUSE-HOLDERS			1
25b	SL23893	LID			1
26	SL09901	LID			1
27	SL20045	CATCH / LOCK			1
28	E86836	Fuse 100 amp			1
29	E86643	Fuse 75 amp			1
30a	E86825	Fuse 5 amp			4
30b	E86827	Fuse 25 amp			1
30c	E86826	Fuse 15 amp			1
31	SL07293	SPACER			2
32	E86704	Washer D 6-18			2
33	SL09540	PLATE			1
34	E86700	Cham Washer D6			1
35	SL04180	SCREW			2
40	E86704	Washer D 6-18			1
41	SL04196	SCREW			1
42	SL04252	SCREW			1
43	E86853	Nyloc Hex Nut, M8 Zinc			1
44	SL04223	SCREW			5
45	SL09694	PLATE			1
46	SL07337	SPACER			1
47	E86552	nut			1
48	SL14199	TERMINAL			2
49	E86835	Floating Switch			1
50	SL17395	REINFORCEMENT			1
51	SL17499	PANEL			1
52	SL11108	RING			2
53	SL06080	WASHER			2
54	SL07301	PIN			2
55	E86453	AS20 Bushing			2
60	SL07308	SUPPORT			1
61	E86726	Washer			1
62	SL04083	SCREW			1