




REF.	CODE	DESCRIPTION	QT
1	GR23478	CONTROL PANEL UNIT	1
2	GR23479	WIRING UNIT	1
3	SL04223	SCREW	10
4	E86423	Bipolar Switch	2
5	E86837	Potentiometer	1
6	E86644	Knob for Potentiometer	1
7	E86832	Switch for Move - Head	2
8	E86421	Reflector	1
8a	E86640	Control Battery Light	1
9a	E86840	Keyless Switch	1
9b	E86988	Operator	1
9c	E86988	Operator	2
	E86830	Horn Switch	1
	SL23461	PUSH-BUTTON	1
10	E88116	Push Button Horn	1
	E86909	AS30/36 Reverse Switch	1
	E86909	AS30/36 Reverse Switch	1
	E88116	Push Button Horn	1
11	E88116	Push Button Horn	1
	E88116	Push Button Horn	1
	E86909	AS30/36 Reverse Switch	1
12	E86935	Decal, Control Panel	1
13	SL09750	PLATE	1
14a	E86947	Handle Plug, Anderson	1
14b	E86946	Anderson Plug, 160 AC	1
15	SL09917	PLATE	1
16	SL09526	SUPPORT	3
17	SL14230	TERMINAL	1

