




REF.	CODE	DESCRIPTION	QT
1	SL04180	SCREW	1
2	E86758	Washer	1
3	SL06092	WASHER	1
4	E86706	Screw TE M 6-16	1
5	E89202	Washer	1
6	E89403	Bushing	2
7	E86354	Screw AS36	2
8	E86363	spring AS36/WS36	1
9	E86847	Clip	1
10	E89442	Bearing	2
11	SL04312	SCREW	1
12	E88091	Washer	2
13	SL13065	SPRING	2
14	SL09537	HOOKING	1
15	E86489	Nut, M12	1
16	E86852	Squeegee Knob	2
20	E86490	AS20 Washer	2
21	E86853	Nyloc Nut, M8 Zinc	4
22	E86726	Washer	6
23	E86845	Bracket, Squeegee	1
24	E86846	Lever, Squeegee	1
25	E86462	AS20 Nut	1
26	E86739	AS28 Nut	2
27	E86797	Washer	2
28	SL14150	CLAMP	1
29	E86828	Microswitch	1
30	E86353	Screw AS36	1
31	E86872	Screw	1
32	E86319	shaft WS20	1
33	E86486	Screw TE M8-45	1
34	E89204	Pin WS36	1
35	E89495	Spring	1
40	SL14006	TEAR RIVET	2
41	E86847	Clip	1
42	SL06018	WASHER	1
43	E86703	Nut M8	1
44	E86917	AS30/36 Fork	1
45	E89205	Lever WS36	1
46	E86450	Tank Support Handle	1
47	E86336	M4 - 1 Screw	1
48	SL09742	SUPPORT	1
49	SL04107	SCREW	2
50	SL09737	SUPPORT	1
55	SL14222	REGISTER	1
56	SL23050	FAIRLEAD	1

