

Betco Foreman 28/32 Traction Diagnostic

- 1 Flashes: traction motor not stopped during
 Turning on of the key switch
- 2 Flashes: traction motor not stopped during turning
 Off of the key switch.
- 3 Flashes: battery voltage too low.
- 4 Flashes: battery voltage too high.
- 5 Flashes: traction potentiometer not at zero during
 Turning on of the key switch (example:
 Traction lever pushed during turning on
 Of the key)
- 6 Flashes: potentiometer wires disconnected.
- 7 Flashes: overheating of the card.