


Chassis B



REF.	CODE	DESCRIPTION	QT
1	E87863	Screw WS20/24	1
2	E87862	Spacer WS20/24	1
3	E86451	AS20 Wheel	1
4	E86879	Washer	4
5	E86876	Nut	6
6	E87898	support WS20/24	1
7	E86853	Nyloc Hex Nut, M8 Zinc	3
8	E87917	Screw	1
9	E86700	Cham Washer D6	1
10	SL09892	Small Square	1
11	E86453	AS20 Bushing	1
12	E89260	Axle bushing WS20	1
13	E86565	washer	2
14	E89199	Key 5-5-15	1
15	SL09895	Bracket	1
16	E89262	Axle bushing WS20	1
17	E86780	Shaft	1
18	E87807	Foot Petal pad WS20/24	1
20	E86509	Wheel, Rubber 7 3/4" x 1	2
21	E86540	AS20 Screw M8x10	2
22	E86563	support	1
23	E86702	Cham Washer D8	5
25	E86797	Washer	2
26	E86420	Relay	1
30	E89230	Spacer	1
31	E86408	Rotating Wheel	1
32	SL39021	Bracket	1
33	E89200	Spring WS20	1
34	E87810	Foot Petal WS20	1
35	E89160	Lever WS20	1
36	SL39135	Lever	1
37	E87868	Self Locking Nut	2
38	E86737	Screw	2
39	E86427	Washer for AS20	2
40	E86490	AS20 Washer	2
41	E86520	Brush Cover	1
42	E86366	screw WS20	2
43	E89467	Bumper	1
44	E86875	Self-Locking Nut	2
45	E86336	M4 - 10 Pan Head	4