


CONTROL PANEL WITH SPEED CONTROL



ITEM	SKU	DESCRIPTION	QTY
	E86776	Control panel complete	1
1	SL09908	CABLE	1
2	SL04187	SCREW	6
3	SL23733-1	WIRING	1
4	SL23695	FAIRLEAD	1
5	E86519	Lever	1
6	E89474	Solution Rod ADJ	1
7	SL04240	SCREW	6
8	E86448	AS20 Washer	2
9	E86798	Lower control panel WS20	1
10	E89468	Fuse Carrier	1
11	E89342	Fuse 30 Amp	6
12	E86647	Fuse 40A	2
13	E87830	Nut	2
14	E87876	Gasket WS20/24 FS28/32	2
15	E86543	Fuse Cover for AS20	1
16	E87877	Screw WS20/24 FS28/32	2
20	SL23209	FUSE TWEEZERS	1
21	SL55061	LABEL	1
22	E89234	Traction card WS24	1
23	SL23221	CONNECTOR	1
24	E86988	Main Key Switch	1
25	E86988	Main Key Switch	1
26	E86988	Main Key Switch	2
27	E89153	Potentiometer	1
28	E86496	Circuit Board	1
29	E87923	Handle	1
30	E86750	Washer D5	6
31	SL06094	WASHER	2
32	E86749	Nut M5 UNI 5588	2
33	SL03607	SUPPORT	1
34	SL04244	SCREW	1
35	E89530	Spring WS20/24	1
36	E89154	Screw	2
37	E89087	Microswitch	1
38	E89471	Vac Motor Relay	1
39	E86797	Washer	1
40	E89529	Relay Support WS20/24	1
41	E89223	Resistor	1
45	E86997	Upper Control Panel WS20/24	1
46	SL55039	LABEL	1
47	E86644	Knob for Potentiometer	1
48	E86421	Reflector	1
49	E89255	Brush rocker switch WS24	1
50	E86423	Bipolar Switch	1