




ITEM	SKU	DESCRIPTION
AP1	E86528	Gearcase Board
FU1	E86825	Fuse 5 amp
FU2	E89342	Fuse 30 Amp
FU3	E89342	Fuse 30 Amp
FU5	E86825	Fuse 5 amp
FU6	E89342	Fuse 30 Amp
FU7	E87883	60 AMP Fuse
GB1	E11767	BATERÍA
HL	E86496	Circuit Board
KM1	E86420	Relay
KM2	E89471	Vac Motor Relay
M1	E86608	Brush Motor
M2	E89478	Vac. Motor
M3	E89459	Drive Motor Shaft

ITEM	SKU	DESCRIPTION
QM1	INTERNAL	THERMAL PROTECTION
QM3	INTERNAL	THERMAL PROTECTION
R1	E89223	Resistor
R2	SL23899	RESISTANCE
S1	E86527	Microswitch
S2	E86527	Microswitch
SB	INTERNAL	PUSH-BUTTON
SH1	E86423	Bipolar Switch
SH2	E86423	Bipolar Switch
VD1	E87965	Diode, 5 OHM
XC1	E86563	support
XC2	SL23414	CLAMP
XC3	SL23414	CLAMP