




REF.	CODE	DESCRIPTION	QT
1	E86597	screw	12
2	E86903	Screw M.4-16	8
3	SL14184	SPACER	12
4	E87901	Board	1
5	SL06009	WASHER	12
6	E89274	Nut	12
7	E86834	Auxiliary Card	1
8	E86838	Traction Card	1
9	E86739	AS28 Nut	8
10	GR23479-2	WIRING UNIT	2
11	SL23039	BOARD	1
12a	E89468	Fuse Carrier	2
12b	SL23893-2	LID	2
13	E86825	Fuse 5 amp	1
14	E86825	Fuse 5 amp	1
15	E86825	Fuse 5 amp	1
16	E86825	Fuse 5 amp	1
17	E86827	Fuse 25 amp	1
18	E86826	Fuse 15 amp	1
19	E86825	Fuse 5 amp	1

