

PARTS LIST LOWER UNIT DM1400

ITEM	SKU	Description
2	E82095	DM1400/1800 screw
16	0000160	Strain Relief N/A
20	2000245	Block,Terminal
52	E82101	Cable Restrain
67	E82097	DM1400/1800 screw
69	E82161	DM1400/1800 locking pedal
70	E82162	DM1400/1800 shaft pedal
73	E82168	DM1400/1800 decal
73	1200731	Decal. LED German N/A
78	E82163	Sscrew short left side
79	1100790	Screw, LH
83	E82169	DM1400/1800 LED cover
89	E82233	DM1400 brush cover
90	E82106	DM1400/1800 washer
96	E82172	DM1400/1800 latch break
98	E82173	Bearing bushing long
99	E82199	DM1400/1800 switch
100	E82174	Bearing bushing short
101	1301010	Gasket
102	E82178	DM1400/1800 swivel neck
103	E82164	knob
104	E82179	Shaft fixing plate
105	E82243	Plate, Guide
106	E82202	DM1400/1800 brush driver
107	E82203	DM1400/1800 roller support
108	1701088	Bearing, Brush
116	E82175	Brush strip cover
117	E82211	DM1400 brush strip
119	E82247	Roller brush complete

ITEM	SKU	Description
122	E82213	Roller support
123	E85889	Cogged Drive
124	E86077	Drive Belt
125	1601250	Ring. Rubber
126	1601260	Foam, Brush Motor
127	E82179	Shaft fixing plate
128	E85880	Brush motor 110v
128	1601281	Motor, 220-240V N/A
130	E82201	Control, 220V N/A
130	1601304	Control, 220V N/A
130	E82201	Circuit board
133	E82227	Pigtail cord
133	1601339	Plug, 2 Pole N/A
136	E82183	Rear wheel
137	E82185	Rear caster shaft
138	E82186	Front wheel
139	E82187	Spring
141	E82245	Adjustment Knob
142	E82096	DM1400/1800 screw
143	E82236	Brush housing bottom
144	E82177	DM1400 Bumper
145	E82188	Brush protector
150	E82166	Spring
155	E88508	Screw, M3 x 16 Zinc
166	1601660	Thermal Overload
753	E82167	Bracket, Swivel
1401	E82195	Front Castor Shaft
146	E82191	Brush protector