

**PARTS LIST LOWER UNIT DM1800**

| ITEM | SKU     | Description               |
|------|---------|---------------------------|
| 2    | E82095  | DM1400/1800 screw         |
| 4    | E82234  | Brush housing upper       |
| 16   | 0000160 | Strain Relief N/A         |
| 18   | E82176  | DM1800 Bumper             |
| 20   | 2000245 | Block,Terminal            |
| 26   | E82210  | DM1800 brush strip        |
| 31   | E82248  | Roller brush complete     |
| 32   | E82197  | Front Caster Shaft        |
| 37   | E88086  | Shaft DM1800              |
| 38   | E82191  | Brush Protector           |
| 52   | E82101  | Cable Restrain            |
| 58   | E82189  | Brush Housing, Lower      |
| 67   | E82097  | DM1400/1800 screw         |
| 69   | E82161  | DM1400/1800 locking pedal |
| 70   | E82162  | DM1400/1800 shaft pedal   |
| 73   | E82168  | DM1400/1800 decal         |
| 73   | 1200731 | Decal. LED German N/A     |
| 78   | E82163  | Screw short left side     |
| 79   | 1100790 | Screw, LH                 |
| 83   | E82169  | DM1400/1800 LED cover     |
| 89   | E82233  | DM1400 brush cover        |
| 90   | E82106  | DM1400/1800 washer        |
| 96   | E82172  | DM1400/1800 latch break   |
| 98   | E82173  | Bearing bushing long      |
| 99   | E82199  | DM1400/1800 switch        |
| 100  | E82174  | Bearing bushing short     |
| 101  | 1301010 | Gasket                    |
| 102  | E82178  | DM1400/1800 swivel neck   |
| 103  | E82164  | knob                      |
| 104  | E82179  | Shaft fixing plate        |

| ITEM | SKU     | Description                |
|------|---------|----------------------------|
| 105  | E82243  | Plate, Guide               |
| 106  | E82202  | DM1400/1800 brush driver   |
| 107  | E82203  | DM1400/1800 roller support |
| 108  | 1701088 | Bearing, Brush             |
| 116  | E82175  | Brush strip cover          |
| 122  | E82213  | Roller support             |
| 123  | E85889  | Cogged Drive               |
| 124  | E86077  | Drive Belt                 |
| 125  | 1601250 | Ring. Rubber               |
| 126  | 1601260 | Foam, Brush Motor          |
| 127  | E82179  | Shaft fixing plate         |
| 128  | E85880  | Brush motor 110v           |
| 128  | 1601281 | Motor, 220-240V N/A        |
| 130  | E82201  | Control, 220V N/A          |
| 130  | 1601304 | Control, 220V N/A          |
| 130  | E82201  | Circuit board              |
| 133  | E82227  | Pigtail cord               |
| 133  | 1601339 | Plug, 2 Pole N/A           |
| 136  | E82183  | Rear wheel                 |
| 137  | E82185  | Rear caster shaft          |
| 138  | E82186  | Front wheel                |
| 139  | E82187  | Spring                     |
| 141  | E82245  | Adjustment Knob            |
| 142  | E82096  | DM1400/1800 screw          |
| 150  | E82166  | Spring                     |
| 155  | E88508  | Screw, M3 x 16 Zinc        |
| 166  | 1601660 | Thermal Overload           |
| 753  | E82167  | Bracket, Swivel            |
| 146  | E82191  | Brush protector            |