


3 INTAKE,EXHAUST GROUP



REF.	PART NUMBER	PART NAME	CODE NO.	QTY	REMARKS	INTERCHANGE
10	263-31801-13	CAM SHAFT CP	-	1		
50	263-33301-A3	TAPPET	-	4	27DX9DX48L	
60	246-33611-03	VALVE SPRING	-	4	22. 2DX2. 9DX37L N=6. 5	
70	246-33711-13	SPRING RETAINER	-	4	7. 6DX26DX8T	
80	263-33401-03	INTAKE VALVE	-	2	35DX6DX79. 8L	263-33401-H3
90	263-33502-13	EXHAUST VALVE	-	2	31DX6DX80. 3L	263-33502-H3
95	246-35501-03	COLLET-VALVE	-	8		
210	263-35322-A1	PUSH ROD CP	-	4		263-35331-01
220	267-36102-03	ROCKER ARM	-	4		
230	263-35801-03	BOLT(PIVOT)	-	4		
235	267-35701-03	PIVOT	-	4		
240	X17-00601-10	NUT	-	4	M6X0. 75X3. 6H	017-00601-10
260	263-37002-A3	GUIDE PLATE	-	2		
340	270-35201-01	GASKET CP (MUFFLER)	-	2	T=0. 4 30D 8. 5DX52P	
350	002-38080-00	FLANGE NUT	-	4	M8X1. 25X17DX7. 5H	
500	263-33051-H1	INTAKE MANIFOLD CP	-	1		
505	X10-50602-70	STUD	-	2		
512	263-32622-A1	CLEANER BASE CP	-	1		
514	263-32630-03	CLEANER COVER	-	1		
516	263-32640-01	WING NUT	-	1		
520	263-32610-A1	CLEANER ELEMENT CP	-	1		
530	263-35502-A3	GASKET,CLEANER	-	2	T=0. 4	
535	263-38001-A3	SPACER	-	1	T=3. 1	
540	263-35401-A3	INSULATOR	-	1	T=7 29D 6. 5DX58P	
550	263-35501-A3	GASKET,INSULATOR	-	2	T=0. 4 29D 6. 5DX58P	
555	263-35503-A3	GASKET(IN MANIFOLD)	-	2	T=0. 4 31D 8. 5DX52P	263-35513-03
570	002-38060-00	FLANGE NUT	-	2	M6X1. 0X13DX6H	
590	002-38080-00	FLANGE NUT	-	4	M8X1. 25X17DX7. 5H	
621	263-35505-A1	BRIDGE,CLEANER	-	1		
625	263-35506-A3	RETAINER,AIR CLEANER	-	1		

REF.	PART NUMBER	PART NAME	CODE NO.	QTY	REMARKS	INTERCHANGE
910	263-91752-A3	LABEL(TRADE MARK)	-	1		