


6 FUEL LUBRICANT GROUP

FIG. 602



REF.	PART NUMBER	PART NAME	CODE NO.	QTY	REMARKS	INTERCHANGE
80	X85-10617-21	RUBBER PIPE	-	1	6. 4DX12. 7DX320L	
90	263-68501-03	HOSE CLAMP	-	4	11. 4DX7. 9BX0. 7T	
270	263-63611-01	OIL GAUGE CP	-	1		
272	263-65101-A2	OIL FILLER	-	1		
277	024-01900-00	O RING	-	1		
280	021-31800-10	GASKET	-	1		
510	267-62201-10	FUEL PUMP AY	-	1		
515	263-67101-A2	BRACKET,F,PUMP	-	1		
522	X85-10617-21	RUBBER PIPE	-	1	6. 4DX12. 7DX320L	
540	X11-00600-20	FLANGE BOLT	-	2	M6X1. 0X14DX12L	011-00600-20
542	X11-00600-30	FLANGE BOLT	-	1	M6X1. 0X14DX14L	011-00600-30
543	X11-00600-90	FLANGE BOLT	-	1	M6X1. 0X13DX32L	011-00600-90
610	263-63921-A3	INNER ROTER	-	1		
615	263-63931-A3	OUTER ROTER	-	1		
617	263-63941-A3	SHAFT,OIL PUMP	-	1		
620	263-64011-A3	OIL PUMP COVER	-	1		
625	263-64411-A3	O RING	-	1		
640	X11-00600-20	FLANGE BOLT	-	4	M6X1. 0X14DX12L	011-00600-20
653	X11-00601-40	FLANGE BOLT	-	1	M6X1. 0X14DX18L	011-00601-40
660	248-65801-00	OIL FILTER AY	-	1		248-65801-10
700	263-76101-H1	SWITCH(OIL PRESSURE)	-	1		