



Instructions for PE50061

If your machine has a Blue Anderson Connector Install accessory Pigtail Adaptor to the Red Battery Connector




If your machine has a Red Anderson Connector Install Pigtail Adaptor to the Blue Charger Connector



Instructions for PE50061

If your machine has a Blue Anderson Connector Install accessory Pigtail Adaptor to the Red Battery Connector



If your machine has a Red Anderson Connector Install Pigtail Adaptor to the Blue Charger Connector

