

WATER SUPPLY AND SPW SYSTEM MAINTENANCE

SINGLE POINT WATERING SYSTEMS

1. Inspect all cells for correct filling level monthly for the first three months after the kit is installed. This is made easier with our Cell Inspection Plugs (P/N BD-107).
2. Inspect all cells quarterly thereafter.

HOSE SYSTEMS

1. Clean the filter washer, located at the inlet of the pressure regulator, quarterly.

DEIONIZED WATER SUPPLY (Deionizer)

1. Clean the filter washer, located at the inlet of the pressure regulator, quarterly.
2. Replace the deionizer's cartridge when the quality light changes from green to red.

PORTABLE WATER CARTS (AC & DC)

1. Clean the suction filter located inside the water tank quarterly. There is also a filter just upstream of the Hose End Assembly (regulator).
2. Charge DC Cart battery on a regular schedule. For example, plug charger in overnight, once per week, or more often if voltage drops below 12 volts while filling.