

Watering System Operation

Please see additional instructions in separate
Pro-Fill On-Board Battery Watering System manual

Millennium SPW™ REGULATED HOSE SYSTEM (P/N BA-MS-320-20) (Does not Include Flow-Rite Deionizer)

- A. Connect the hose to a dedicated hose bibb.
- B. After installing, purge the air out of the hose. Purging is necessary after the Millennium SPW™ system is installed and each time that the system is disconnected and reconnected to the hose bibb. See included [Purge Procedure instructions](#).

PURGING IS REQUIRED BEFORE FIRST USE, OR IF HOSE ASSEMBLY HAS BEEN REINSTALLED SINCE LAST USE.

- C. Refill batteries after they have been charged. One watering per week is usually enough. Firmly mate the quick coupler. When the connection is made the red balls in the Flow Indicator will start rotating indicating water is flowing into the battery cells.
- D. After the Flow Indicator balls stop rotating, immediately disconnect by pushing the CPC button in and pulling the male Quick Coupler out.
- E. Put the dust cover back on the battery's male Quick Coupler.
- F. Store hose out of traffic area when not in use.

