

Citymaster 650 1470.15
12.0.5 Disassembly hydraulic tank

Hako

Remove the cladding at the back left.




Citymaster 650 1470.15

12.0.5 Disassembly hydraulic tank



Empty the hydraulic tank completely.
Remove the green parts.



Citymaster 650 1470.15
12.0.5 Disassembly hydraulic tank



Remove the green mounting screws of the hydraulic tank.

