

Description: TURBOCHARGER

 Last variation:  
 17/09/2014 15:56:18

**Elenco Articoli**


Pos	Description	Part Number	Qty	Pos	Description	Part Number	Qty
001	FLANGED NUT M8	41880208F	8	031	SCREW	41901204F	2
002	STUD	41750910F	6				
003	GASKET	22022181F	1				
004	NUT	21792027F	3				
005	FLANGED NUT M8	46210130F	8				
006	EXHAUST TURBO FLANGE	21082028F	1				
007	GASKET - TURBO OUTLET	22022104F	1				
008	STUD	41752008F	3				
009	EXHAUST TURBO FLANGE	20732101F	1				
010	GASKET TURBO HR	22022027A	1				
011	STUD M8X20	41750906F	4				
012	EXHAUST MANIFOLD ASSY	11052063F	1				
013	EXHAUST MANIFOLD HEAT	22082234F	1				
014	WASHER	46230038A	2				
015	SCREW	41762007A	2				
016	NUT	41880308F	8				
017	GASKET EXHAUST MANIFOLD	22032114F	4				
018	INTAKE MANIFOLD GASKET	22022198F	4				
019	INTAKE MANIFOLD	21042114F	1				
020	PIPE	21303023F	1				
021	GASKET	42020010A	2				
022	MAIN BEARING OIL FEED TURBO	21322022F	1				
023	TURBOCHARGER	35242133H	1				
024	GASKET	22032141G	1				
025	SCREW	41901206F	1				
026	PIPE	21302909F	1				
027	UNION	21782045A	1				
028	INOX WASHER GASKET	22022281F	2				
029	UNION SCREW	41320132F	1				
030	P3 SENSOR PIPE	21283100F	1				











Description: FUEL INJECTION CIRCUIT

Last variation:  
20/02/2014 16:53:36

Elenco Articoli

Pos	Description	Part Number	Qty	Pos	Description	Part Number	Qty
001	VALVE	45022054F	1	032	SCREW	41901206F	1
002	NUT	41880308F	5	033	RAIL SUPPORT BRACKET	20513177F	1
003	SCREW ASSY	11762002F	1	034	FIXING FUEL REFUSE BLOCK	21632282F	1
004	OR	46320548A	1	035	SPACER	21632321F	1
005	INJECTION PUMP GEAR ASSY	10662019G	1	036	RAIL PRESSURE SENSOR	45962079F	1
006	STUD	41753006F	3	037	RAIL	35022107G	1
007	INJECTION PUMP GASKET	22032299F	1	038	SCREW	41901305F	1
008	NUT	41880415F	1	039	STUD	41753010F	2
009	INJECTION PUMP GEAR	20662180F	1				
010	INJECTION PUMP KIT	15022280F	1				
011	GASKET	42020012A	4				
012	UNION	41320112F	2				
013	SLEEVE FUEL WASTE FROM INJECTION PUMP	21332036F	1				
014	WIF SENSOR	45962100F	1				
015	FUEL FILTER ELEMENT	45312014F	1				
016	FUEL FILTER ASSEMBLY	35312036F	1				
017	SCREW	41762540F	4				
018	SPHERICAL WASHER	21812036F	4				
019	INJECTOR FIXING CLAMP	21362025F	4				
020	INJECTOR GASKET	45062027F	4				
021	O RING	46320267F	4				
022	INJECTOR SPRING REF.F00VC22003 BOSCH	45062028F	4				
023	INJECTOR	35062013F	4				
025	PIPE	31302040F	1				
026	FUEL INJECTION PIPE SET	11262008F	1				
027	CLAMP WITH RUBBER APA	41612156F	1				
028	SCREW	41901203F	1				
029	FUEL RETURN BODY ASSY	20112156F	1				
030	SPRINGBAND CLAMP	41612101F	2				
031	FUEL REFUSE PIPE	21302828F	1				
















Description: FRONT EGR SYSTEM Last variation: 07/03/2014 16:06:03

Elenco Articoli

Pos	Description	Part Number	Qty	Pos	Description	Part Number	Qty
001	SCREW	41762025F	6	031	GASKET FOR EGR VALVE COOLER	22022123F	2
002	EGR COOLER	41212103G	1	032	EGR COOLER SUPPORT BRACKET	20513357F	1
003	CLAMP	41612113F	4				
004	PIPE	21303019F	1				
005	EGR COOLER GASKET	22022238F	1				
006	PIPE	21303018F	1				
007	UNION	21782266G	2				
008	GASKET	22020012A	2				
009	EGR SUPPORT ASSY	10512089F	1				
010	EGR COOLER SUPPORT BRACKET	20513356F	1				
011	SCREW	41901307F	4				
012	SCREW	41901306F	3				
013	GASKET	22022277F	1				
014	EGR GASKET	42022016F	1				
015	EGR VALVE	49002029F	1				
016	SCREW	41901207F	2				
017	PIPE	21283036F	1				
018	CLAMP	41612154F	2				
019	EGR GASKET	22022172F	2				
020	BANJO BOLT	21320025A	1				
021	GASKET	42020008A	2				
022	BANJO-AIR BLEED	21332001A	1				
023	INTAKE THROTTLE GASKET	22032286F	1				
024	AIR INTAKE MANIFOLD	21092322F	1				
025	O RING	46320277F	1				
026	INTAKE TROTTLER	39002017G	1				
027	SCREW	41901212F	6				
028	SCREW	21902012F	2				
029	PIPE	21283035F	1				
030	FLANGED NUT M8	41880208F	2				







