



PowerBoss®

Parts

THE ENGINE GROUP (GASOLINE)



Mike



Need gasket

3610080

*(This diagram represents a
Toyota 4P engine.)*

PowerBoss®

Parts

SW/9XT		ENGINE GROUP (Toyota)		
REF #	PART NUMBER	SUB PARTS	DESCRIPTION	NUMBER REQUIRED
	307015	Sub	ASSY - PWR TRN SUB TYA ARMA GAS	1
1	contains >	303989	ENGINE - TOYOTA 4P 4 CYL	1
2		303381	PUMP - MAIN V/D T6 <i>3302841</i>	1
3		3032007	PUMP - AUXW/ENG DRCKS/LP <i>30718126</i>	1
4		303320	COUPLING - PUMP DRIVE TOYOTA MS	1
5		301995	RADIATOR - HEAVY DUTY	1
6		300420	CAP - RADIATOR	1
	Sub	307011	ASSY - AIR CLNR SUB TYA ARMA	1
	contains >	300459	BAND - MTG AIR CLEANER PNTD BLACK	2
7		303031	AIR CLEANER - HEAVY DUTY	1
	Replacement Parts	302842	ELEMENT - DONALDSON AIR CLEANER	1
		302597	FILTER - SAFETY ELEMENT	1
		303991	INDICATOR - AIR CLEANER KIT	1
21		307180	MOUNT - AIR CLNR TYA PNTD SW/A	1
		400036	SCREW - HHM 5/16-18 X .75 LG ZP	3
		400384	WASHER - CONICAL SPRING 5/16	3
	400390	NUT - FLANGE LOCK 5/16-18	3	
8	Sub	307012	ASSY - HOSE CABD ARMA SUB	1
	contains >	300336	CLAMP - HOSE 2 1/2 NOM S5	1
		300396	ADAPTER - 90 EL RUBBER H-DUTY AC	1
		303223	TUBE - AIR CLNR INTAKE SHORT PNTD	1
		303365	ADAPTER - 90 EL RUBBER 3.5 X 2.5	1
9		O44112	CLAMP - HOSE 2.50 MAX WORM	6
10		300387	SENDER - OIL PRESSURE	1
11		305853	SENDER - TEMP TYA	1
12		305303	PLATE - PUMP MTG MS PNTD TOYOTA	1
13		300464	MOUNT - ISOLATION	4
14		300465	MOUNT - ISOLATION (RADIATOR)	1
15		400091	WASHER - FENDER 1/2 ZP	4
19		307177	MNT - ENG FLYWHEEL OUT TYA PNTD	1
20		307179	MNT - ENG OUTER TYA PNTD SW/A	1
22		307176	MNT LH - RADIATOR SW/A PNTD	1
23		307175	MNT RH - RADIATOR SW/A PNTD	1
24		307356	ASSY - ENG PAN TYA SW/A PNTD	1
25		400191	FIN - ROLL 5/16 DIA X 1.0	2