

Ref. N°	Part. N°	Description	Briggs & Stratton Qty	Electric Qty
1	1000338	Chassis	1	1
2	1000872	Hood Panel RH	-	1
2	1000871	Hood Panel RH	1	-
3	1000874	Hood Panel LH	-	1
3	1000873	Hood Panel LH	1	-
4	1000645	Upper Hood	1	1
5	1000646	Front Hood Panel	1	1
6	1000877	Front Hood	1	1
7	1001425	Hood Support	1	1
8	1000251	RH Support	1	1
9	1000252	LH Support	1	1
10	1000250	Support Plate	1	1
11	1000089	Plate	1	1
12	1000228	RH Lower Panel	1	1
13	1000227	LH Lower Panel	1	1
14	1001391	Safety Key	1	1
15	1001010	Wire Rope	1	1
16	1000103	Plate - Safety Key	1	1
17	1000724	Spacer - Safety Key	1	1
18	1000259	Hood Rod	1	1
19	1000957	Spring	1	1
20	1001763	Flashing Light Housing	R	R
21	1001764	Multi Voltage Flashing Light	1	1
22	1001341	Flashing Light Kit	R	R
23	1000254	Supporting Rod	1	1
24	1000703	Rubber Ring	9	9
25	1000469	Lock Pin	9	9
26	1001029	Driver's Seat	1	1
27	1000884	Decal	1	1
28	1000881	Adhesive Strip	1	1
29	1000904	Adhesive Strip	1	1
31	1000885	Decal - Flap	1	1
32	1000886	Decal - Main Broom	1	1
33	1000721	Adhesive Strip	2	2
34	1000723	Carpet	1	1
35	1001170	Bulb Xenon	R	R