



Ref. N°	Part. N°	Description	Briggs & Stratton Qty	Electric Qty
1	1000339	Pivot	1	1
2	1000461	Bushing	2	2
3	1000561	Satellite gearing	2	2
4	1000562	Planetary gearing	2	2
5	1000787	Bearing	2	2
6	1000519	Gear housing, left	2	2
7	1000875	Differential gear	1	1
8	1000563	Rh shaft	1	1
9	1001009	Thread	1	1
10	1001005	Sheath	1	1
11	1001006	Sheath	1	1
12	1001004	Clamp	2	2
13	1000966	Spring	2	2
14	1000808	Support	2	2
15	1000564	Lh shaft	1	1
16	1000348	Flange	1	1
17	1000347	Flange	1	1
18	1001052	Clamps	2	2
19	1000496	Flange	2	2
20	1000488	Wheel rim	2	2
21	1001343	Rubber ring	2	2
22	1000575	Free wheel hub	2	2
23	1001186	Nut	2	2
24	1001225	Key	2	2
25	1000520	Axle shaft	2	2
26	1001216	Ring	4	4
27	1000801	Bearing	2	2
29	1000979	Parking brake lock	1	1
30	1001178	Screw	1	1
31	1000678	Pedal-cover	1	1
32	1000765	Rubber	1	1
33	1000088	Support	1	1
34	1000346	Brake pedal	1	1
35	1000087	Pedal locking	1	1
36	1000468	Spacer	1	1
37	1000086	Cylinder	1	1
38	1000233	Cable tensioner	1	1
39	1000604	Pulley	1	1