



Ref. N°	Part. N°	Description	Briggs & Stratton Qty	Electric Qty
1	1001760	Push button	2	-
2	1001761	Couple of keys	1	-
3	1000971	Handle up to serial n° 3294	1	-
4	1001429	Instruments panel from serial n° 2174	1	-
5	1001430	Adhesive from serial n° 2174	1	-
6	1000766	Plate	1	-
7	1001762	Switch without key	1	-
8	1001146	Electromagnetic switch	1	-
9	1001149	Microswitch	1	-
10	1000090	Support	1	-
11	1000722	Sponge	2	-
12	1000781	Vacuum hose tube	1	-
13	1000187	Batteries case	1	-
14	1001080	Battery	1	-
15	1001087	Battery wiring +	1	-
16	1001088	Battery wiring -	1	-
17	1000696	Rubber ring	1	-
18	1001613	Clamp cover	1	-
19	1000230	Support	1	-
21	1000665	Rubber plug	1	-
22	1001113	Clamp	1	-
24	1000390	Nipples	1	-
25	1001016	Clamp	1	-
26	1000768	Oil drain	1	-
27	1000934	Washer	1	-
28	1000096	Plate	1	-
29	1000937	Silencer	1	-
30	1000092	Plate	1	-
31	1000235	Air conveyor	1	-
32	1000371	Air conveyor	1	-
33	1001097	Horn 12v	1	-
34	1000870	Centrifugal pulley	1	-
35	1000464	Washer	1	-
36	1000832	Belt	1	-
37	1000831	Belt	1	-
38	1000463	Spacer	1	-
39	1001117	Fuse-box	1	-
40	1001092	Fuse	1	-
41	1001409	1150 B&S 5Hp engine Up to serial n° 3294	1	-
42	1001431	Catalytic silencer Up to serial n° 3294	R	-
43	1001408	Sheathing support From serial n° 2174 Up to serial n° 3294	1	-
44	1001411	Sheath locking From serial n° 2174 Up to serial n° 3294	1	-
45	1001407	Start knob From serial n° 2174 Up to serial n° 3294	1	-
46	1001443	Adhesive	1	-
47	1000266	Protection	1	-