



DOLLIES

ITEM NUMBER	PART NUMBER	DESCRIPTION
1	301321	Caster - Swivel 4.00 Diameter
2	302012 302011	Assembly - Hopper Dolly Grp HD Assembly Hopper Dolly HD Pntd
3	301701 301314	Assembly - Hopper Dolly Grp LD Assembly - Hopper Dolly LD Pntd



LOW DUMP HOPPER SHUTOFF


ITEM NUMBER	PART NUMBER	DESCRIPTION
1	300050	Assembly - Gasket Mount Pntd
2	301418	Rod - Hopper Shutoff Pltd
3	301498	Damper - Hopper Shutoff
4	300563	Knob
5	301713	Spring - Extension Damper
6	300414	Bushing - Plastic
7	300193	Gasket - Hopper Air Outlet



STEERING


ITEM NUMBER	PART NUMBER		DESCRIPTION
	Series 88	Series 78*	
1	300208	300296	Assembly - Steering Fork
2	301533	301534	Motor - Hydraulic
3	300153		Assembly - Fork Pivot
4	300472		Bearing Thrust
5	301440		Spacer Main Broom
6	400188		Nut - Hex Jam Half 1/2 - 20
7	301013		Assembly - Steering Link
8	300215		Arm - Steering
9	400223		Nut - Hex Slotted 1/2 - 20 SP
10	300374		Assembly - Steering Gear
11	300228		Bracket Steering
12	300373		Cap - Steering Wheel
13	300372		Wheel - Steering
14	400205		Fitting - Grease 65 el 1/4 NPT
15	300415		Stud - Wheel Hub
16	301014	301018	Hub - Rear Wheel
17	300211		Rim - Inner
18	300408		Rim - Outer
19	300411		Nut - Wheel Lug
20	400224	400223	Nut - Hex Slotted 1 1/4 - 18 x .62
21	301525 301526		Assembly - Tire (Solid) Assembly - Tire (Pneumatic)
22	300470		Bearing - Tapered Roller Cup
23	300471		Bearing - Tapered Roller Cone
24	400083		Jam Nut - Lock Half Height 1 1/4 - 12
25	302122		Key Hydraulic Motor - 4000 Series

*When no numbers appear in this column, the parts number for the 78 Series is the same as that for the 88 Series.



AXLE, BRAKES AND WHEEL

ITEM NUMBER	PART NUMBER		DESCRIPTION
	Series 88	Series 78*	
1	300852		Assembly - Front Axle
2	300523		Shoe - Brake with Lining
3	300787		Hub - Front Wheel
4	300211		Rim - Front Wheel
5	300467		Bearing - Ball 2.44 x 1.18 ID
6	300473		Ring - Retainer Internal
7	300369		Cap - Hub
8	300415		Stud - Wheel Hub
9	301519		Spring Extension Brake Shoe
10	300408		Rim Outer
11	300411		Nut - Wheel Lug
12	300410		Bushing - 1.00 OD x .87 ID
13	301518		Spring - Compression Brake Shoe
14	300484		Ring - Retainer Extension .87
15	301517		Spring - Extension Brake Lever
16	300870		Assembly - Brake Lever
17	300203		Bar - Cable
18	400118		Pin - Clevis 5/16 x .88
19	400185		Pin - Clevis 5/16 x 1.25
20	300202		Bar - Cable Adjustment
21	300412	300486	Cable Brake
22	300367		Pulley - Brake
23	300035		Spacer - Brake Pulley
24	300209		Retainer - Cable
25	300955		Bracket - Brake Pulley
26	300462		Clevis - Cablecraft AC-218
27	300132		Assembly - Brake Arm
28	400115		Pin - Clevis 3/8 x 3.00



AXLE, BRAKES AND WHEEL (cont.)

ITEM NUMBER	PART NUMBER		DESCRIPTION
	Series 88	Series 78*	
29	301216		Assembly - Brake Pedal Lock
30	300058		Assembly - Brake Lock
31	300413		Pad Brake Pedal
32	300370 300371		Tire - Solid Tire - Pneumatic
33	300414		Bushing - Plastic Main Broom
34	301522		Spring Extension Brake Arm
35	400116		Pin - Clevis 3/8 x 1.25
36	400118		Pin - Clevis 5/16 x .88

*When no number appears in this column, the parts number for the 78 Series is the same as that for the 88 Series.


TABLE OF CONTENTS
Options

To Order Parts and Supplies.....	I-1
Ford Gas Engine.....	I-3
Perkins Diesel Engine.....	I-5
Kubota Diesel Engine.....	I-9
Cab.....	I-11
Overhead Guard.....	I-13
Windshield Wiper.....	I-15
Heater/Defroster.....	I-17
Pressurizer.....	I-19
Hopper Fire Indicator.....	I-21
Clogged Filter Indicator.....	I-23
Light Options.....	I-25
Power Packer High Dump Assembly.....	I-27
Powerstack Group.....	I-31
Blower Option.....	I-33
Vacuum Wand.....	I-35
Vacuumized Curb Broom (Hood Detail).....	I-37
Vacuumized Curb Broom (Hopper Detail).....	I-39
Heavy Duty Curb Broom Guard.....	I-41
Wet Sweep Bypass.....	I-43
Michelin Tire Assembly.....	I-45

TO ORDER PARTS AND SUPPLIES


The components and parts used in your PowerBoss™ sweeper are selected for quality, performance and safety. Use only AAR Brooks & Perkins parts and supplies to repair and maintain your machine.

To order parts and supplies, contact your distributor.




FORD GAS ENGINE

ITEM NUMBER	PART NUMBER	DESCRIPTION
1	301865	Assembly Engine Ford Gas
2	300722	Assembly - Engine Mnt Frt Ford
3	300724	Assembly - Engine Mnt Rear Ford
4	300954	Adap - Pump Drive Ford
5	301718	Key - 1/4" Sq x .88 Lg
6,7,8	302655	Assembly - Drive Sprocket Complete
9	300679	Assembly - Pump Mtg Plate Pntd
10	300464	Mnt Isolation
11	303094	Ftg - Adap 1/2 - 20 to 3/8" NPT
12	400190	Ftg - 90° El 1/2" Tube to 3/8" NPT
13	301716	Hose - Oil Drain
14	400194	Ftg - Pipe Plug 3/8" NPT - Socket
15	300387	Sender - Oil Pressure
16	301716	Hose - Oil Drain
17	301856	Rod - Throttle Pltd Ford
18	301459	Assembly - Ball Joint #10 - 32
19	301468	Assembly - Throttle Lever Pltd
20	303015	Assembly - Pump VD & Aux Comp
21	303097	Hose - Vacuum Line Governor - Ford
22	300386	Sender - Temp Ford
23	300563	Knob - Ball Throttle
24	301858	Cable - Choke Ford
25	301853	Assembly - Engine Mount Flywheel Ford
26	303036	Bracket - Radiator Hose Mount Ford




PERKINS DIESEL ENGINE

ITEM NUMBER	PART NUMBER	DESCRIPTION
1	302745	Engine - Diesel Perkins
2	302979	Mnt - Engine Lt Frt
3	302981	Mnt - Engine Rt Frt
4	302978	Mnt - Engine Lt Rear
5	302980	Mnt - Engine Rt Rear
6	302971	Adap - Pump Drive Perkins
7	301718	Key - 1/4" Sq x .88 Lg
8	302655	Assy - Sprocket Driven & Drive Comp
9	302558	Assy - Sprocket Driven & Drive Comp
10	300531	Bushing - Tapered Ret
11	303101	Assy - Pump Mtg Plate Perkins
12	303015	Assy - Pump VD & Aux Comp
13	303098	Coupling - Flywheel Perkins
14	303099	Brkt - Flywheel Coupling Perkins
15	302994	Spacer - Pump Mtg Plate Perkins
16	300464	Mnt - Isolation
17	303107	Hose - Fuel Return Line Diesel
18	303006	Tube - Fuel Return Line Diesel
19A	302931	Hose - H ₂ O Sep Perkins (Inlet)
19B	303107	Hose - H ₂ O Sep Perkins (Outlet)
20	302989	Mnt - H ₂ O Sep Perkins
21	302970	Spacer - Fan Perkins
22	302993	Brkt - Hose Ret Perkins
23	302904	Sender - Temp Diesel
24	303105	Ftg - Nipple 1/8" NPT x 2.00 Lg
25	300387	Sender - Oil Pressure
26	303122	Guard - Alternator Belt Perkins
27	302985	Assy - Bellcrank Pivot Diesel Perkins
28	302987	Assy - Bellcrank Mnt Diesel Perkins




PERKINS DIESEL ENGINE (cont.)

ITEM NUMBER	PART NUMBER	DESCRIPTION
29	302976	Rod - Throttle Short Perkins
30	301199	Assy - Ball Joint 1/4 - 28
31	302991	Rod - Throttle Linkage Perkins
32	302846	Assy - Throttle Lever Diesel
33	300430	Bushing - Self-Lubricating
34	300339	Sleeve - Squeegee
35	400178	Thrust Bearing - Laminated
36	301720	Ftg - 90° El 1/8" NPT
37	302969	Ftg - Oil Drain Diesel Perkins
38	303106	Hose - Oil Drain Perkins
39	400190	Ftg - 90° El 1/2" Tube to 3/8" NPT
40	400194	Ftg - Pipe Plug 3/8" NPT - Socket
41	301427	Cable - Stop Diesel
42	303110	Bar - Stop Cable Adj Perkins
43	302990	Rod - Stop Cable Ext Perkins
44	302992	Brkt - Imp Mnt Perkins
45	302340	Clip - Hyd Hose Case Drain



KUBOTA DIESEL ENGINE


ITEM NUMBER	PART NUMBER	DESCRIPTION
1	300439	Engine - Diesel Kubota
2	301885	Mnt - Engine Frt Diesel Kubota
3	301883	Mnt - Engine F/W Frt Diesel Kubota
4	301881	Mnt - Engine F/W Frt Diesel Kubota
5	301134	Assembly - Pump Mtg Plate Kubota
6	303015	Assembly - Pump VD & Aux Comp
7	303008	Hose - Fuel Return Line Kubota
8	303006	Tube - Fuel Return Line Diesel
9	300464	Mnt - Isolation
10	302801	Pulley - Engine Kubota
11	302906	Spacer - Fan
12	302907	Brkt - Imp Adj Kubota
13	302904	Sender - Temp Diesel
14	300387	Sender - Oil Pressure
15	301720	Ftg - 90° El 1/8" NPT
16	303014	Hose - Crankcase Vent Kubota
17	303011	Assembly - Bellcrank Diesel Kubota
18	302783	Assembly - Bellcrank Mnt Kubota
19	302780	Assembly - Bellcrank Pivot Kubota
20	400178	Brg - Fiberglide .531 ID x 1.00 OD
21	300339	Sleeve - Sq
22	300430	Bushing - Self - Lub .499 ID x .594 OD
23	302790	Rod - Throttle Long Kubota
24	301199	Assembly - Ball Joint 1/4 - 28
25	302846	Assembly - Throttle Lever Diesel
26	300563	Knob - Ball 1.00 Diameter
27	301427	Cable - Imp & Stop Diesel
28	302905	Fitting - Oil Pan Drain Kubota
29	400190	Fitting - 90° El 1/2" Tube to 3/8" NPT
30	303013	Hose - Oil Drain Kubota
31	400194	Ftg - Pipe Plug 3/8" NPT Socket
32	302935	Spring - Throttle Return
33	302791	Rod - Throttle Short Kubota
34	301459	Assembly - Ball Joint 10-32
35	302799	Adaptor - Pump Drive
36	302655	Assembly - Drive Sprocket Complete



CAB

ITEM NUMBER	PART NUMBER	DESCRIPTION
1	302916	Assy - Cab Frame
2	302908	Assy - Door Cab
3	302877	Assy - Hinge
4	302875	Spacer - Cab Option
5	302857	Striker - Latch Cab
6	302882	Plate - Cab Filler
7	302895	Insulation Cab Door
8	302888	Insulation - Cab Roof
9	302887	Insulation - Cab Door
10	302919	Seal - Cab Door
11	302922	Seal - Cab Door Post
12	302923	Seal - Cab - Bottom Front
13	302924	Seal- Cab Bottom Left Hand
14	302925	Seal - Cab Bottom Rear
15	302926	Seal - Cab Filler Plate
16	302928	Gasket - Frame Short
17	302929	Seal - Cab Foot Plate
18	302927	Gasket - Cab Frame
19	302482	Bumper - Seat Mount
20	300465	Mount - Isolation
21	302301	Latch - Cab
22	302932	Bolt - Cab Latch
23	303152	Plate - Cab Light Cover
24	303153	Plate - Cab Pressurizer
25	303141	Gasket - Cab Frame Lintel
26	303293	Bracket - Sup Sub Seat Mount


*When no number appears in this columns, the parts number for the 78 Series is the same as that for the 88 Series.



OVERHEAD GUARD

ITEM NUMBER	PART NUMBER		DESCRIPTION
	Series 88	Series 78*	
1	300785	300784	Assembly - Top Overhead Guard Pntd
2	300763		Assembly - Side RH Overhead Guard Pntd
3	300762		Assembly - Side LH Overhead Guard Pntd
4	302708		Bracket Corner - Overhead Guard Pntd
5	400203		Washer - Neoprene .41 ID x 2.00 OD

*When no number appears in this column, the parts number for the 78 Series is the same as that for the 88 Series.



WINDSHIELD WIPER

ITEM NUMBER	PART NUMBER	DESCRIPTION
1	303172	Kit - Wiper Motor
2	303173	Arm - Wiper Drive
3	303174	Shaft - Wiper Pivot
4	303175	Kit - Pantograph Arm Adaptor
5	303176	Arm - Wiper Fixed Length Pantograph
6	303177	Blade - Wiper Flat

