Chapter 2: Programma

		1
Chapter	Configuration	Content
2 2 2	0 0	
2	0	0
2	0	1
2 2 2	1 1 1	
2	1	0
2	1	1
2 2 2	3 3 3	
2	3	0
2	3	1
2 2 2	4 4 4	
2	4	0
2	4	1
2 2 2	5	
2	5 5	0 1
2	5	1
2	7 7 7	
2	7	0
2 2 2	7	1
2	8	
2	8	0
2	8	1
2	9	
2	9	0
2	9	1
2	В	
2	В	0
		•

2	В	1

able Program Varianten

Description	B400R
Last error indicator after switching on the machine	
Deactivate	Х
Activate	d
Water level when switching on scrubbing	
Last setting	d
Preset level (4)	х
Water level when switching on TOOL	
Last setting	d
Preset level (4)	X
Water amount depending on the speed	
Deactivate	Х
Activate	d
BlueSpot always On (drive pedal neutral)	
Deactivate	d
Activate	x
Silence Mode Setting	
Is not saved	X
Is saved	d
Acoustic Alarm Tone Interval	
Standard	d
Alternative	х
Chemical Dosing Adjustment- when machine is switched On	
Last setting	
Preset level (1:75)	
Highest water stage independent from machine speed	
No	d

Yes	Х