




REF.	CODE	DESCRIPTION	QT
1	SL04180	SCREW	1
2	E86758	Washer	1
3	SL06092	WASHER	1
4	E86706	Screw TE M 6-16	1
5	E89202	Washer	1
6	E89403	Bushing	2
7	E89194	Screw	2
8	E86363	spring AS36/WS36	1
9	E86847	Clip	1
10	E89442	Bearing	2
11	SL04312	SCREW	1
12	E88091	Washer Watchman 24	2
13	SL13065	SPRING	2
14	SL09537	HOOKING	1
15	E89464	Screw	1
16	E86852	Squeegee Knob AS30/36	2
20	E86878	Washer	3
21	E86853	Nyloc Hex Nut, M8 Zinc	5
22	E86879	Washer	8
23	E86845	Bracket, Squeegee	1
24	E86846	Lever, Squeegee	1
25	E86462	AS20 Nut	1
30	SL07493	SPACER	1
31	E86872	Screw	1
32	E86319	shaft WS20	1
33	E86486	Screw TE M8-45	1
34	E89204	Pin WS36	1
35	E89495	Spring	1
40	SL13014	CLIP	1
41	SL14006	TEAR RIVET	2
42	SL06018	WASHER	1
43	E86703	Nut M8	1
44	E86917	AS30/36 Fork	1
45	E89205	Lever WS36	1
46	E86450	Tank Support Handle	1
50	SL09737	SUPPORT	1
55	SL14222	REGISTER	1
56	SL23050	FAIRLEAD	1
57	SL04075	SCREW	1

