

Item	SKU	Description	QTY
01	E83989	Switch	3
02	E83175	battery level display	1
03	E82486	Momentary Rocker Switch	1
03A	E88305	Cover, Black	1
04	E88441	Control Panel Cover, Upper	1
05	E82493	Grips, Handle	2
06	E82782	Washer	2
07	E85751	Trigger Lever	1
08	400648	PLAQUE	2
09	E82304	Spring, 20.2x1.3x20.8mm	1
10	E81653	Shaft	1
11	E82284	Lever	1
12	E82270	Micro Switch	3
13	206198	SUPPORT	1
14	409370	SPRING PIN	1
15	400662	PLAQUE	1
16	400663	PLAQUE	1
17	206818	SPECIAL SCREW	2
18	E81704	Gasket	5
19	206196	PIPE	1
20	E83159	Relay 24VDC 20A	2
21	409815	FAIRLEAD	1
22	E82511	Chopper Card	1
25	E82359	Resistor, Braking	1
26	210310	HANDLE BAR BODY	1
28	E83157	battery indicator card	1
29	E81559	Decal	1
30	E83316	Key Switch	1
31	E83173	Contact, Key Switch	1
32	E83315	Switch Key	1
33	409556	RED CRISTAL	1
34	E81358	Switch Flange	1
35	E82351	Key Switch Assembly w/Keys	1
36	E82440	Bulb, Simpla Parking Brake	1
37	E82454	Bulb Socket, Simpla	1
38	E82441	Lamp Body, Simpla	1
50	E20243	Machine Screw M3x30 Zinc	3
51	E20292	Flat Washer M4x9x0.8 Zinc	3
52	409145	WASHER	2
53	E81673	Hex Nyloc Nut, M3 Zinc	2
54	408833	SCREW	1
55	408639	SCREW	4
56	409034	NUT	2
57	408834	SCREW	2
58	E88362	Screw M5 x 30	6
59	E83841	Lock Washer M5 Zinc	6
60	E88010	Hex Nut, M5	1
61	E83278	Washer M6.5x24x2	1
62	E86263	Machine Screw M5x35 SS	1