

General Purpose Engine GXV340K2 (Volume 1)

HONDA

Power

Equipment

Parts Catalog

Third Edition

April, 1998

AMERICAN HONDA MOTOR CO., INC.

© American Honda Motor Co., Inc. 1998

1MZE90E3-AH
PRINTED IN USA

TABLE OF CONTENTS

	Page
How To Use This Catalog	iv
Serial Numbers	vi
Part Groups	
Contents By Page No. Sequence	viii
Contents In Alphabetical Order	1
Engine Group	2
Index	
Part Number Index	38
Description Index	42

HOW TO USE THIS CATALOG

This parts catalog is to be used when ordering replacement parts for the model (s) specified on the microfiche strip.

CATALOG PAGE BREAKDOWN

MODEL(S)										Block No. E-1		
Ref. No.	Description								Qty Req	Part Number	H/C	
		M	M	M	M							
		O	O	O	O	T	T	T				
		D	D	D	D	Y	Y	Y				
		E	E	E	E	P	P	P				
		L	L	L	L	E	E	E				
		A	B	C	D	a	b	c	From	To		
1	2	3a						4a	5	6	7	8

1. **REF. NO.** — Reference number corresponding with the reference numbers on the illustrations. *
- * All illustrations are representative only and do not necessarily correspond exactly to the actual part. "NI" signifies the part is not illustrated.

2. **DESCRIPTION** — Describes the part for the related part number.

Abbreviations:

ASSY.	- Assembly	L (100L)	- Link (100 Links)
COMP.	- Complete	A.C.	- Alternating Current
R.	- Right	D.C.	- Direct Current
L.	- Left	IN	- Inlet
STD.	- Standard	EX.	- Exhaust
- MM	- Millimeter	FR.	- Front
G	- Gram	RR.	- Rear
T (22T)	- Tooth	HEX.	- Hexagonal
A	- Ampere	A.M.	- Attaching Mark
V	- Volt	T.M.	- Transcript Mark
W	- Watt	C.D.I.	- Capacitive Discharge Ignition
		H.S.T.	- Hydrostatic transmission

Decision for 'R' or 'L'.

'R' or 'L' in the description of a part stands for the Right hand side or the Left hand side which is decided by the operator's position during proper use of equipment.

3. **MODEL Application** — Model application for the various models listed in the catalog. Single model application will not require this section.

- 3a. **MODEL APPLICATION GUIDE** — A guide to the part application. These guide references are in upper case characters ie. A, B, C, etc..

4. **TYPE** — Model type variations. Single model type application will not require this section.

- 4a. **MODEL TYPE GUIDE** — A guide to the model type part's application. These guide references are in lower case characters ie. a, b, c, etc..

5. **SERIAL NUMBER** — Applies to Engine or Frame serial numbers depending on the section.
- The serial number of the vehicle (frame, engine, carburetor) should be checked prior to ordering parts for a specific unit. In cases where a part has been modified, the serial number of the vehicle bearing the modification is listed in the 'SERIAL NUMBER' column.
- The modification parts are controlled by each pertinent serial number below:
- Engine serial number** — Engine group parts (Block numbers beginning with 'E').
- Carburetor identification number** — Carburetor component parts.
- Frame serial numbers** — Frame group parts (Block numbers beginning with 'F').
- Serial number application chart and Serial number locations are provided.

Note: Some models may be controlled by one serial number only.

6. **QTY. REQ.** — Quantity required per unit as specified.
- A. "AR" in place of the quantity indicates AS REQUIRED.
- B. "()" Parenthesis in the quantity required column indicates "optional" (only the open parenthesis will appear if the quantity required is over 9).
7. **PART NUMBER** — Part number corresponding to the reference numbers and application. Several part numbers may be listed under one (1) reference number. For your convenience the current supersede chain, as of print date, has been listed for you from oldest to newest. Supersede chains are subject to change without notice.

HOW TO USE THIS CATALOG

MAKE-UP OF PART NUMBERS

All parts are classified into two groups consisting of "GENERAL PARTS" and "STANDARD PARTS". All parts are numbered in accordance with system described below:

General Parts

Example: Throttle lever knob 17856-750-000ZA
 Function No. 17
 Component No. 856
 Parts Classification No. -750-
 Classification No. 000
 *Color Code ZA

Standard Parts

Example: Screw, Pan 4 x 20 Part No. 93500-04020-1A
 Function No. 93
 Type No. 500
 Dimensions -04020-
 ISO Standard Designation 1
 Chemical Surface Treatment A

- * The color code at the end of a General Part's part number indicate the color. However, color codes such as ZA, ZB, ZC onward except ZZ, do not indicate the color directly but refer to the notes " " in the Description Column of this Parts Catalog Microfiche. If the color description is not indicated in the text, refer to the color table.

8. H/C — The Honda Code is listed to the right of each Part Number.

ADDITIONAL INFORMATION

The table of contents located at the right of each microfiche grid lists sectioned titles in alphabetical order. Some microfiche will require separate tables of contents for the Engine and Frame sections when they exceed the number of lines allowed if combined.

- NOTE:** The Block No. listed in the upper right hand corner of the Description heading refers to a complete illustration page and it's text, and should not be confused with the GRID NO. when using microfiche.

SERIAL NUMBERS


Models and applicable serial numbers

Models and applicable serial Nos. given in this parts catalog can be identified as follows.
Parts with types are exclusive for models destined for countries designated.
If no types are listed, parts are for common use.


Model	Type	Applicable Engine Serial No.	Applicable Frame Serial No.	Applicable Carburetor Identification No.
GXV340K2	DA23	GJ02-6000001 ~	—	BE81A
	DA33	GJ02-6000001 ~	—	BE81A
	DET3	GJ02-6000001 ~	—	BE81A
	DE33	GJ02-6000001 ~	—	BE81A
	DNE3	GJ02-6000001 ~	—	BE81A
	DN3	GJ02-6000001 ~	—	BE81A
	DP23 *	GEAA-6000001 ~	—	BEL6A
	DX3	GJ02-6000001 ~	—	BE81A

*(PROPANE)

Location of stamped serial number



CARBURETOR IDENTIFICATION NUMBER



DZE9-B

MANUALS

DESCRIPTION	PART NUMBER	H/C
GXV340K2 (VOLUME 1) MICROFICHE	1MZE90M	5018817
GXV340K2 (VOLUME 1) PARTS CATALOG	1MZE90E3-AH	5596424
GXV270; GXV340 SERVICE MANUAL	61ZE802	2950152
GXV340K2; GXV390 (SUPPLEMENT) SERVICE MANUAL	61ZE802W	5159496
GXV270; GXV340; GXV390 SERVICE MANUAL	61ZE810	4782363
GXV340; GXV390 OWNER'S MANUAL	31ZF5710	5046891


Contents By Page No. Sequence

PAGE TITLE	PAGE	GRID	PAGE TITLE	PAGE	GRID
CYLINDER HEAD	2	1-B1			
CYLINDER BARREL	4	1-B2			
CRANKSHAFT	9	1-B4			
CAMSHAFT	12	1-B6			
RECOIL STARTER	14	1-B7			
FAN COVER	16	1-C1			
CARBURETOR (1)	18	1-C2			
CARBURETOR (2)	20	1-C3			
AIR CLEANER (1)	21	1-C3			
AIR CLEANER (2)	22	1-C4			
MUFFLER	23	1-C4			
FUEL TANK	26	1-C6			
FLYWHEEL	28	1-C7			
IGNITION COIL	30	1-D1			
STARTER MOTOR	32	1-D2			
CONTROL	33	1-D2			
LABEL	36	1-D4			

Contents in Alphabetical Order

PAGE TITLE	PAGE	GRID	PAGE TITLE	PAGE	GRID
AIR CLEANER (1)	21	1-C3			
AIR CLEANER (2)	22	1-C4			
CAMSHAFT	12	1-B6			
CARBURETOR (1)	18	1-C2			
CARBURETOR (2)	20	1-C3			
CONTROL	33	1-D2			
CRANKSHAFT	9	1-B4			
CYLINDER BARREL	4	1-B2			
CYLINDER HEAD	2	1-B1			
FAN COVER	16	1-C1			
FLYWHEEL	28	1-C7			
FUEL TANK	26	1-C6			
IGNITION COIL	30	1-D1			
LABEL	36	1-D4			
MUFFLER	23	1-C4			
RECOIL STARTER	14	1-B7			
STARTER MOTOR	32	1-D2			

CYLINDER HEAD




ZE8ME0100

GXV340K2 GXV340K2-P			TYPE								ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-1	G X V 3 4 0 K 2	G X V 3 4 0 K 2	D A 2 3 3	D A 2 3 3	D E T 3 3	D E N 3 3	D E N 3 3	D P X 3 3	FROM	TO			
	1 CYLINDER HEAD COMP.	•	•	•	•	•	•	•	•	•	-----	-----	1	122A0-ZE9-600	3131794
	CYLINDER HEAD COMP.	•	•	•	•	•	•	•	•	•	-----	-----	1	12200-ZE9-920	4949749
	2 GUIDE, VALVE (OS)	•	•	•	•	•	•	•	•	•	-----	-----	(1)	12204-ZE2-306	4179164
		•	•	•	•	•	•	•	•	•	-----	-----	(1)	12204-ZE2-306	4179164
	3 GUIDE, EX. VALVE (OS)	•	•	•	•	•	•	•	•	•	-----	-----	(1)	12205-ZE2-305	2089563
		•	•	•	•	•	•	•	•	•	-----	-----	(1)	12205-ZE2-305	2089563
	4 CLIP, VALVE GUIDE	•	•	•	•	•	•	•	•	•	-----	-----	2	12216-ZE2-300	2089597
		•	•	•	•	•	•	•	•	•	-----	-----	2	12216-ZE2-300	2089597
	5 GASKET, CYLINDER HEAD	•	•	•	•	•	•	•	•	•	-----	-----	1	12251-ZE9-600	3131810
	GASKET, CYLINDER HEAD	•	•	•	•	•	•	•	•	•	-----	-----	1	12251-ZE9-900	3112299
	6 COVER, HEAD	•	•	•	•	•	•	•	•	•	-----	-----	1	12310-ZE8-000	2089613
		•	•	•	•	•	•	•	•	•	-----	-----	1	12310-ZE8-000	2089613
	7 GASKET, CYLINDER HEAD COVER	•	•	•	•	•	•	•	•	•	-----	-----	1	12391-ZE8-000	2089670
		•	•	•	•	•	•	•	•	•	-----	-----	1	12391-ZE8-000	2089670
	8 COVER (LOWER)	•	•	•	•	•	•	•	•	•	-----	-----	1	18345-ZF5-020	4949848
	9 STAY COMP., COVER (LOWER)	•	•	•	•	•	•	•	•	•	-----	-----	1	18347-ZE8-000	2278729
	10 BOLT, FLANGE (6X12)	•	•	•	•	•	•	•	•	•	-----	-----	3	90013-883-000	0636845

GXV340K2 GXV340K2-P		E-1	TYPE							ENGINE SERIAL NUMBER	QTY REQ		
Ref. No.	BLOCK NO. DESCRIPTION		G X V 3 4 0 K 2 -	D A 2 3 3	D A 3 3 3	D E T 3 3	D E E 3 3	D N E 3 3	D N X 3 3			PART NUMBER	HONDA CODE
11	BOLT, HEAD COVER	•	•	•	•	•	•	•	•	-----	1	90014-ZE8-000	2092955
		•	•	•	•	•	•	•	•	-----	1	90014-ZE8-000	2092955
12	BOLT, STUD (8X131.5)	•	•	•	•	•	•	•	•	-----	2	90042-ZE8-000	2106656
		•	•	•	•	•	•	•	•	-----	2	90042-ZE8-000	2106656
13	WASHER COMP., HEAD COVER	•	•	•	•	•	•	•	•	-----	1	90441-ZE2-010	2293918
		•	•	•	•	•	•	•	•	-----	1	90441-ZE2-010	2293918
14	BOLT, STUD (8X32)	•	•	•	•	•	•	•	•	-----	2	92900-08032-0B	1803451
		•	•	•	•	•	•	•	•	-----	2	92900-08032-0B	1803451
15	PIN A, DOWEL (12X20)	•	•	•	•	•	•	•	•	-----	2	94301-12200	0165324
		•	•	•	•	•	•	•	•	-----	2	94301-12200	0165324
16	BOLT, FLANGE (6X12)	•	•	•	•	•	•	•	•	-----	1	95701-06012-00	2105799
17	BOLT, FLANGE (10X80)	•	•	•	•	•	•	•	•	-----	4	95701-10080-00	2545341
		•	•	•	•	•	•	•	•	-----	4	95701-10080-00	2545341
18	SPARK PLUG (BPR5ES) (NGK)	•	•	•	•	•	•	•	•	-----	1	98079-55846	1672443
		•	•	•	•	•	•	•	•	-----	1	98079-55846	1672443

CYLINDER BARREL




ZE9ME0300

GXV340K2 GXV340K2-P		TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-3	G X V 3 4 0 K 2 -	D A 3 3	D E T 3	D E N 3	D N 3	D P 2 3	FROM	TO			
1	GOVERNOR KIT	•	•	•	•	•	•	•	-----	-----	(1)	06165-ZE3-000	3712940
		•						•	-----	-----	(1)	06165-ZE3-000	3712940
2	PAN ASSY., OIL	•			•		•	•	-----	-----	1	11300-ZF5-W03	4949707
	PAN ASSY., OIL	•	•						-----	-----	1	11300-ZF5-W13	4949715
	PAN ASSY., OIL	•				•		•	-----	-----	1	11300-ZF5-W22	4892881
	PAN ASSY., OIL	•		•					-----	-----	1	11300-ZF5-W32	4949723
	PAN ASSY., OIL	•	•					•	-----	-----	1	11300-ZF5-W32	4949723
3	GASKET, OIL PAN	•	•	•	•	•	•	•	-----	-----	1	11381-ZE9-800	4145660
		•						•	-----	-----	1	11381-ZE9-800	4145660
4	CYLINDER ASSY.	•	•	•	•	•	•	•	-----	-----	1	12000-ZE9-603	4981932
		•						•	-----	-----	1	12000-ZE9-603	4981932
5	TUBE, BREATHER	•	•	•	•	•	•	•	-----	-----	1	12315-ZF5-000	3131828
		•						•	-----	-----	1	12315-ZF5-000	3131828
6	CAP, BREATHER CHAMBER	•	•	•	•	•	•	•	-----	-----	1	12370-ZF5-000	3131836
		•						•	-----	-----	1	12370-ZF5-000	3131836
7	VALVE, BREATHER	•	•	•	•	•	•	•	-----	-----	1	12372-ZE2-300	2061620
		•						•	-----	-----	1	12372-ZE2-300	2061620

GXV340K2 GXV340K2-P		E-3	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION		G X V 3 4 0 K 2	D A 3	D A 3	D E 3	D E 3	D N 3	D P 2			
	8 GASKET, BREATHER CAP		•	•	•	•	•	•	•	1	12373-ZE8-000	2089647
			•						•	1	12373-ZE8-000	2089647
	9 PLATE, ONE-WAY VALVE		•	•						1	12375-ZE9-010	2484954
			•						•	1	12375-ZE9-010	2484954
	10 VALVE, ONE-WAY		•	•						1	12376-ZE8-000	2089662
			•						•	1	12376-ZE8-000	2089662
	11 COVER, OIL PUMP		•	•	•	•	•	•	•	1	15130-ZE8-000	2089886
			•						•	1	15130-ZE8-000	2089886
	12 O-RING, PUMP COVER		•	•	•	•	•	•	•	1	15131-ZE9-003	2278331
			•						•	1	15131-ZE9-003	2278331
	13 ROTOR COMP. (INNER)		•	•	•	•	•	•	•	1	15330-ZE8-000	2089902
			•						•	1	15330-ZE8-000	2089902
	14 ROTOR, OIL PUMP (OUTER)		•	•	•	•	•	•	•	1	15332-891-003	0800219
			•						•	1	15332-891-003	0800219
	15 PLATE, OIL FILTER		•		•	•	•	•	•	1	15334-ZE8-010	2461655
	16 PLATE, OIL FILTER		•	•						1	15334-ZE8-811	2577294
			•						•	1	15334-ZE8-811	2577294
	17 RUBBER, OIL RETURN		•	•	•	•	•	•	•	1	15335-ZE9-000	2278349
			•						•	1	15335-ZE9-000	2278349
	18 STOPPER, OIL		•	•						1	15336-ZE8-000	2485043
			•						•	1	15336-ZE8-000	2485043
	19 PLATE, OIL STOPPER		•	•						1	15337-ZE8-000	2485050
			•						•	1	15337-ZE8-000	2485050
	20 FILTER, OIL (TOYO) (SHIPPED IN MULTIPLES OF 30) ...		•	•	•	•	•	•		1	15400-PR3-004	3179553
	FILTER, OIL (SINGLE ITEM)		•	•	•	•	•	•		1	15410-ZJ4-999AH	5159298
	21 BASE, OIL FILTER		•	•	•	•	•	•		1	15411-ZF5-W00	4452918
	22 PLATE COMP., SUCTION		•	•						1	15420-ZE8-000	2461663
			•						•	1	15420-ZE8-000	2461663
	23 SCREEN, OIL FILTER		•	•	•	•	•	•	•	1	15421-ZE9-003	2608644
			•						•	1	15421-ZE9-003	2608644
	24 CAP ASSY., OIL FILLER		•	•	•	•	•	•	•	1	15600-ZF5-000	3131919
			•						•	1	15600-ZF5-000	3131919
	25 GASKET, OIL FILLER CAP		•	•	•	•	•	•	•	1	15625-ZE8-000	2089969
			•						•	1	15625-ZE8-000	2089969
	26 EXTENSION, OIL FILLER		•	•	•	•	•	•	•	1	15630-ZE8-000	2089977
			•						•	1	15630-ZE8-000	2089977

CYLINDER BARREL




ZE9ME0300

GXV340K2 GXV340K2-P		TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-3	G X V 3 4 0 K 2	D A 3 3	D E T 3	D E E 3	D E N 3	D N X 3	FROM	TO			
27	GOVERNOR ASSY.	•	•	•	•	•	•	•	-----	-----	1	16510-ZE3-000	3713187
		•	•	•	•	•	•	•	-----	-----	1	16510-ZE3-000	3713187
28	WEIGHT, GOVERNOR	•	•	•	•	•	•	•	-----	-----	3	16511-ZE8-000	2090090
		•	•	•	•	•	•	•	-----	-----	3	16511-ZE8-000	2090090
29	HOLDER, GOVERNOR WEIGHT	•	•	•	•	•	•	•	-----	-----	1	16512-ZE3-000	3713195
		•	•	•	•	•	•	•	-----	-----	1	16512-ZE3-000	3713195
30	PIN, GOVERNOR WEIGHT	•	•	•	•	•	•	•	-----	-----	3	16513-ZE2-000	2025971
		•	•	•	•	•	•	•	-----	-----	3	16513-ZE2-000	2025971
31	SLIDER, GOVERNOR	•	•	•	•	•	•	•	-----	-----	1	16531-ZE2-000	2025989
		•	•	•	•	•	•	•	-----	-----	1	16531-ZE2-000	2025989
32	SHAFT, GOVERNOR ARM	•	•	•	•	•	•	•	-----	-----	1	16541-ZE8-010	4751293
		•	•	•	•	•	•	•	-----	-----	1	16541-ZE8-010	4751293
33	COLLAR, EXTENSION	•	•	•	•	•	•	•	-----	-----	1	17240-ZE6-000	1453000
		•	•	•	•	•	•	•	-----	-----	1	17240-ZE6-000	1453000
34	SWITCH COMP., OIL LEVEL	•	•	•	•	•	•	•	-----	-----	1	35410-ZF5-003	3132206
		•	•	•	•	•	•	•	-----	-----	1	35410-ZF5-003	3132206
35	PROTECTOR, SWITCH	•	•	•	•	•	•	•	-----	-----	1	35419-ZF5-000	3132214
		•	•	•	•	•	•	•	-----	-----	1	35419-ZF5-000	3132214

GXV340K2 GXV340K2-P			GXV340K2- E-3	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE	
Ref. No.	BLOCK NO. DESCRIPTION	DA23		DA33	DET33	DEN33	DN33	DP23	FROM TO					
	36 BOLT, FLANGE (6X12)	•	•						-----	-----	4	90013-883-000	0636845	
		•		•	•	•	•		-----	-----	2	90013-883-000	0636845	
		•						•	-----	-----	4	90013-883-000	0636845	
	37 BOLT, FLANGE (6X35)	•	•	•		•	•	•	-----	-----	1	90014-ZE6-000	1688076	
		•						•	-----	-----	1	90014-ZE6-000	1688076	
	38 HOLDER, OIL FILTER	•	•		•		•		-----	-----	1	90018-PN3-000	3509528	
	39 BOLT, FLANGE (6X25)	•	•			•	•		-----	-----	2	90121-952-000	0748111	
	40 WASHER, THRUST-(8.1MM)	•	•	•	•	•	•		-----	-----	1	90406-VM6-000	1806934	
		•						•	-----	-----	1	90406-VM6-000	1806934	
	41 CLIP, GOVERNOR HOLDER	•	•	•	•	•	•	•	-----	-----	1	90602-ZE1-000	2456697	
		•							-----	-----	1	90602-ZE1-000	2456697	
	42 PIN, DOWEL (8X12)	•	•	•	•	•	•	•	-----	-----	2	90701-HC4-000	2978443	
		•						•	-----	-----	2	90701-HC4-000	2978443	
	43 BEARING, RADIAL BALL (6202)	•	•	•	•	•	•	•	-----	-----	2	91001-ZF5-003	3132263	
		•						•	-----	-----	2	91001-ZF5-003	3132263	
	44 OIL SEAL (35X52X8)	•	•	•	•	•	•	•	-----	-----	2	91201-ZE3-004	2108595	
		•						•	-----	-----	2	91201-ZE3-004	2108595	
	45 OIL SEAL (8X14X5)	•	•	•		•	•	•	-----	-----	1	91201-ZE9-003	2461713	
		•						•	-----	-----	1	91201-ZE9-003	2461713	
	OIL SEAL (8X14X5)	•	•	•	•	•	•	•	-----	-----	1	91203-952-771	0744326	
		•						•	-----	-----	1	91203-952-771	0744326	
	46 O-RING (22.5X2.2)	•	•	•	•	•	•	•	-----	-----	1	91301-ZE9-003	2280006	
		•						•	-----	-----	1	91301-ZE9-003	2280006	
	47 O-RING (11.8X2.4)	•	•						-----	-----	2	91320-MJ6-003	2023935	
		•		•	•	•	•	•	-----	-----	1	91320-MJ6-003	2023935	
		•						•	-----	-----	2	91320-MJ6-003	2023935	
	48 O-RING (11X1.9) (NOK)	•	•		•		•		-----	-----	2	91303-HA0-004	1842384	
	49 COLLAR, OIL FILTER SETTING	•			•	•	•	•	-----	-----	1	91501-ZF5-000	3132271	
	50 BOLT, DRAIN PLUG (20MM)	•	•	•	•	•	•	•	-----	-----	1	92800-20000	0209635	
		•						•	-----	-----	1	92800-20000	0209635	
	51 WASHER, PLAIN (6MM)	•	•	•	•	•	•	•	-----	-----	1	94101-06800	0345900	
		•						•	-----	-----	1	94101-06800	0345900	
	52 WASHER, PLAIN (6MM)	•	•			•	•		-----	-----	1	94103-06700	0622324	
		•						•	-----	-----	1	94103-06700	0622324	
	53 WASHER, DRAIN PLUG (20MM)	•	•	•	•	•	•	•	-----	-----	1	94109-20000	0251728	
		•						•	-----	-----	1	94109-20000	0251728	
	54 PIN, LOCK (10MM)	•	•	•	•	•	•	•	-----	-----	1	94251-10000	0159269	
		•						•	-----	-----	1	94251-10000	0159269	


CYLINDER BARREL



ZE9ME0800

GXV340K2 GXV340K2-P		TYPE						ENGINE SERIAL NUMBER		Q T Y	PART NUMBER		HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-3	G X V 3 4 0 K 2	D A 2 3	D E T 3	D E N 3	D X 3	FROM	TO	R E Q			
55	BOLT, FLANGE (6X12)	•	•	•	•	•	•	-----	-----	3	95701-06012-00	2105799	
		•	•	•	•	•	•	-----	-----	3	95701-06012-00	2105799	
56	BOLT, FLANGE (6X16)	•	•	•	•	•	•	-----	-----	1	95701-06016-00	2410892	
		•	•	•	•	•	•	-----	-----	1	95701-06016-00	2410892	
57	BOLT, FLANGE (6X25)	•	•	•	•	•	•	-----	-----	1	95701-06025-00	2105831	
		•	•	•	•	•	•	-----	-----	1	95701-06025-00	2105831	
58	BOLT, FLANGE (8X40)	•	•	•	•	•	•	-----	-----	6	95701-08040-08	2374775	
		•	•	•	•	•	•	-----	-----	6	95701-08040-08	2374775	
59	BOLT, FLANGE (8X60)	•	•	•	•	•	•	-----	-----	1	95701-08060-08	2488526	
		•	•	•	•	•	•	-----	-----	1	95701-08060-08	2488526	
60	BEARING, RADIAL BALL (6207)	•	•	•	•	•	•	-----	-----	1	96100-62070-00	0997320	
		•	•	•	•	•	•	-----	-----	1	96100-62070-00	0997320	
	BEARING, RADIAL BALL (6207)	•	•	•	•	•	•	-----	-----	1	96100-62073-00	0572206	
		•	•	•	•	•	•	-----	-----	1	96100-62073-00	0572206	


CRANKSHAFT



ZE9ME0700

GXV340K2 GXV340K2-P		TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-7	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E E 3	D N E 3	D N X 3	D P 2 3			
1	RING SET, PISTON (STD)	•	•	•	•	•	•	•	•	•	1	13010-ZE3-003	2278182
		•	•	•	•	•	•	•	•	•	1	13010-ZE3-003	2278182
	RING SET, PISTON (0.25)	•	•	•	•	•	•	•	•	•	(1)	13011-ZE3-003	2278208
		•	•	•	•	•	•	•	•	•	(1)	13011-ZE3-003	2278208
	RING SET, PISTON (0.50)	•	•	•	•	•	•	•	•	•	(1)	13012-ZE3-003	2278224
		•	•	•	•	•	•	•	•	•	(1)	13012-ZE3-003	2278224
	RING SET, PISTON (0.75)	•	•	•	•	•	•	•	•	•	(1)	13013-ZE3-003	2278240
		•	•	•	•	•	•	•	•	•	(1)	13013-ZE3-003	2278240
2	PISTON (STD)	•	•	•	•	•	•	•	•	•	1	13101-ZE3-W00	3735420
		•	•	•	•	•	•	•	•	•	1	13101-ZE3-W00	3735420
	PISTON (0.25)	•	•	•	•	•	•	•	•	•	(1)	13102-ZE3-W00	3738226
		•	•	•	•	•	•	•	•	•	(1)	13102-ZE3-W00	3738226
	PISTON (0.50)	•	•	•	•	•	•	•	•	•	(1)	13103-ZE3-W00	3738234
		•	•	•	•	•	•	•	•	•	(1)	13103-ZE3-W00	3738234
	PISTON (0.75)	•	•	•	•	•	•	•	•	•	(1)	13104-ZE3-W00	3738242
		•	•	•	•	•	•	•	•	•	(1)	13104-ZE3-W00	3738242
3	PIN, PISTON	•	•	•	•	•	•	•	•	•	1	13111-ZE3-000	2107696
		•	•	•	•	•	•	•	•	•	1	13111-ZE3-000	2107696

CRANKSHAFT




ZE9ME0700

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-7	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E N 3	D N X 3	D P 2 3	FROM	TO			
3	PIN, PISTON	•	•	•	•	•	•	•	•	-----	-----	1	13111-ZF6-000	3134434
		•	•	•	•	•	•	•	•	-----	-----	1	13111-ZF6-000	3134434
4	ROD ASSY., CONNECTING	•	•	•	•	•	•	•	•	-----	-----	1	13200-ZE9-010	2879948
		•	•	•	•	•	•	•	•	-----	-----	1	13200-ZE9-010	2879948
	ROD ASSY., CONNECTING (0.25 LOWER SIZE)	•	•	•	•	•	•	•	•	-----	-----	(1)	13200-ZE9-315	2953107
		•	•	•	•	•	•	•	•	-----	-----	(1)	13200-ZE9-315	2953107
5	CRANKSHAFT COMP.	•	•	•	•	•	•	•	•	-----	-----	1	13310-ZF5-030	4788683
		•	•	•	•	•	•	•	•	-----	-----	1	13310-ZF5-030	4788683
6	WEIGHT A, BALANCER	•	•	•	•	•	•	•	•	-----	-----	1	13351-ZE9-603	4949764
		•	•	•	•	•	•	•	•	-----	-----	1	13351-ZE9-603	4949764
7	WEIGHT B, BALANCER	•	•	•	•	•	•	•	•	-----	-----	1	13356-ZE9-604	4949772
		•	•	•	•	•	•	•	•	-----	-----	1	13356-ZE9-604	4949772
8	BOLT, CONNECTING ROD	•	•	•	•	•	•	•	•	-----	-----	2	90001-ZE8-000	2160489
		•	•	•	•	•	•	•	•	-----	-----	2	90001-ZE8-000	2160489
9	WASHER, THRUST (14MM)	•	•	•	•	•	•	•	•	-----	-----	2	90417-HA0-000	1824507
		•	•	•	•	•	•	•	•	-----	-----	2	90417-HA0-000	1824507
10	CLIP, PISTON PIN (20MM)	•	•	•	•	•	•	•	•	-----	-----	2	90601-ZE3-000	2108579
		•	•	•	•	•	•	•	•	-----	-----	2	90601-ZE3-000	2108579

GXV340K2 GXV340K2-P		E-7	TYPE							ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION		G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E T 3	D E T 3	D E T 3				
	11 BEARING, RADIAL BALL (6207)		•	•	•	•	•	•	•	-----	1	96100-62070-00	0997320
			•							-----	1	96100-62070-00	0997320
	BEARING, RADIAL BALL (6207)		•	•	•	•	•	•	•	-----	1	96100-62073-00	0572206
			•							-----	1	96100-62073-00	0572206

CAMSHAFT




ZE9ME0900

GXV340K2 GXV340K2-P		GXV340K2	TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO.		D A 2 3	D A 3 3	D E T 3	D E 3 3	D N 3 3	D P 2 3	SERIAL NUMBER					
	DESCRIPTION								FROM	TO				
	_1 SEAL, VALVE STEM	•	•	•	•	•	•	•	-----	-----	2	12209-ZE8-003	2089571	
		•						•	-----	-----	2	12209-ZE8-003	2089571	
	2 CAMSHAFT	•	•	•	•	•	•	•	-----	-----	1	14100-ZE8-305	4730503	
		•						•	-----	-----	1	14100-ZE8-305	4730503	
	CAMSHAFT ASSY.	•	•	•	•	•	•	•	-----	-----	1	14100-ZE8-601	4608410	
		•						•	-----	-----	1	14100-ZE8-601	4608410	
	3 ROD, PUSH	•	•	•	•	•	•	•	-----	-----	2	14410-ZE3-013	3371804	
		•						•	-----	-----	2	14410-ZE3-013	3371804	
	4 ARM, VALVE ROCKER	•	•	•	•	•	•	•	-----	-----	2	14431-ZE2-000	2025591	
		•						•	-----	-----	2	14431-ZE2-000	2025591	
	5 LIFTER, VALVE	•	•	•	•	•	•	•	-----	-----	2	14441-ZE2-000	2025609	
		•						•	-----	-----	2	14441-ZE2-000	2025609	
	6 PIVOT, ROCKER ARM	•	•	•	•	•	•	•	-----	-----	2	14451-ZE1-013	4300901	
		•						•	-----	-----	2	14451-ZE1-013	4300901	
	7 SPRING, WEIGHT RETURN	•	•	•	•	•	•	•	-----	-----	1	14568-ZE1-000	1426907	
		•						•	-----	-----	1	14568-ZE1-000	1426907	
	8 VALVE, IN.	•	•	•	•	•	•	•	-----	-----	1	14711-ZE3-000	2107779	
	VALVE, IN.	•	•					•	-----	-----	1	14711-ZE9-900	2383123	

GXV340K2 GXV340K2-P		E-9	TYPE							ENGINE SERIAL NUMBER FROM TO	QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION		GXV340K2-	DA33	DET3	DEN3	DN3	DPX3					
	9 VALVE, EX.		•	•	•	•	•	•	-----	-----	1	14721-ZE3-000	2107787
	VALVE, EX. (STELITE)		•					•	-----	-----	1	14721-ZE9-900	2383131
	10 SPRING, VALVE		•	•	•	•	•	•	-----	-----	2	14751-ZE2-003	2025633
			•					•	-----	-----	2	14751-ZE2-003	2025633
	11 RETAINER, IN. VALVE SPRING		•	•	•	•	•	•	-----	-----	1	14771-ZE2-000	2025641
			•					•	-----	-----	1	14771-ZE2-000	2025641
	12 RETAINER, EX. VALVE SPRING		•	•	•	•	•	•	-----	-----	1	14773-ZE2-000	2025658
	RETAINER, IN. VALVE SPRING		•					•	-----	-----	1	14771-ZE2-000	2025641
	13 SEAT, VALVE SPRING		•	•	•	•	•	•	-----	-----	2	14775-ZE2-010	2157485
			•					•	-----	-----	2	14775-ZE2-010	2157485
	14 ROTATOR, VALVE		•	•	•	•	•	•	-----	-----	1	14781-ZE2-000	2025666
	15 GUIDE, PUSH ROD		•	•	•	•	•	•	-----	-----	1	14791-ZE9-000	2271286
			•					•	-----	-----	1	14791-ZE9-000	2271286
	16 BOLT, PIVOT		•	•	•	•	•	•	-----	-----	2	90012-ZE0-010	1756964
			•					•	-----	-----	2	90012-ZE0-010	1756964
	17 NUT, PIVOT ADJ.		•	•	•	•	•	•	-----	-----	2	90206-ZE1-000	1431287
			•					•	-----	-----	2	90206-ZE1-000	1431287

RECOIL STARTER




ZE9ME1100A

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-11	G X V 3 4 0 K 2	D A 3 3	D E 3 3	D E 3 3	D E 3 3	D N 3 3	D P 2 3	FROM	TO			
-1	FILTER, AIR		•						•	-----	-----	1	17219-ZE8-900	2324093
2	STARTER ASSY., RECOIL *R8* (BRIGHT RED)		•	•	•	•	•	•	•	-----	-----	1	28400-ZE3-W01ZA	3713302
	STARTER ASSY., RECOIL *NH1* (BLACK)		•	•	•	•	•	•	•	-----	-----	1	28400-ZE3-W01ZB	4209920
3	STARTER ASSY., RECOIL *R8* (BRIGHT RED)		•						•	-----	-----	1	28400-ZE8-821ZA	4820049
	STARTER ASSY., RECOIL *NH1* (BLACK)		•						•	-----	-----	1	28400-ZE8-821ZB	5281183
4	CASE COMP., RECOIL STARTER *R8* (BRIGHT RED)		•	•	•	•	•	•	•	-----	-----	1	28410-ZE3-W01ZA	3713310
	CASE COMP., RECOIL STARTER *NH1* (BLACK)		•	•	•	•	•	•	•	-----	-----	1	28410-ZE3-W01ZB	4209953
5	CASE COMP., RECOIL STARTER *R8* (BRIGHT RED)		•						•	-----	-----	1	28410-ZE8-821ZA	5040241
	CASE COMP., RECOIL STARTER *NH1* (BLACK)		•						•	-----	-----	1	28410-ZE8-821ZB	5281191
6	PULLEY, RECOIL STARTER		•	•	•	•	•	•	•	-----	-----	1	28421-ZE3-W01	3713328

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER	Q T Y	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-11	G X V 3 4 0 K 2 -	D A 3 3	D E T 3 3	D E N 3 3	D E N 3 3	D X 3 3	D P 2 3				
										FROM TO	R E Q		
	6 PULLEY, RECOIL STARTER		•						•	-----	1	28421-ZE8-821	4820064
	7 RATCHET, STARTER		•	•	•	•	•	•	•	-----	2	28422-ZE2-W01	3678877
			•						•	-----	2	28422-ZE2-W01	3678877
	8 SPRING, FRICTION		•	•	•	•	•	•	•	-----	1	28441-ZE2-W01	3678885
			•						•	-----	1	28441-ZE2-W01	3678885
	9 SPRING, STARTER RETURN		•	•	•	•	•	•	•	-----	1	28442-ZE2-W01	3678893
			•						•	-----	1	28442-ZE2-W01	3678893
	10 SPRING, RATCHET		•	•	•	•	•	•	•	-----	2	28443-ZE2-W01	3678901
			•						•	-----	2	28443-ZE2-W01	3678901
	11 RETAINER, SPRING		•	•	•	•	•	•	•	-----	1	28444-ZE2-W01	3678919
			•						•	-----	1	28444-ZE2-W01	3678919
	12 HOLDER, SPRING		•	•	•	•	•	•	•	-----	1	28445-ZE2-W01	3678927
	13 GRIP, STARTER		•	•	•	•	•	•	•	-----	1	28461-ZE2-W01	3678950
			•						•	-----	1	28461-ZE2-W01	3678950
	14 ROPE, RECOIL STARTER		•	•	•	•	•	•	•	-----	1	28462-ZE3-W01	3713344
	ROPE, RECOIL STARTER		•						•	-----	1	28462-ZH8-003	3683968
	15 GRIP, REINFORCEMENT		•	•	•	•	•	•	•	-----	1	28469-ZE2-W01	3678976
			•						•	-----	1	28469-ZE2-W01	3678976
	16 SCREW, CENTER		•	•	•	•	•	•	•	-----	1	90004-ZE2-W01	3679024
			•						•	-----	1	90004-ZE2-W01	3679024
	17 BOLT, FLANGE (6X10)		•	•	•	•	•	•	•	-----	3	96001-06010-00	2154656
			•						•	-----	3	96001-06010-00	2154656

FAN COVER




ZE9ME1200A

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-12	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E N 3	D N 3	D P 2 3	FROM	TO			
1	COVER COMP., FAN *NH1* (BLACK)	•	•			•	•	•		-----	-----	1	19610-ZF5-V10ZA	5738265
	COVER COMP., FAN *R8* (BRIGHT RED)	•	•			•	•	•		-----	-----	1	19610-ZF5-V10ZB	5794334
	COVER COMP., FAN *NH1* (BLACK)	•	•	•					•	-----	-----	1	19610-ZF5-V20ZA	5738273
	COVER COMP., FAN *R8* (BRIGHT RED)	•	•	•					•	-----	-----	1	19610-ZF5-V20ZB	5738281
2	COVER COMP., FAN *R8* (BRIGHT RED)	•	•						•	-----	-----	1	19610-ZF5-801ZA	4542502
	COVER COMP., FAN *NH1* (BLACK)	•	•						•	-----	-----	1	19610-ZF5-801ZB	4542924
3	PLATE COMP., SIDE	•	•						•	-----	-----	1	19611-ZE8-901	2409571
4	PLATE, SIDE	•	•	•					•	-----	-----	1	19612-ZF5-010	4221156
5	BRACKET, FAN COVER	•	•	•	•	•	•	•	•	-----	-----	2	19617-ZF5-V00	4903928
6	STAY COMP., STARTER	•	•						•	-----	-----	1	31255-ZE8-901	2409662
7	BOLT, FLANGE (6X12)	•	•	•	•	•	•	•	•	-----	-----	1	90013-883-000	0636845
			•						•	-----	-----	1	90013-883-000	0636845

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER	QTY REQ		
Ref. No.	BLOCK NO.	E-12	G X V 3 4 0 K 2 -	D A 2 3 3	D A 3 3 3	D E T 3 3	D E N 3 3	D E N 3 3	D P X 3 3			PART NUMBER	HONDA CODE
	DESCRIPTION									FROM TO			
	8 BOLT, FLANGE (6X16)		•	•	•	•	•	•	•	-----	4	90029-888-000	0747733
	9 NUT, FLANGE (6MM)		•	•	•	•	•	•	•	-----	4	94050-06000	0471623
			•						•	-----	3	94050-06000	0471623
	10 BOLT, FLANGE (8X16)		•						•	-----	2	95701-08016-00	2298396
	11 BOLT, FLANGE (8X20)		•	•	•			•	•	-----	2	95701-08020-08	2440477
	12 BOLT, FLANGE (8X28)		•						•	-----	2	95801-08028-00	4150074

CARBURETOR (1)




ZE9ME1400

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		Q T Y	P A R T N U M B E R	H O N D A C O D E
Ref. No.	BLOCK NO. DESCRIPTION	E-14	G X V 3 4 0 K 2	D A 2 3 3	D A 3 3 3	D E T 3 3	D E E 3 3	D N E 3 3	D N X 3 3	F R O M	T O	R E Q		
1	GASKET SET	•	•	•	•	•	•	•	•	-----	-----	1	16010-ZE2-015	3521176
2	VALVE SET, FLOAT	•	•	•	•	•	•	•	•	-----	-----	1	16011-ZA0-931	2059236
3	FLOAT SET	•	•	•	•	•	•	•	•	-----	-----	1	16013-ZA0-931	2059244
4	CHAMBER SET, FLOAT	•	•	•	•	•	•	•	•	-----	-----	1	16015-ZE8-005	2089993
5	SCREW SET	•	•	•	•	•	•	•	•	-----	-----	1	16016-ZH7-W01	4219879
6	SCREW SET, DRAIN	•	•	•	•	•	•	•	•	-----	-----	1	16024-ZE1-811	1672187
7	SCREW SET B	•	•	•	•	•	•	•	•	-----	-----	1	16028-ZE0-005	1441518
8	CARBURETOR ASSY. (SPEC)	•	•	•	•	•	•	•	•	-----	-----	1	16100-ZE9-W01	5173323
9	SCREW, THROTTLE STOP	•	•	•	•	•	•	•	•	-----	-----	1	16124-ZE0-005	1441559
10	CAP, CHOKE LEVER DUST	•	•	•	•	•	•	•	•	-----	-----	1	16148-141-881	2110468
11	NOZZLE, MAIN	•	•	•	•	•	•	•	•	-----	-----	1	16166-ZE9-W00	4455457
12	COLLAR SET	•	•	•	•	•	•	•	•	-----	-----	1	16172-ZE3-W10	3738358
13	TUBE, AIR VENT (75MM)	•	•	•	•	•	•	•	•	-----	-----	1	16199-ZE8-000	2278406
14	INSULATOR, CARBURETOR	•	•	•	•	•	•	•	•	-----	-----	1	16211-ZE9-601	3131950
15	SPACER COMP., CARBURETOR	•	•	•	•	•	•	•	•	-----	-----	1	16220-ZA0-702	2686533
16	GASKET, CARBURETOR	•	•	•	•	•	•	•	•	-----	-----	1	16221-ZE3-800	3795358


GXV340K2 GXV340K2-P			GXV340K2-P	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE		
Ref. No.	BLOCK NO.	E-14		D A 2 3	D A 3 3	D E T 3	D E N 3	D X 3	D P 2 3					FROM TO	
	DESCRIPTION														
17	GASKET, INSULATOR	•	•	•	•	•	•	•	•	-----	1	16223-ZE9-800	4145777		
18	LEVER, COCK	•	•	•	•	•	•	•	•	-----	1	16953-ZE1-712	5266069		
19	PLATE, LEVER SETTING	•	•	•	•	•	•	•	•	-----	1	16954-ZE1-812	5148135		
20	SPRING, PETCOCK LEVER	•	•	•	•	•	•	•	•	-----	1	16956-ZE1-811	1807809		
21	GASKET, PETCOCK	•	•	•	•	•	•	•	•	-----	1	16957-ZE1-812	3440708		
22	SCREW, PAN (3X6)	•	•	•	•	•	•	•	•	-----	2	93500-03006-OH	0561654		
	SCREW, PAN (3X8)	•	•	•	•	•	•	•	•	-----	2	93500-03008-OG	0420505		
23	CLIP, TUBE (B8)	•	•	•	•	•	•	•	•	-----	1	95002-02080	0250647		
24	JET, MAIN (#85)	•	•	•	•	•	•	•	•	-----	(1)	99101-ZH7-0850	4335717		
	JET, MAIN (#88)	•	•	•	•	•	•	•	•	-----	(1)	99101-ZH7-0880	4221073		
	JET, MAIN (#90)	•	•	•	•	•	•	•	•	-----	1	99101-ZH7-0900	4221081		
25	JET SET, PILOT (#38)	•	•	•	•	•	•	•	•	-----	1	99204-ZE0-0380	3353075		

CARBURETOR (2)



ZE9ME1401


GXV340K2 GXV340K2-P		GXV340K2	GXV340K2	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE			
Ref. No.	BLOCK NO. DESCRIPTION			E-14-1	DA23	DA33	DET3	DEN3	DNX3					DP23	FROM TO	
	1 CARBURETOR ASSY. (BEL6A B)	•							•	-----	-----	1	16100-ZE9-V42	5281209		
	2 SCREW, THROTTLE STOP	•							•	-----	-----	1	16124-ZE0-005	1441559		
	3 CAP, CHOKE LEVER DUST	•							•	-----	-----	1	16148-141-881	2110468		
	4 COLLAR SET	•							•	-----	-----	1	16172-ZE3-W10	3738358		
	5 INSULATOR, CARBURETOR	•							•	-----	-----	1	16211-ZE9-601	3131950		
	6 SPACER COMP., CARBURETOR	•							•	-----	-----	1	16220-ZA0-702	2686533		
	7 GASKET, CARBURETOR	•							•	-----	-----	1	16221-ZE3-800	3795358		
	8 GASKET, INSULATOR	•							•	-----	-----	1	16223-ZE9-800	4145777		
	9 VALVE, DASHPOT CHECK	•							•	-----	-----	(1)	36135-PH3-004	2177228		
	10 JET, PILOT (#45)	•							•	-----	-----	1	99104-ZE9-0450	5040563		

AIR CLEANER (1)

ZE9ME1500A

GXV340K2 GXV340K2-P			GXV340K2	TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO.	E-15		D A 2 3	D A 3 3	D E T 3	D E N 3	D E N 3	D X 3	D P 2 3	FROM TO				
	DESCRIPTION										FROM	TO			
	1 ELEMENT, AIR CLEANER	•	•	•	•	•	•	•	•	•	-----	-----	1	17211-ZF5-V00	4903886
	2 FILTER (OUTER)	•	•	•	•	•	•	•	•	•	-----	-----	1	17218-ZF5-V00	4907283
	3 COVER, AIR CLEANER	•	•	•	•	•	•	•	•	•	-----	-----	1	17231-ZF5-V00	4903894
	4 ELBOW COMP., AIR CLEANER	•	•	•	•	•	•	•	•	•	-----	-----	1	17410-ZF5-V00	4903902
	5 BOLT, FLANGE (6X35)	•	•	•	•	•	•	•	•	•	-----	-----	1	90014-ZE6-000	1688076
	6 WINGNUT, TOOL BOX SETTING	•	•	•	•	•	•	•	•	•	-----	-----	1	90325-044-000	0127720
	7 COLLAR, AIR CLEANER	•	•	•	•	•	•	•	•	•	-----	-----	2	91502-ZF5-V00	4907325
	8 COLLAR, AIR CLEANER	•	•	•	•	•	•	•	•	•	-----	-----	1	91503-ZF5-V00	4907333
	9 NUT, FLANGE (6MM)	•	•	•	•	•	•	•	•	•	-----	-----	2	94050-06000	0471623


AIR CLEANER (2)



ZE9ME1501

GXV340K2 GXV340K2-P			GXV340K2-	TYPE							ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE	
Ref. No.	BLOCK NO.	E-15-1		DA23	DA33	DET3	DEN3	DNX3	DP23	FROM TO					
	DESCRIPTION														
1	GASKET, ELBOW	•							•	-----	-----	1	16271-ZE8-000	2090082	
2	ELEMENT COMP., AIR CLEANER	•							•	-----	-----	1	17210-ZF5-000	3133808	
3	FILTER (OUTER)	•							•	-----	-----	1	17218-ZF5-000	3132024	
	FILTER (OUTER)	•							•	-----	-----	1	17218-ZF5-505	5183777	
4	COVER, AIR CLEANER (DUAL)	•							•	-----	-----	1	17230-ZE8-900	2832020	
5	GROMMET, AIR CLEANER	•							•	-----	-----	1	17232-891-000	0999763	
6	COLLAR, AIR CLEANER	•							•	-----	-----	1	17238-ZE1-000	1427525	
7	COLLAR, AIR CLEANER	•							•	-----	-----	2	17238-ZE2-310	2384105	
8	ELBOW COMP., AIR CLEANER	•							•	-----	-----	1	17410-ZE8-900	2832038	
9	BOLT, FLANGE (6X35)	•							•	-----	-----	1	90014-ZE6-000	1688076	
10	WINGNUT, TOOL BOX SETTING	•							•	-----	-----	2	90325-044-000	0127720	
11	NUT, FLANGE (6MM)	•							•	-----	-----	2	94050-06000	0471623	


MUFFLER



ZE9ME1600AH

GXV340K2 GXV340K2-P			GXV340K2- 340K2- 2	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE		
Ref. No.	BLOCK NO.	E-16		D A 2 3 3	D A 3 3 3	D E T 3 3	D E N 3 3	D P X 3 3	D P 2 3					FROM	TO
	DESCRIPTION														
1	MUFFLER COMP.	•	•	•	•	•	•	•	•	-----	-----	1	18310-ZE9-003	2271484	
	MUFFLER COMP.	•	•						•	-----	-----	1	18310-ZE9-901	2791077	
2	SEPARATOR, MUFFLER	•	•	•	•	•	•	•	•	-----	-----	1	18316-ZF5-V00	4949830	
	SEPARATOR, MUFFLER	•	•						•	-----	-----	1	18325-ZE9-010	4542478	
3	STAY COMP., MUFFLER	•	•	•	•	•	•	•	•	-----	-----	1	18318-ZE8-000	2106284	
		•	•						•	-----	-----	1	18318-ZE8-000	2106284	
4	PROTECTOR, MUFFLER	•	•	•	•	•	•	•	•	-----	-----	1	18321-ZF5-000	3132040	
	PROTECTOR COMP., MUFFLER	•	•						•	-----	-----	1	18320-ZE9-901	2791085	
5	CAP, MUFFLER	•	•	•	•	•			•	-----	-----	1	18331-ZE2-810	2026227	
		•	•						•	-----	-----	1	18331-ZE2-810	2026227	
6	PIPE, EX.	•	•	•	•	•	•	•	•	-----	-----	1	18331-ZF5-000	3132057	
	PIPE, EX.	•	•						•	-----	-----	1	18330-ZE9-000	2271518	
7	GASKET, EX. PIPE	•	•	•	•	•	•	•	•	-----	-----	1	18333-ZE3-800	3520194	
		•	•						•	-----	-----	1	18333-ZE3-800	3520194	
	GASKET, EX. PIPE (WACKER)	•	•	•	•	•	•	•	•	-----	-----	1	18333-ZK6-Y00	5164199	
		•	•						•	-----	-----	1	18333-ZK6-Y00	5164199	
8	ARRESTER, SPARK	•	•						•	-----	-----	1	18335-ZE8-000	2106326	

MUFFLER




ZE9ME1600AH

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE		
Ref. No.	BLOCK NO. DESCRIPTION	E-18	G X V 3 4 0 K 2	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E N 3	D E N 3	D X 3	D P 2 3				FROM	TO
9	GASKET, EX. PIPE	•	•	•	•	•	•	•	•	•	•	-----	-----	1	18382-ZE9-800	4455473
		•	•	•	•	•	•	•	•	•	•	-----	-----	1	18382-ZE9-800	4455473
10	BOLT, FLANGE (8X16)	•	•	•	•	•	•	•	•	•	•	-----	-----	1	90031-883-000	0674473
		•	•	•	•	•	•	•	•	•	•	-----	-----	1	90031-883-000	0674473
11	SCREW, TAPPING (5X8)	•	•	•	•	•	•	•	•	•	•	-----	-----	3	90050-ZE1-000	1431105
		•	•	•	•	•	•	•	•	•	•	-----	-----	3	90050-ZE1-000	1431105
12	SCREW, TAPPING (4X6)	•	•	•	•	•	•	•	•	•	•	-----	-----	3	90055-ZE1-000	1431121
	SCREW, PAN (6X6)	•	•	•	•	•	•	•	•	•	•	-----	-----	1	93500-06006-0A	1808013
13	BOLT, STUD (8X60)	•	•	•	•	•	•	•	•	•	•	-----	-----	1	92900-08060-1B	1869692
		•	•	•	•	•	•	•	•	•	•	-----	-----	1	92900-08060-1B	1869692
14	BOLT, STUD (8X70)	•	•	•	•	•	•	•	•	•	•	-----	-----	1	92900-08070-1B	2106680
		•	•	•	•	•	•	•	•	•	•	-----	-----	1	92900-08070-1B	2106680
15	SCREW, PAN (6X6)	•	•	•	•	•	•	•	•	•	•	-----	-----	3	93500-06006-0A	1808013
		•	•	•	•	•	•	•	•	•	•	-----	-----	3	93500-06006-0A	1808013
16	NUT, FLANGE (8MM)	•	•	•	•	•	•	•	•	•	•	-----	-----	4	94050-08000	0481143
		•	•	•	•	•	•	•	•	•	•	-----	-----	4	94050-08000	0481143
17	WASHER, PLAIN (6MM)	•	•	•	•	•	•	•	•	•	•	-----	-----	3	94101-06000	0059071
		•	•	•	•	•	•	•	•	•	•	-----	-----	3	94101-06000	0059071

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER	QTY REQ		
Ref. No.	BLOCK NO. DESCRIPTION	E-16	G X V 3 4 0 K 2 -	D A 2 3	D A 3 3	D E T 3	D E 3 3	D E N 3	D X 3			PART NUMBER	HONDA CODE
	17 WASHER, PLAIN (6MM)		•	•	•	•	•	•	•	-----	3	94101-06800	0345900
			•						•	-----	3	94101-06800	0345900
	18 BOLT, FLANGE (8X14)		•	•	•	•	•	•	•	-----	1	95701-08014-00	2529105
			•						•	-----	1	95701-08014-00	2529105

FUEL TANK




ZE9ME1700

GXV340K2 GXV340K2-P			TYPE						ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-17	G X V 3 4 0 K 2 -	D A 2 3 3	D E 3 3	D E T 3 3	D E N 3 3	D E N X 3 3	FROM	TO			
1	FILTER COMP., FUEL	•	•	•					-----	-----	1	16910-ZE8-015	4287553
2	FILTER, FUEL	•			•	•	•	•	-----	-----	1	16952-ZE6-000	1452945
3	TANK, FUEL	•			•	•	•	•	-----	-----	1	17510-ZE9-000	2278646
4	TUBE, FUEL	•			•	•	•	•	-----	-----	1	17512-ZE9-000	2278653
5	RUBBER B, TANK MOUNTING	•			•	•	•	•	-----	-----	1	17516-ZE8-000	2106250
6	RUBBER B, TANK MOUNTING	•			•	•	•	•	-----	-----	3	17516-896-700	0933416
7	COLLAR, TANK SETTING	•			•	•	•	•	-----	-----	2	17518-ZE8-000	2106268
8	CAP ASSY., FUEL TANK	•			•	•	•	•	-----	-----	1	17620-ZE7-000	2289833
9	SPONGE, FUEL CAP BREATHER	•			•	•	•	•	-----	-----	1	17622-888-010	0810341
10	GASKET, FUEL CAP	•			•	•	•	•	-----	-----	1	17624-ZE7-000	2507689
11	WASHER, TANK MOUNTING	•			•	•	•	•	-----	-----	4	90455-896-700	0933325
12	WASHER, PLAIN (8MM)	•			•	•	•	•	-----	-----	2	90471-SB0-000	2372183
13	BULK HOSE, FUEL (4.5X3000) (4.5X360)	•	•	•					-----	-----	1	95001-45003-20M	2380558
14	CLIP, TUBE (B8)	•			•	•	•	•	-----	-----	1	95002-02080	0250647
15	CLIP, TUBE (D8.5)	•	•	•					-----	-----	2	95002-40850-08	0665240

GXV340K2 GXV340K2-P		E-17	GXV340K2	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION			D A 2 3	D A 3 3	D E 3 3	D E 3 3	D N 3 3	D N 3 3				
										FROM TO			
	16 CLIP, TUBE (C11)									-----	1	95002-70000	0053595
	17 BOLT, FLANGE (8X95)									-----	2	95701-08095-00	4949988

FLYWHEEL




ZE9ME1900A

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-19	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E N 3	D N X 3	D P 2 3	FROM	TO			
1	FAN, COOLING	•	•	•	•	•	•	•	•	-----	-----	1	19511-ZE9-010	2485407
		•								-----	-----	1	19511-ZE9-010	2485407
2	PULLEY COMP., STARTER (SCREEN GRID)	•	•	•	•	•	•	•	•	-----	-----	1	28450-ZE9-004	4186342
3	PULLEY, STARTER	•	•						•	-----	-----	1	28451-ZE2-W01	3678943
4	FLYWHEEL COMP.	•	•	•				•	•	-----	-----	1	31100-ZE9-020	5355870
5	FLYWHEEL COMP. (SEL-4 POLE) FLYWHEEL COMP.	•	•		•	•	•			-----	-----	1	31110-ZF5-L32	5355888
		•	•						•	-----	-----	1	31100-ZE9-804	5335914
6	COIL ASSY., CHARGE	•	•						•	-----	-----	1	31510-ZE8-901	2324168
7	COIL ASSY., CHARGE	•	•		•	•				-----	-----	1	31630-ZF5-003	3132198
	COIL ASSY., CHARGE (1A CHG)	•	•				•			-----	-----	1	31630-ZF5-801	4542536
8	CLIP, BRAKE PIPE (A)	•	•	•	•	•	•	•	•	-----	-----	1	46391-VM0-003	1769652
		•	•	•	•	•	•	•	•	-----	-----	1	46391-VM0-003	1769652
9	BOLT, FLANGE (6X28)	•	•		•	•	•			-----	-----	2	90015-883-000	0636852
		•	•						•	-----	-----	2	90015-883-000	0636852
10	NUT, SPECIAL (16MM) (1)	•	•	•	•	•	•	•	•	-----	-----	1	90201-ZE3-V00	5032727

GXV340K2 GXV340K2-P			GXV340K2	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE		
Ref. No.	BLOCK NO.	E-19		GXV340K2	DA33	DET33	DEN33	DNN33	DPX33					FROM TO	
	DESCRIPTION														
	10 NUT, SPECIAL (16MM)		•	•	•	•	•	•	•	-----	1	90201-ZE3-790	2326908		
			•						•	-----	1	90201-ZE3-790	2326908		
	11 CLIP, HARNESS		•						•	-----	1	90684-ZA0-600	1979160		
	CLIP, WIRE HARNESS		•						•	-----	1	90684-ZA0-601	2539138		
	12 KEY, SPECIAL WOODRUFF (25X18) ...		•	•	•	•	•	•	•	-----	1	90741-ZE2-000	2027159		
			•						•	-----	1	90741-ZE2-000	2027159		

IGNITION COIL




ZE9ME2000

GXV340K2 GXV340K2-P			GXV340K2	TYPE						ENGINE SERIAL NUMBER	QTY REQ	PART NUMBER	HONDA CODE		
Ref. No.	BLOCK NO.	E-20		D A 2 3	D A 3 3	D E T 3	D E N 3	D E N 3	D P X 2 3					FROM	TO
	DESCRIPTION														
	1 SPACER, AIR CLEANER ELBOW		•						•	-----	-----	1	17239-ZE8-700	2090223	
	2 GROMMET, WIRE		•						•	-----	-----	1	19613-ZA8-000	1787951	
	3 COIL ASSY., IGNITION		•	•	•	•	•	•	•	-----	-----	1	30500-ZE9-L32	4542528	
			•						•	-----	-----	1	30500-ZE9-L32	4542528	
	4 CAP ASSY., NOISE SUPPRESSOR		•	•	•	•	•	•	•	-----	-----	1	30700-ZF5-013	3803467	
			•						•	-----	-----	1	30700-ZF5-013	3803467	
	5 RECTIFIER ASSY., SILICON		•		•	•				-----	-----	1	31700-ZE8-003	2106516	
	RECTIFIER ASSY., SILICON		•						•	-----	-----	1	31700-ZE8-901	2324176	
	6 RECTIFIER COMP., SILICON		•				•			-----	-----	1	31700-ZF5-003	4542544	
	7 BRACKET, RECTIFIER		•		•	•				-----	-----	1	31717-ZF5-V00	4924486	
	8 BAND B1, CABLE		•		•	•				-----	-----	1	32161-404-610	0637728	
	9 WIRE, STOP SWITCH		•				•	•	•	-----	-----	1	36101-ZE8-000	2106532	
	10 WIRE, STOP SWITCH		•	•	•	•				-----	-----	1	36101-ZE8-810	2461739	
			•						•	-----	-----	1	36101-ZE8-810	2461739	
	11 HOLDER, STOP SWITCH WIRE		•	•						-----	-----	1	36103-ZE1-000	1429141	
			•						•	-----	-----	1	36103-ZE1-000	1429141	

GXV340K2 GXV340K2-P			GXV340K2- 2	TYPE						ENGINE SERIAL NUMBER FROM TO	QTY REQ	PART NUMBER	HONDA CODE	
Ref. No.	BLOCK NO.	E-20		DA33	DE33	DE33	DN33	DX33	DP23					
	DESCRIPTION													
12	GROMMET, WIRE	•	•	•	•	•	•	•	•	-----	-----	1	80101-166-000	1085471
		•							•	-----	-----	1	80101-166-000	1085471
13	BOLT, FLANGE (6X28)	•	•	•	•	•	•	•	•	-----	-----	2	90015-883-000	0636852
		•							•	-----	-----	2	90015-883-000	0636852
14	BOLT, FLANGE (6X32)	•		•	•					-----	-----	1	95701-06032-00	2105856
	BOLT, FLANGE (6X40)	•	•						•	-----	-----	1	95701-06040-00	2410942


STARTER MOTOR



ZE6ME2100

GXV340K2 GXV340K2-P			TYPE						ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-21	G X V 3 4 0 K 2	D A 2 3	D E T 3	D E N 3	D E N 3	D X 3	FROM	TO			
1	MOTOR ASSY., STARTER	•	•	•	•	•	•	•	-----	-----	1	31200-ZF5-L32	4982245
2	DRIVE ASSY.	•	•	•	•	•	•	•	-----	-----	1	31206-ZF5-L31	4982252
3	STOPPER SET, PINION	•	•	•	•	•	•	•	-----	-----	1	31225-ZF5-L31	4907309
4	BRUSH SET	•	•	•	•	•	•	•	-----	-----	1	31226-ZJ1-004	4210142
5	BOLT, THROUGH	•	•	•	•	•	•	•	-----	-----	2	31261-ZJ1-004	4210209
6	WIRE, MAGNET SWITCH	•	•	•	•	•	•	•	-----	-----	1	32402-ZF5-V00	4949863
7	COVER, STARTER TERMINAL	•	•	•	•	•	•	•	-----	-----	1	32411-ZV4-811	2797009
8	COVER, MAGNETIC SWITCH TERMINAL ..	•	•	•	•	•	•	•	-----	-----	1	32412-ZV4-811	2797017
9	SWITCH ASSY., STARTER MAGNETIC ..	•	•	•	•	•	•	•	-----	-----	1	35850-ZF5-V01	4949889
10	COLLAR, DISTANCE	•	•	•	•	•	•	•	-----	-----	2	91504-ZF5-V00	4949954
11	NUT-WASHER (6MM)	•	•	•	•	•	•	•	-----	-----	2	94070-06080	0660795
12	PIN, DOWEL (10X12)	•	•	•	•	•	•	•	-----	-----	2	94301-10120	2028900
13	BOLT, FLANGE (8X35)	•	•	•	•	•	•	•	-----	-----	2	95701-08035-00	2724029
14	BOLT, FLANGE (6X25)	•	•	•	•	•	•	•	-----	-----	2	96001-06025-00	2105989


CONTROL



ZE9ME2200

GXV340K2 GXV340K2-P		TYPE						ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-22	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E N 3	D E N 3	D P X 3	FROM	TO	
1	CONTROL ASSY.	•	•	•	•	•	•	•	•	1	16500-ZF5-000	3131968
	CONTROL ASSY.	•	•	•	•	•	•	•	•	1	16500-ZF5-800	3131976
		•	•	•	•	•	•	•	•	1	16500-ZF5-800	3131976
2	ARM, GOVERNOR	•	•	•	•	•	•	•	•	1	16551-ZF5-000	3131984
		•	•	•	•	•	•	•	•	1	16551-ZF5-000	3131984
3	ROD, GOVERNOR	•	•	•	•	•	•	•	•	1	16555-ZE9-000	2271393
		•	•	•	•	•	•	•	•	1	16555-ZE9-000	2271393
4	ROD, CHOKE	•	•	•	•	•	•	•	•	1	16556-ZE9-000	2271401
		•	•	•	•	•	•	•	•	1	16556-ZE9-000	2271401
5	ROD, JOINT	•	•	•	•	•	•	•	•	1	16557-ZE8-810	2608677
		•	•	•	•	•	•	•	•	1	16557-ZE8-810	2608677
6	SPRING, GOVERNOR	•	•	•	•	•	•	•	•	1	16561-ZF5-000	3131992
		•	•	•	•	•	•	•	•	1	16561-ZF5-000	3131992
7	SPRING, GOVERNOR PRIMARY	•	•	•	•	•	•	•	•	1	16563-ZE8-000	2110211
		•	•	•	•	•	•	•	•	1	16563-ZE8-000	2110211
8	HOLDER, CABLE	•	•	•	•	•	•	•	•	1	16576-891-000	0800466
		•	•	•	•	•	•	•	•	1	16576-891-000	0800466
9	SPRING, CONTROL ADJUSTING	•	•	•	•	•	•	•	•	1	16584-883-300	0636431
		•	•	•	•	•	•	•	•	1	16584-883-300	0636431

CONTROL




ZE8ME2200

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE	
Ref. No.	BLOCK NO. DESCRIPTION	E-22	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E N 3	D E N 3	D N X 3	D P 2 3	FROM				TO
10	SPRING, CABLE RETURN	•	•	•	•	•	•	•	•	•	-----	-----	1	16592-732-700	2485142
		•								•	-----	-----	1	16592-732-700	2485142
11	LEVER, CHOKE JOINT	•	•	•	•	•	•	•	•	•	-----	-----	1	16619-ZF5-000	3132016
		•								•	-----	-----	1	16619-ZF5-000	3132016
12	SWITCH ASSY., ENGINE	•	•	•	•	•	•	•	•	•	-----	-----	1	35330-ZG1-751	2279370
		•								•	-----	-----	1	35330-ZG1-751	2279370
13	COVER, SWITCH	•	•	•	•	•	•	•	•	•	-----	-----	1	35336-750-003	2279388
		•								•	-----	-----	1	35336-750-003	2279388
14	SWITCH ASSY., ENGINE STOP	•	•	•	•	•	•	•	•	•	-----	-----	1	36100-ZE8-003	2110328
		•								•	-----	-----	1	36100-ZE8-003	2110328
15	BUZZER ASSY.	•	•	•						•	-----	-----	1	38400-ZE8-003	2461754
		•								•	-----	-----	1	38400-ZE8-003	2461754
16	STAY, BUZZER	•	•	•						•	-----	-----	1	38401-ZF5-800	3132222
		•								•	-----	-----	1	38401-ZF5-800	3132222
17	SUSPENSION, AUDIBLE PILOT	•	•	•						•	-----	-----	1	38402-GC1-000	1704642
		•								•	-----	-----	1	38402-GC1-000	1704642
18	BOLT, FLANGE (6X12)	•	•	•	•	•	•	•	•	•	-----	-----	1	90013-883-000	0636845
		•								•	-----	-----	1	90013-883-000	0636845

GXV340K2 GXV340K2-P		TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	E-22	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E T 3	D E T 3	D E T 3	D E T 3			
									FROM	TO			
	19 BOLT, GOVERNOR ARM		•	•	•	•	•	•	-----	-----	1	90015-ZE5-010	2418671
			•						-----	-----	1	90015-ZE5-010	2418671
	20 BOLT, FLANGE (6MM)		•	•	•	•	•	•	-----	-----	1	90015-ZE8-000	2092963
			•						-----	-----	1	90015-ZE8-000	2092963
	21 SCREW, PAN (5X20)		•	•	•	•	•	•	-----	-----	1	93500-05020-0A	0197731
			•						-----	-----	1	93500-05020-0A	0197731
	22 SCREW, TAPPING (5X8)		•	•	•				-----	-----	1	90050-ZE1-000	1431105
			•						-----	-----	1	90050-ZE1-000	1431105
	23 CLIP, WIRE HARNESS		•	•	•				-----	-----	1	90684-ZA0-601	2539138
			•						-----	-----	1	90684-ZA0-601	2539138
	24 BOLT, SLOT (5X14)		•		•	•	•	•	-----	-----	1	92300-05014-0A	4949962
	BOLT, SLOT (5X16)		•	•	•				-----	-----	1	92301-05016-0A	3509742
			•						-----	-----	1	92301-05016-0A	3509742
	25 SCREW, PAN (4X14)		•	•	•	•	•	•	-----	-----	1	93500-04014-0A	0156471
			•						-----	-----	1	93500-04014-0A	0156471
	26 NUT, FLANGE (6MM)		•	•	•	•	•	•	-----	-----	1	94050-06000	0471623
			•						-----	-----	1	94050-06000	0471623
	27 WASHER, PLAIN (6MM)		•	•	•	•	•	•	-----	-----	1	94101-06800	0345900
			•						-----	-----	1	94101-06800	0345900
	28 WASHER, SPRING (4MM)		•	•	•	•	•	•	-----	-----	1	94111-04000	0058958
			•						-----	-----	1	94111-04000	0058958
	29 WASHER, SPRING (5MM)		•	•	•				-----	-----	1	94111-05000	0058966
			•						-----	-----	1	94111-05000	0058966

LABEL



"CAUTION OR WARNING LABELS MUST BE ORDERED SEPARATELY WHEN APPLICABLE"

ZE9ME2800A

GXV340K2 GXV340K2-P		TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE
Ref. No.	BLOCK NO. DESCRIPTION	G X V 3 4 0 K 2	D A 2 3	D A 3 3	D E T 3	D E N 3	D N 3	D P 2 3	FROM	TO			
1	MARK, TOP COVER EMBLEM (11.0)	•	•	•	•	•	•	•	-----	-----	1	87101-ZE9-V00	4903944
2	LABEL, FUEL CAUTION	•	•	•	•	•	•	•	-----	-----	1	87101-ZE9-V00	4903944
3	LABEL, HONDA NAME	•	•	•	•	•	•	•	-----	-----	1	87106-ZE9-V00	5040548
4	LABEL, MAINTENANCE CAUTION	•	•	•	•	•	•	•	-----	-----	1	87140-VA3-S00	4712006
5	LABEL, CAUTION	•	•	•	•	•	•	•	-----	-----	1	87167-ZE9-901	3399698
6	MARK, TYPE (DN3)	•	•	•	•	•	•	•	-----	-----	1	87522-ZF5-V00	4918603
	MARK, TYPE (DNE3)	•	•	•	•	•	•	•	-----	-----	1	87522-ZF5-V00	4918603
	MARK, TYPE (DA33)	•	•	•	•	•	•	•	-----	-----	1	87601-ZF5-V80	4982955
	MARK, TYPE (DNE3)	•	•	•	•	•	•	•	-----	-----	1	87601-ZF5-V90	4982963
	MARK, TYPE (DA33)	•	•	•	•	•	•	•	-----	-----	1	87601-ZF5-W00	4982971
	MARK, TYPE (DA23)	•	•	•	•	•	•	•	-----	-----	1	87601-ZF5-W10	4982989
	MARK, TYPE (DE33)	•	•	•	•	•	•	•	-----	-----	1	87601-ZF5-W20	4928776
	MARK, TYPE (DET3)	•	•	•	•	•	•	•	-----	-----	1	87601-ZF5-W30	4928784
	MARK, TYPE (DX3)	•	•	•	•	•	•	•	-----	-----	1	87601-ZF5-850	4982997
	MARK, TYPE (DP23)	•	•	•	•	•	•	•	-----	-----	1	87601-ZE9-V00	5024237
7	WRENCH, BOX (P21)	•	•	•	•	•	•	•	-----	-----	1	99004-21002	1107010
		•	•	•	•	•	•	•	-----	-----	1	99004-21002	1107010

GXV340K2 GXV340K2-P			TYPE							ENGINE SERIAL NUMBER		QTY REQ	PART NUMBER	HONDA CODE	
Ref. No.	BLOCK NO. DESCRIPTION	E-28	G X V 3 4 0 K 2 -	D A 2 3	D A 3 3	D E T 3	D E 3 3	D E N 3	D N 3	D X 3	D P 2 3				FROM

Part Number Index

Part Number	Grid	Page	Part Number	Grid	Page	Part Number	Grid	Page
(0)			14721-ZE9-900	1-B6	13	16512-ZE3-000	1-B3	6
06165-ZE3-000	1-B2	4	14751-ZE2-003	1-B6	13	16513-ZE2-000	1-B3	6
(1)			14771-ZE2-000	1-B6	13	16531-ZE2-000	1-B3	6
11300-ZF5-W03	1-B2	4	14773-ZE2-000	1-B6	13	16541-ZE8-010	1-B3	6
11300-ZF5-W13	1-B2	4	14775-ZE2-010	1-B6	13	16551-ZF5-000	1-D2	33
11300-ZF5-W22	1-B2	4	14781-ZE2-000	1-B6	13	16555-ZE9-000	1-D2	33
11300-ZF5-W32	1-B2	4	14791-ZE9-000	1-B6	13	16556-ZE9-000	1-D2	33
11381-ZE9-800	1-B2	4	15130-ZE8-000	1-B2	5	16557-ZE8-810	1-D2	33
12000-ZE9-603	1-B2	4	15131-ZE9-003	1-B2	5	16561-ZF5-000	1-D2	33
122A0-ZE9-600	1-B1	2	15330-ZE8-000	1-B2	5	16563-ZE8-000	1-D2	33
12200-ZE9-920	1-B1	2	15332-891-003	1-B2	5	16576-891-000	1-D2	33
12204-ZE2-306	1-B1	2	15334-ZE8-010	1-B2	5	16584-883-300	1-D2	33
12205-ZE2-305	1-B1	2	15334-ZE8-811	1-B2	5	16592-732-700	1-D3	34
12209-ZE8-003	1-B6	12	15335-ZE9-000	1-B2	5	16619-ZF5-000	1-D3	34
12216-ZE2-300	1-B1	2	15336-ZE8-000	1-B2	5	16910-ZE8-015	1-C6	26
12251-ZE9-600	1-B1	2	15337-ZE8-000	1-B2	5	16952-ZE6-000	1-C6	26
12251-ZE9-900	1-B1	2	15400-PR3-004	1-B2	5	16953-ZE1-712	1-C2	19
12310-ZE8-000	1-B1	2	15410-ZJ4-999AH	1-B2	5	16954-ZE1-812	1-C2	19
12315-ZF5-000	1-B2	4	15411-ZF5-W00	1-B2	5	16956-ZE1-811	1-C2	19
12370-ZF5-000	1-B2	4	15420-ZE8-000	1-B2	5	16957-ZE1-812	1-C2	19
12372-ZE2-300	1-B2	4	15421-ZE9-003	1-B2	5	17210-ZF5-000	1-C4	22
12373-ZE8-000	1-B2	5	15600-ZF5-000	1-B2	5	17211-ZF5-V00	1-C3	21
12375-ZE9-010	1-B2	5	15625-ZE8-000	1-B2	5	17218-ZF5-V00	1-C3	21
12376-ZE8-000	1-B2	5	15630-ZE8-000	1-B2	5	17218-ZF5-000	1-C4	22
12391-ZE8-000	1-B1	2	16010-ZE2-015	1-C2	18	17218-ZF5-505	1-C4	22
13010-ZE3-003	1-B4	9	16011-ZA0-931	1-C2	18	17219-ZE8-900	1-B7	14
13011-ZE3-003	1-B4	9	16013-ZA0-931	1-C2	18	17230-ZE8-900	1-C4	22
13012-ZE3-003	1-B4	9	16015-ZE8-005	1-C2	18	17231-ZF5-V00	1-C3	21
13013-ZE3-003	1-B4	9	16016-ZH7-W01	1-C2	18	17232-891-000	1-C4	22
13101-ZE3-W00	1-B4	9	16024-ZE1-811	1-C2	18	17238-ZE1-000	1-C4	22
13102-ZE3-W00	1-B4	9	16028-ZE0-005	1-C2	18	17238-ZE2-310	1-C4	22
13103-ZE3-W00	1-B4	9	16100-ZE9-V42	1-C3	20	17239-ZE8-700	1-D1	30
13104-ZE3-W00	1-B4	9	16100-ZE9-W01	1-C2	18	17240-ZE6-000	1-B3	6
13111-ZE3-000	1-B4	9	16124-ZE0-005	1-C2	18	17410-ZE8-900	1-C4	22
13111-ZF6-000	1-B5	10	16148-141-881	1-C2	18	17410-ZF5-V00	1-C3	21
13200-ZE9-010	1-B5	10		1-C3	20	17510-ZE9-000	1-C6	26
13200-ZE9-315	1-B5	10	16166-ZE9-W00	1-C2	18	17512-ZE9-000	1-C6	26
13310-ZF5-030	1-B5	10	16172-ZE3-W10	1-C2	18	17516-ZE8-000	1-C6	26
13351-ZE9-603	1-B5	10		1-C3	20	17516-896-700	1-C6	26
13356-ZE9-604	1-B5	10	16199-ZE8-000	1-C2	18	17518-ZE8-000	1-C6	26
14100-ZE8-305	1-B6	12	16211-ZE9-601	1-C2	18	17620-ZE7-000	1-C6	26
14100-ZE8-601	1-B6	12		1-C3	20	17622-888-010	1-C6	26
14410-ZE3-013	1-B6	12	16220-ZA0-702	1-C2	18	17624-ZE7-000	1-C6	26
14431-ZE2-000	1-B6	12		1-C3	20	18310-ZE9-003	1-C4	23
14441-ZE2-000	1-B6	12	16221-ZE3-800	1-C2	18	18310-ZE9-901	1-C4	23
14451-ZE1-013	1-B6	12		1-C3	20	18316-ZF5-V00	1-C4	23
14568-ZE1-000	1-B6	12	16223-ZE9-800	1-C2	19	18318-ZE8-000	1-C4	23
14711-ZE3-000	1-B6	12		1-C3	20	18320-ZE9-901	1-C4	23
14711-ZE9-900	1-B6	12	16271-ZE8-000	1-C4	22	18321-ZF5-000	1-C4	23
14721-ZE3-000	1-B6	13	16500-ZF5-000	1-D2	33	18325-ZE9-010	1-C4	23
			16500-ZF5-800	1-D2	33	18330-ZE9-000	1-C4	23
			16510-ZE3-000	1-B3	6	18331-ZE2-810	1-C4	23
			16511-ZE8-000	1-B3	6	18331-ZF5-000	1-C4	23
						18333-ZE3-800	1-C4	23

Part Number Index								
Part Number	Grid	Page	Part Number	Grid	Page	Part Number	Grid	Page
18333-ZK6-Y00	1-C4	23	31226-ZJ1-004	1-D2	32	(9)		
18335-ZE8-000	1-C4	23	31255-ZE8-901	1-C1	16	90001-ZE8-000	1-B5	10
18345-ZF5-020	1-B1	2	31261-ZJ1-004	1-D2	32	90004-ZE2-W01	1-B7	15
18347-ZE8-000	1-B1	2	31510-ZE8-901	1-C7	28	90012-ZE0-010	1-B6	13
18382-ZE9-800	1-C5	24	31630-ZF5-003	1-C7	28	90013-883-000	1-B1	2
19511-ZE9-010	1-C7	28	31630-ZF5-801	1-C7	28		1-B3	7
19610-ZF5-V10ZA	1-C1	16	31700-ZE8-003	1-D1	30		1-C1	16
19610-ZF5-V10ZB	1-C1	16	31700-ZE8-901	1-D1	30		1-D3	34
19610-ZF5-V20ZA	1-C1	16	31700-ZF5-003	1-D1	30	90014-ZE6-000	1-B3	7
19610-ZF5-V20ZB	1-C1	16	31717-ZF5-V00	1-D1	30		1-C3	21
19610-ZF5-801ZA	1-C1	16	32161-404-610	1-D1	30		1-C4	22
19610-ZF5-801ZB	1-C1	16	32402-ZF5-V00	1-D2	32	90014-ZE8-000	1-B1	3
19611-ZE8-901	1-C1	16	32411-ZV4-811	1-D2	32	90015-ZE5-010	1-D3	35
19612-ZF5-010	1-C1	16	32412-ZV4-811	1-D2	32	90015-ZE8-000	1-D3	35
19613-ZA8-000	1-D1	30	35330-ZG1-751	1-D3	34	90015-883-000	1-C7	28
19617-ZF5-V00	1-C1	16	35336-750-003	1-D3	34		1-D1	31
(2)			35410-ZF5-003	1-B3	6	90018-PN3-000	1-B3	7
28400-ZE3-W01ZA	1-B7	14	35419-ZF5-000	1-B3	6	90029-888-000	1-C1	17
28400-ZE3-W01ZB	1-B7	14	35850-ZF5-V01	1-D2	32	90031-883-000	1-C5	24
28400-ZE8-821ZA	1-B7	14	36100-ZE8-003	1-D3	34	90042-ZE8-000	1-B1	3
28400-ZE8-821ZB	1-B7	14	36101-ZE8-000	1-D1	30	90050-ZE1-000	1-C5	24
28410-ZE3-W01ZA	1-B7	14	36101-ZE8-810	1-D1	30		1-D3	35
28410-ZE3-W01ZB	1-B7	14	36103-ZE1-000	1-D1	30	90055-ZE1-000	1-C5	24
28410-ZE8-821ZA	1-B7	14	36135-PH3-004	1-C3	20	90121-952-000	1-B3	7
28410-ZE8-821ZB	1-B7	14	38400-ZE8-003	1-D3	34	90201-ZE3-V00	1-C7	28
28421-ZE3-W01	1-B7	14	38401-ZF5-800	1-D3	34	90201-ZE3-790	1-C7	29
28421-ZE8-821	1-B7	15	38402-GC1-000	1-D3	34	90206-ZE1-000	1-B6	13
28422-ZE2-W01	1-B7	15	(4)			90325-044-000	1-C3	21
28441-ZE2-W01	1-B7	15	46391-VM0-003	1-C7	28		1-C4	22
28442-ZE2-W01	1-B7	15	(8)			90406-VM6-000	1-B3	7
28443-ZE2-W01	1-B7	15	80101-166-000	1-D1	31	90417-HA0-000	1-B5	10
28444-ZE2-W01	1-B7	15	87101-ZE9-V00	1-D4	36	90441-ZE2-010	1-B1	3
28445-ZE2-W01	1-B7	15	87106-ZE9-V00	1-D4	36	90455-896-700	1-C6	26
28450-ZE9-004	1-C7	28	87140-VA3-S00	1-D4	36	90471-SB0-000	1-C6	26
28451-ZE2-W01	1-C7	28	87167-ZE9-901	1-D4	36	90601-ZE3-000	1-B5	10
28461-ZE2-W01	1-B7	15	87522-ZF5-V00	1-D4	36	90602-ZE1-000	1-B3	7
28462-ZE3-W01	1-B7	15	87601-ZE9-V00	1-D4	36	90684-ZA0-600	1-C7	29
28462-ZH8-003	1-B7	15	87601-ZF5-V80	1-D4	36	90684-ZA0-601	1-C7	29
28469-ZE2-W01	1-B7	15	87601-ZF5-V90	1-D4	36		1-D3	35
(3)			87601-ZF5-W00	1-D4	36	90701-HC4-000	1-B3	7
30500-ZE9-L32	1-D1	30	87601-ZF5-W10	1-D4	36	90741-ZE2-000	1-C7	29
30700-ZF5-013	1-D1	30	87601-ZF5-W20	1-D4	36	91001-ZF5-003	1-B3	7
31100-ZE9-020	1-C7	28	87601-ZF5-W30	1-D4	36	91201-ZE3-004	1-B3	7
31100-ZE9-804	1-C7	28	87601-ZF5-850	1-D4	36	91201-ZE9-003	1-B3	7
31110-ZF5-L32	1-C7	28				91203-952-771	1-B3	7
31200-ZF5-L32	1-D2	32				91301-ZE9-003	1-B3	7
31206-ZF5-L31	1-D2	32				91303-HA0-004	1-B3	7
31225-ZF5-L31	1-D2	32				91320-MJ6-003	1-B3	7
						91501-ZF5-000	1-B3	7
						91502-ZF5-V00	1-C3	21
						91503-ZF5-V00	1-C3	21
						91504-ZF5-V00	1-D2	32
						92300-05014-0A	1-D3	35

Part Number Index

Part Number	Grid	Page	Part Number	Grid	Page	Part Number	Grid	Page
92301-05016-0A	1-D3	35	99004-21002	1-D4	36			
92800-20000	1-B3	7	99101-ZH7-0850	1-C2	19			
92900-08032-0B	1-B1	3	99101-ZH7-0880	1-C2	19			
92900-08060-1B	1-C5	24	99101-ZH7-0900	1-C2	19			
92900-08070-1B	1-C5	24	99104-ZE9-0450	1-C3	20			
93500-03006-0H	1-C2	19	99204-ZE0-0380	1-C2	19			
93500-03008-0G	1-C2	19						
93500-04014-0A	1-D3	35						
93500-05020-0A	1-D3	35						
93500-06006-0A	1-C5	24						
94050-06000	1-C1	17						
	1-C3	21						
	1-C4	22						
	1-D3	35						
94050-08000	1-C5	24						
94070-06080	1-D2	32						
94101-06000	1-C5	24						
94101-06800	1-B3	7						
	1-C5	25						
	1-D3	35						
94103-06700	1-B3	7						
94109-20000	1-B3	7						
94111-04000	1-D3	35						
94111-05000	1-D3	35						
94251-10000	1-B3	7						
94301-10120	1-D2	32						
94301-12200	1-B1	3						
95001-45003-20M	1-C6	26						
95002-02080	1-C2	19						
	1-C6	26						
95002-40850-08	1-C6	26						
95002-70000	1-C6	27						
95701-06012-00	1-B1	3						
	1-B4	8						
95701-06016-00	1-B4	8						
95701-06025-00	1-B4	8						
95701-06032-00	1-D1	31						
95701-06040-00	1-D1	31						
95701-08014-00	1-C5	25						
95701-08016-00	1-C1	17						
95701-08020-08	1-C1	17						
95701-08035-00	1-D2	32						
95701-08040-08	1-B4	8						
95701-08060-08	1-B4	8						
95701-08095-00	1-C6	27						
95701-10080-00	1-B1	3						
95801-08028-00	1-C1	17						
96001-06010-00	1-B7	15						
96001-06025-00	1-D2	32						
96100-62070-00	1-B4	8						
	1-B5	11						
96100-62073-00	1-B4	8						
	1-B5	11						
98079-55846	1-B1	3						

Part Number Index

[illegible]

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
(A)							
ARM, GOVERNOR	1-D2	33	2	BRACKET, FAN COVER	1-C1	16	5
ARM, VALVE ROCKER	1-B6	12	4	BRACKET, RECTIFIER	1-D1	30	7
ARRESTER, SPARK	1-C4	23	8	BRUSH SET	1-D2	32	4
				BULK HOSE, FUEL	1-C6	26	13
				Buzzer ASSY.	1-D3	34	15
(B)				(C)			
BAND B1, CABLE	1-D1	30	8	CAMSHAFT	1-B6	12	2
BASE, OIL FILTER	1-B2	5	21	CAMSHAFT ASSY.	1-B6	12	2
BEARING, RADIAL BALL	1-B3	7	43	CAP ASSY, FUEL TANK	1-C6	26	8
	1-B4	8	60	CAP ASSY, NOISE SUPPRESSOR	1-D1	30	4
	1-B5	11	11	CAP ASSY, OIL FILLER	1-B2	5	24
BOLT, CONNECTING ROD	1-B5	10	8	CAP, BREATHER CHAMBER	1-B2	4	6
BOLT, DRAIN PLUG	1-B3	7	50	CAP, CHOKE LEVER DUST	1-C2	18	10
BOLT, FLANGE	1-B1	2	10		1-C3	20	3
	1-B1	3	17	CAP, MUFFLER	1-C4	23	5
	1-B1	3	16	CARBURETOR ASSY.	1-C2	18	8
	1-B3	7	39		1-C3	20	1
	1-B3	7	37	CASE COMP, RECOIL STARTER	1-B7	14	4
	1-B3	7	36		1-B7	14	5
	1-B4	8	57	CHAMBER SET, FLOAT	1-C2	18	4
	1-B4	8	56	CLIP, BRAKE PIPE	1-C7	28	8
	1-B4	8	55	CLIP, GOVERNOR HOLDER	1-B3	7	41
	1-B4	8	59	CLIP, HARNESS	1-C7	29	11
	1-B4	8	58	CLIP, PISTON PIN	1-B5	10	10
	1-B7	15	17	CLIP, TUBE	1-C2	19	23
	1-C1	16	7		1-C6	26	15
	1-C1	17	8		1-C6	26	14
	1-C1	17	12		1-C6	27	16
	1-C1	17	11	CLIP, VALVE GUIDE	1-B1	2	4
	1-C1	17	10	CLIP, WIRE HARNESS	1-C7	29	11
	1-C3	21	5		1-D3	35	23
	1-C4	22	9	COIL ASSY, CHARGE	1-C7	28	6
	1-C5	24	10		1-C7	28	7
	1-C5	25	18	COIL ASSY, IGNITION	1-D1	30	3
	1-C6	27	17	COLLAR SET	1-C2	18	12
	1-C7	28	9		1-C3	20	4
	1-D1	31	13	COLLAR, AIR CLEANER	1-C3	21	8
	1-D1	31	14		1-C3	21	7
	1-D2	32	13		1-C4	22	6
	1-D2	32	14		1-C4	22	7
	1-D3	34	18	COLLAR, DISTANCE	1-D2	32	10
	1-D3	35	20	COLLAR, EXTENSION	1-B3	6	33
BOLT, GOVERNOR ARM	1-D3	35	19	COLLAR, OIL FILTER SETTING	1-B3	7	49
BOLT, HEAD COVER	1-B1	3	11	COLLAR, TANK SETTING	1-C6	26	7
BOLT, PIVOT	1-B6	13	16	CONTROL ASSY.	1-D2	33	1
BOLT, SLOT	1-D3	35	24	COVER	1-B1	2	8
BOLT, STUD	1-B1	3	12	COVER COMP, FAN	1-C1	16	1
	1-B1	3	14		1-C1	16	2
	1-C5	24	14	COVER, AIR CLEANER	1-C3	21	3
	1-C5	24	13		1-C4	22	4
BOLT, THROUGH	1-D2	32	5	COVER, HEAD	1-B1	2	6

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
COVER, MAGNETIC SWITCH TERMINAL	1-D2	32	8	GOVERNOR ASSY.	1-B3	6	27
COVER, OIL PUMP	1-B2	5	11	GOVERNOR KIT	1-B2	4	1
COVER, STARTER TERMINAL	1-D2	32	7	GRIP, REINFORCEMENT	1-B7	15	15
COVER, SWITCH	1-D3	34	13	GRIP, STARTER	1-B7	15	13
CRANKSHAFT COMP.	1-B5	10	5	GROMMET, AIR CLEANER	1-C4	22	5
CYLINDER ASSY.	1-B2	4	4	GROMMET, WIRE	1-D1	30	2
CYLINDER HEAD COMP.	1-B1	2	1		1-D1	31	12
				GUIDE, EX. VALVE	1-B1	2	3
(D)				GUIDE, PUSH ROD	1-B6	13	15
DRIVE ASSY.	1-D2	32	2	GUIDE, VALVE	1-B1	2	2
				(H)			
(E)				HOLDER, CABLE	1-D2	33	8
ELBOW COMP, AIR CLEANER	1-C3	21	4	HOLDER, GOVERNOR WEIGHT	1-B3	6	29
	1-C4	22	8	HOLDER, OIL FILTER	1-B3	7	38
ELEMENT COMP, AIR CLEANER	1-C4	22	2	HOLDER, SPRING	1-B7	15	12
ELEMENT, AIR CLEANER	1-C3	21	1	HOLDER, STOP SWITCH WIRE	1-D1	30	11
EXTENSION, OIL FILLER	1-B2	5	26				
				(I)			
(F)				INSULATOR, CARBURETOR	1-C2	18	14
FAN, COOLING	1-C7	28	1		1-C3	20	5
FILTER	1-C3	21	2				
	1-C4	22	3	(J)			
FILTER COMP, FUEL	1-C6	26	1	JET SET, PILOT	1-C2	19	25
FILTER, AIR	1-B7	14	1	JET, MAIN	1-C2	19	24
FILTER, FUEL	1-C6	26	2	JET, PILOT	1-C3	20	10
FILTER, OIL	1-B2	5	20				
FLOAT SET	1-C2	18	3	(K)			
FLYWHEEL COMP.	1-C7	28	4	KEY, SPECIAL WOODRUFF	1-C7	29	12
	1-C7	28	5				
				(L)			
(G)				LABEL, CAUTION	1-D4	36	5
GASKET SET	1-C2	18	1	LABEL, FUEL CAUTION	1-D4	36	2
GASKET, BREATHER CAP	1-B2	5	8	LABEL, HONDA NAME	1-D4	36	3
GASKET, CARBURETOR	1-C2	18	16	LABEL, MAINTENANCE CAUTION	1-D4	36	4
	1-C3	20	7	LEVER, CHOKE JOINT	1-D3	34	11
GASKET, CYLINDER HEAD	1-B1	2	5	LEVER, COCK	1-C2	19	18
GASKET, CYLINDER HEAD COVER	1-B1	2	7	LIFTER, VALVE	1-B6	12	5
GASKET, ELBOW	1-C4	22	1				
GASKET, EX. PIPE	1-C4	23	7	(M)			
	1-C5	24	9	MARK, TOP COVER EMBLEM	1-D4	36	1
GASKET, FUEL CAP	1-C6	26	10	MARK, TYPE	1-D4	36	6
GASKET, INSULATOR	1-C2	19	17				
	1-C3	20	8				
GASKET, OIL FILLER CAP	1-B2	5	25				
GASKET, OIL PAN	1-B2	4	3				
GASKET, PETCOCK	1-C2	19	21				

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
MOTOR ASSY, STARTER	1-D2	32	1				
MUFFLER COMP.	1-C4	23	1				
				(R)			
(N)				RATCHET, STARTER	1-B7	15	7
NOZZLE, MAIN	1-C2	18	11	RECTIFIER ASSY, SILICON	1-D1	30	5
NUT-WASHER	1-D2	32	11	RECTIFIER COMP, SILICON	1-D1	30	6
NUT, FLANGE	1-C1	17	9	RETAINER, EX. VALVE SPRING	1-B6	13	12
	1-C3	21	9	RETAINER, IN. VALVE SPRING	1-B6	13	11
	1-C4	22	11		1-B6	13	12
	1-C5	24	16	RETAINER, SPRING	1-B7	15	11
	1-D3	35	26	RING SET, PISTON	1-B4	9	1
NUT, PIVOT ADJ.	1-B6	13	17	ROD ASSY, CONNECTING	1-B5	10	4
NUT, SPECIAL	1-C7	28	10	ROD, CHOKE	1-D2	33	4
				ROD, GOVERNOR	1-D2	33	3
				ROD, JOINT	1-D2	33	5
				ROD, PUSH	1-B6	12	3
(O)				ROPE, RECOIL STARTER	1-B7	15	14
O-RING	1-B3	7	48	ROTATOR, VALVE	1-B6	13	14
	1-B3	7	47	ROTOR COMP.	1-B2	5	13
	1-B3	7	46	ROTOR, OIL PUMP	1-B2	5	14
O-RING, PUMP COVER	1-B2	5	12	RUBBER B, TANK MOUNTING	1-C6	26	5
OIL SEAL	1-B3	7	45		1-C6	26	6
	1-B3	7	44	RUBBER, OIL RETURN	1-B2	5	17
				(S)			
(P)				SCREEN, OIL FILTER	1-B2	5	23
PAN ASSY, OIL	1-B2	4	2	SCREW SET	1-C2	18	5
PIN A, DOWEL	1-B1	3	15	SCREW SET B	1-C2	18	7
PIN, DOWEL	1-B3	7	42	SCREW SET, DRAIN	1-C2	18	6
	1-D2	32	12	SCREW, CENTER	1-B7	15	16
PIN, GOVERNOR WEIGHT	1-B3	6	30	SCREW, PAN	1-C2	19	22
PIN, LOCK	1-B3	7	54		1-C5	24	12
PIN, PISTON	1-B4	9	3		1-C5	24	15
PIPE, EX.	1-C4	23	6		1-D3	35	21
PISTON	1-B4	9	2		1-D3	35	25
PIVOT, ROCKER ARM	1-B6	12	6	SCREW, TAPPING	1-C5	24	11
PLATE COMP, SIDE	1-C1	16	3		1-C5	24	12
PLATE COMP, SUCTION	1-B2	5	22		1-D3	35	22
PLATE, LEVER SETTING	1-C2	19	19	SCREW, THROTTLE STOP	1-C2	18	9
PLATE, OIL FILTER	1-B2	5	16		1-C3	20	2
	1-B2	5	15	SEAL, VALVE STEM	1-B6	12	1
PLATE, OIL STOPPER	1-B2	5	19	SEAT, VALVE SPRING	1-B6	13	13
PLATE, ONE-WAY VALVE	1-B2	5	9	SEPARATOR, MUFFLER	1-C4	23	2
PLATE, SIDE	1-C1	16	4	SHAFT, GOVERNOR ARM	1-B3	6	32
PROTECTOR COMP, MUFFLER	1-C4	23	4	SLIDER, GOVERNOR	1-B3	6	31
PROTECTOR, MUFFLER	1-C4	23	4	SPACER COMP, CARBURETOR	1-C2	18	15
PROTECTOR, SWITCH	1-B3	6	35		1-C3	20	6
PULLEY COMP, STARTER	1-C7	28	2	SPACER, AIR CLEANER ELBOW	1-D1	30	1
PULLEY, RECOIL STARTER	1-B7	14	6	SPARK PLUG	1-B1	3	18
PULLEY, STARTER	1-C7	28	3	SPONGE, FUEL CAP BREATHER	1-C6	26	9
				SPRING, CABLE RETURN	1-D3	34	10
				SPRING, CONTROL ADJUSTING	1-D2	33	9
				SPRING, FRICTION	1-B7	15	8

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
SPRING, GOVERNOR	1-D2	33	6	WEIGHT A, BALANCER	1-B5	10	6
SPRING, GOVERNOR PRIMARY	1-D2	33	7	WEIGHT B, BALANCER	1-B5	10	7
SPRING, PETCOCK LEVER	1-C2	19	20	WEIGHT, GOVERNOR	1-B3	6	28
SPRING, RATCHET	1-B7	15	10	WINGNUT, TOOL BOX SETTING	1-C3	21	6
SPRING, STARTER RETURN	1-B7	15	9		1-C4	22	10
SPRING, VALVE	1-B6	13	10	WIRE, MAGNET SWITCH	1-D2	32	6
SPRING, WEIGHT RETURN	1-B6	12	7	WIRE, STOP SWITCH	1-D1	30	9
STARTER ASSY., RECOIL	1-B7	14	3		1-D1	30	10
	1-B7	14	2	WRENCH, BOX	1-D4	36	7
STAY COMP, COVER	1-B1	2	9				
STAY COMP, MUFFLER	1-C4	23	3				
STAY COMP, STARTER	1-C1	16	6				
STAY, BUZZER	1-D3	34	16				
STOPPER SET, PINION	1-D2	32	3				
STOPPER, OIL	1-B2	5	18				
SUSPENSION, AUDIBLE PILOT	1-D3	34	17				
SWITCH ASSY., ENGINE	1-D3	34	12				
SWITCH ASSY., ENGINE STOP	1-D3	34	14				
SWITCH ASSY., STARTER MAGNETIC	1-D2	32	9				
SWITCH COMP, OIL LEVEL	1-B3	6	34				
(T)							
TANK, FUEL	1-C6	26	3				
TUBE, AIR VENT	1-C2	18	13				
TUBE, BREATHER	1-B2	4	5				
TUBE, FUEL	1-C6	26	4				
(V)							
VALVE SET, FLOAT	1-C2	18	2				
VALVE, BREATHER	1-B2	4	7				
VALVE, DASHPOT CHECK	1-C3	20	9				
VALVE, EX.	1-B6	13	9				
VALVE, IN.	1-B6	12	8				
VALVE, ONE-WAY	1-B2	5	10				
(W)							
WASHER COMP, HEAD COVER	1-B1	3	13				
WASHER, DRAIN PLUG	1-B3	7	53				
WASHER, PLAIN	1-B3	7	52				
	1-B3	7	51				
	1-C5	24	17				
	1-C6	26	12				
	1-D3	35	27				
WASHER, SPRING	1-D3	35	28				
	1-D3	35	29				
WASHER, TANK MOUNTING	1-C6	26	11				
WASHER, THRUST	1-B3	7	40				
	1-B5	10	9				

