

Minuteman[®]

MAINTENANCE CHART MINUTEMAN'S MIRAGE BURNISHER



REQUIRED DAILY MAINTENANCE ITEMS

1. Check oil level and general engine inspection.
2. Clean Recoil Dust Filter
3. Check Pad and Pad Holder, replace or clean pad as necessary.
4. Check Belt Tension.
5. Check LP hose connections.

50 HOUR OR WEEKLY MAINTENANCE ITEMS

1. Service engine air cleaner and element wrapper.
2. Change crankcase oil and engine oil filter.
3. Clean cooling fins.
4. Clean Spark Arrestor.
5. Wash motor and inspect/tighten all bolts.

All operators should be certified to operate the Mirage Propane Burnisher BEFORE operating the unit for the first time. Contact your nearest local Minuteman distributor to received your N.F.P.A. #58 Certification.