
# 13 Grind welding off back side of cam and drive out pin. Replace with nut, bolt & lock washer, to lock motor in desired position.

Reuse the original bearing on the new weldment bracket. Lower motor to floor with a pad holder or brush in place to attain level attitude.

Tighten bolt to lock



Replace # 61 with : 210108 for 200 Models 430009 for 170 Models Note: Bracket shape may vary from illustration NULE. DIACKEL SHAPE HAY VALY HUHH HUSLALIOH

L.