

12.0.3 Solution tank installation

Contents	Page
----------	------

Disassembling and assembling the solution tank	2–4
--	-----

12.0.3 Solution tank installation

Disassembling and assembling the solution tank:

- Loosen the front cab mount on the left and right.**
- Unscrew the bolts of the rear cab mount.**
- Lower the front tool carrier.**
- Disassemble the suction hose.**
- Disassemble the suction hose holder at the rear wagon.**
- Raise the cab carefully using a crane or suitable lifting equipment.**



12.0.3 Solution tank installation

- Raise the cab carefully using a crane or suitable lifting equipment.**
- Unscrew the bolts from the solution tank below the cab.**
- Unscrew the bolts from the rear of the solution tank.**
- Disconnect the solution hoses from below the solution tank.**
- Open the side doors of the rear wagon.**
- Pull back the solution tank slightly.**
- Tilt the solution tank.**
- Extract the solution tank carefully with the help of a second person.**



12.0.3 Solution tank installation



- 1 – Bolts of the rear cab mount
- 2 – Bolts of the solution tank

