Hales- Hamster 688 1/700 / 93400 to 93499

KUD-BELEGEXEMPLAR

## Illustrated Parts List Model Series 93400 to 93499

TYPE NUMBERS 0035, 0036, 0038, 0049, 0060, 0136.

93432 - 0036-01


## TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.


BRIGGS & STRATTON
®

**COPYRIGHT®** 



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1 2 3 5 7 8 9 10 11 13	399269 *299819 214145 *272694 495774 *27549 94621 66578	Cylinder Assembly Bushing Seal—Oil Head—Cylinder ————————————————————————————————————	13A 15 227 230 306 307 308 337	496000 94742 224555 93758 224556	Stud-Cylinder Head Plug-Oil Drain (1/4" Std., Square Hd.) Lever AssyGovernor Washer-Governor Lever Shield-Cylinder Screw-Cylinder Shield Cover-Cylinder Head Plug-Spark (1-63/64" High, 51mm., Resistor Type)	383 528 552 562 592 614 615 616 635 869 870 871 1019	231818 231079 92613 231082 93306 93307 231077 66538 211172 211291 262001	Wrench-Spark Plug Tube-Breather Bushing-Governor Crank Bolt-Governor Lever Nut-Hex. Cotter-Pin Retainer-E-Ring Crank-Governor Elbow-Spark Plug Seat-Intake Valve Seat-Exhaust Valve Guide-Exhaust Valve Label Kit

<sup>★</sup> Included in Gasket Set-Part No. 496865.
◆ Included in Carburetor Kit-Part No. 493762.
◆ Included in Carburetor Gasket Set-Part No. 490937.




	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	12	<b>★270833</b>	Gasket-Crankcase (.015" Thick, Standard) *270895 Gasket-	24 25	222698	Key-Flywheel Piston Assembly See Last Pages.	33 34 35	296677	Valve-Exhaust Valve-Intake Spring-Valve
İ			Crankcase	26		Ring Set	40	93312	Retainer-Spring
			(.005" Thick) <b>★27089</b> 6 Gasket–	27	26026	See Last Pages. Lock-Piston Pin	45 46		TappetValve GearCam
			Crankcase-	28	298909	Pin-Piston	219	496786	GearGovernor
7	16		(.009" Thick) Crankshaft			(Standard) 298908 Pin-Piston	220 284		Washer–Thrust Screw–Hex. Hd.
			See Last Pages.			(.005" O.S.)	441		Bracket-Oil Fill
	17 18	495484	Bearing-Ball Cover-Crankcase	29	294367	Rod-Connecting 390459 Rod-Conn.	523 524		
	10		See Last Pages.			(.020" Undersize	524 525		Seal-Oil Fill Tube-Oil Fill
İ	20	*495355		00	000070	Crankpin Bore)	741		Gear-Timing
	21 21A		Plug-Oil Fill Plug and Seal Assy.	30	220670	DipperConnecting Rod	842 847	*270920 496435	Seal-Oil Fill Cap Tube AssyHigh Oil
-			(For High Oil Fill Hole)	32	94699	Screw-Connecting			Fill
-	22	94682	Screw-Sem			Rod			
-									
							]		
							1		

<sup>Included in Gasket Set-Part No. 496865.
Included in Carburetor Kit-Part No. 493762.</sup> 


Included in Carburetor Gasket Set-Part No. 490937.

## 93400 to 93499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	<b>*27229</b> 5	Gasket-Carburetor Mtg.	118	•493765	Valve and Spring- Needle	137	•	Gasket-Float Bowl (Sold in Kit Only)
52	<b>*272585</b>	Gasket-Intake Port	124	94681	Screw-Hex. Washer	141	496860	
53	94705	Screw-Adapter Mtg.			Head	164	281247	Manifold-Intake
95	94098	Screw-Round Head	125	496863	Carburetor	611	493496	Elbow-Fuel Pipe
98		Screw-Idle Adjusting	127	•	Plug-Welch	634	••	Seal-Shaft
104		Pin-Float Hinge	130		Valve-Throttle			(Sold in Kit Only)
38	223471		131	496861	Shaft-Throttle	634A	••	Seal-Choke Shaft
111		. •	133		Float-Carburetor			(Sold in Kit Only)
116	••	Gasket-Sealing	134	<b>●398188</b>		955	496063	
į		(Sold in Kit Only)			(Includes Seat)	975	493640	Bowl-Float
						<u></u>		

<sup>★</sup> Included in Gasket Set-Part No. 496865.
• Included in Carburetor Kit-Part No. 493762.
• Included in Carburetor Gasket Set-Part No. 490937.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
NO. 75 98A 165 201 209 222 232 268	495659 493280 94692 262960 263005 495762 262959	DESCRIPTION  Washer Kit Screw Assy.— Speed Adj. Nut—Wing Link—Governor Spring—Governor Plate—Control Spring—Link Casing—Control Wire (48" Long)			DESCRIPTION  Note If Longer Casing is Needed, Specify Length in Inches; If a Shorter Casing is Needed Cut to Required Length. Casing Wire (54" Long)		NO. 6342⊵ 290568	DESCRIPTION  Note If Longer Wire is Needed, Specify Length in Inches; If Shorter Wire is Needed Cut to Required Length. Locknut-Casing Lever-Control Screw-Hex. Hd.


<sup>Included in Gasket Set-Part No. 496865.
Included in Carburetor Kit-Part No. 493762.
Included in Carburetor Gasket Set-Part No. 490937.</sup> 




F.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
11 159 163 284A 284B 300	280871 *272948 94620 94659	Tube-Breather Support-Filter Gasket-Air Cleaner Screw-Hex. Hd. Screw-Hex. Hd. Muffler-Exhaust	301 445 535 613 642	494511 495246 94729	Pipe-Exhaust Filter-Air Element-Air Cleaner Screw-Sem Cover-Air Cleaner	832 883 966 969 971	*272252 495839 94120	Guard-Muffler Gasket-Exhaust Base-Air Cleaner Screw-Hex. Head Screw-Hex. Head

<sup>Included in Gasket Set–Part No. 496865.
Included in Carburetor Kit–Part No. 493762.
Included in Carburetor Gasket Set–Part No. 490937.</sup> 








958
-----

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
182 184 185 187	NO. 224837 93559 94726	DESCRIPTION  Bracket–Fuel Tank Screw–Hex. Hd. Nut–Hex. Line–Fuel	187A 188	NO. 495218	DESCRIPTION  (11" Long, Cut to Suit) Pipe–Fuel (Molded) Screw–Hex. Head		93053 493988 494769	DESCRIPTION  Clamp—Fuel Pipe Cap—Fuel Tank Vaive—Shut-Off Tank—Fuel


<sup>Included in Gasket Set-Part No. 496865.
Included in Carburetor Kit-Part No. 493762.
Included in Carburetor Gasket Set-Part No. 490937.</sup> 




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
56. 57 58 59 60 73 74	NO. 280439 490179 280406 230228 393152 221661	Pulley-Starter Spring-Starter Rope-Rewind Starter (81" Long) (Cut to Suit) Pin-Starter Grip Grip-Starter Rope Screen-Rotating Screw-Sem	NO.  265 267 305 608	NO. 221535 93496 94786	DESCRIPTION  Clamp—Casing Screw—Clamp Mtg. Screw—Hex. Head Starter—Rewind (12 o'Clock)		NO.	Note 493414 Starter- Rewind (12 o'Clock) Used On Type No(s). 0136. Guard-Finger


<sup>★</sup> Included in Gasket Set-Part No. 496865.
• Included in Carburetor Kit-Part No. 493762.
• Included in Carburetor Gasket Set-Part No. 490937.


23




















REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	496278 224557 399671 394897 63770 298799	DESCRIPTION  Flywheel Guard-Flywheel Clutch-Starter Housing-Starter Ball-Clutch Ratchet-Clutch Washer-Clutch	NO. 75 305A 333 335 347	223047 94811 496914 93731	DESCRIPTION  Washer-Spring Screw-Sem Armature Group Screw-Armature Mounting Sem Switch-Rocker	356 356A 356B 363 851	496037 493400	Wire-Stop (Armature to Switch) Wire-Stop Wire-Stop Flywheel Puller

<sup>Included in Gasket Set–Part No. 496865.
Included in Carburetor Kit–Part No. 493762.
Included in Carburetor Gasket Set–Part No. 490937.</sup> 

## 93400 to 93499







	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	3		Seal-Oil Gasket-Cylinder Head	52 80		Gasket-Intake Port Gasket-Gear Case	137	••	Gasket-Float Bowl (Sold in Kit Only)
- 1	9		Gasket-Breather	88		Gasket-Gear Case	163	<b>★272948</b>	Gasket-Air Cleaner
	12		Gasket-Crankcase		/\	Cover	358		Gasket Set
- 1			(.015" Thick, Standard)	104	●231371	Pin-Float Hinge	524	<b>★271485</b>	Seal-Oil Fill
			<b>★270895</b> Gasket-	116	••	Gasket-Sealing	634	••	Seal-Shaft
L			Crankcase			(Sold in Kit Only)			(Sold in Kit Only)
			(.005" Thick)	118	<b>●493765</b>	Valve and Spring-	634A	••	Seal-Choke Shaft
Γ	_		<b>★270896</b> Gasket-			Needle			(Sold in Kit Only)
			Crankcase	121	493762	Carburetor Kit	842	<b>*270920</b>	Seal-Oil Fill Cap
-1			(.009" Thick)	127	•	Plug-Welch	883		Gasket-Exhaust
-	20	<b>★495355</b>		134	•398188	Valve-Inlet	977	490937	Gasket Set-Carburetor
	51	<b>★2722</b> 95	Gasket-Carburetor			(Includes Seat)	İ		
1			Mtg.	•			ļ.		
			İ				]		
Ţ							l		
ı							ļ		
-									
ŀ									
-							Ì		
			ŀ				ŀ		
							ŀ		}