



- To program the serial number of the engine, select “4. Diagnostics tests”.




- Select „Scrittura Informazioni“




- Select „2. Write Engine Serial“



- The serial number must be read directly from the engine.



- Save the entry with the button "Write".



- The programming of the motor serial number was successful as soon as the green window appears.
- Confirm with „Exit“.