

# **Contents, Training Documents**

**Hako- Citymaster 1250**

**Hako- Citymaster 1250 with Citycleaner Variant (6150.10) and wet cleaning function kit (1463)**

## **1.1 Operation and Functions of Hako- Citymaster 1250**

**1.1.1 Operating elements**

**1.1.2 Technical data, Hako Citymaster 1250**

**1.1.3 Improvements Hako- Citymaster 1250 on CD**

**1.1.4 Instruction Manual Hako- Citymaster 1250 on CD**

## **2.0 Maintenance Hako- Citymaster 1250**

**2.0.1 Maintenance instructions CM 1250**

**2.0.2 Hako System Maintenance CM 1250**

**2.0.3 Quick reference, daily/weekly maintenance (operator)**

## **3.0 Electrical Installation, CM 1250**

**3.0.1 Electrical installation documents, CM 1250**

**3.0.2 Electrical circuit diagram, CM 1250**

**3.0.3 Electrical function diagram, engine control unit relay **K2**; starting CM 1250**

- 3.0.4 Electrical function diagram, work hydraulics with control unit **A1 broom speed** and control unit **A4 incr./decr. pressure front attachment support (option)**
- 3.0.5 Electrical function diagram, CM 1200, Citycleaner variant with control units **A1 brush speed** and **A4 incr./ decr. pressure srubdeck and waterpump M9 and watervalue Y21**
- 3.0.6 Electrical function diagram, Citymaster 1250 with control unit **A1 with sand+ salt spreader**
- 3.0.7 Electrical function diagram, Citytrac 1250 with mower
- 3.0.8 Electrical symbols (switching icons) in electrical circuit Diagrams, on CD
- 3.0.9 Jumpers (bridges) for device detection on connector X60, X63, X64, X66, on CD

## **4.0 Steering CM 1250**

- 4.0.1 Steering CM 1250, on CD

## **5.0 Hydraulic Drive, CM 1250**

- 5.0.1 Hydraulic drive documents, CM 1250
- 5.0.2 Hydraulic function diagram, drive, CM 1250
- 5.0.3 Hydraulic circuit diagram, Hako- Citymaster 1250
- 5.0.4 Spare part list drive pump Bosch- Rexroth A10VG 45
- 5.0.5 Repair manual drive pump Bosch- Rexroth A10VG45
- 5.0.6 Spare part list drive motor Bosch- Rexroth MRC 3, 225 ccm
- 5.0.7 Service manual drive motor Bosch- Rexroth MRC 3

## **6.0 Work Hydraulics CM 1250**

**6.0.1 Work hydraulics documents, CM 1250**

**6.0.2 Hydraulic function diagram, work hydraulics**

**6.0.3 Hydraulic function diagram, work hydraulics,  
CM 1250 with Citycleaner (6150.10)**

**6.0.4 Hydraulic circuit diagram, Citymaster 1250, in A3**

**6.0.5 Hydraulic circuit diagram Citycleaner**

**6.0.6 Pressure control front tool carrier (1459)**

**6.0.7 Circuit diagram high pressure cleaner**

**6.0.8 Hydraulic switching icons (Graphic Symbols) in  
in hydraulic circuit diagrams, on CD**

**6.0.9 Drawing Hydraulic Manifold (Bucher) with tightening  
Torques, on CD**

## **7.0 Brake System, CM 1250**

**7.0.1 Brake system documents, CM 1250**

**7.0.2 Knott Brakes, on CD**

## **9.0 Yanmar Engine 4TNV88- BMHW**

### **9.0.1 Yanmar engine documents**

**9.0.2 Spare parts list, Yanmar engine 4TNV88- BMHW, on CD**

**9.0.3 Yanmar Service Manual 4 TNV-series (in English), on CD**

**9.0.4 B7 fuel**

**9.0.5 B20 fuel**

## **10.0 Air Conditioning Unit, CM 1250**

**10.0.1 Air conditioning unit documents, CM 1250**

## **12.0 Mechanics, Torques**

**12.0.1 Documents on mechanics, torques, tools**

## **13.0 Tools**

**13.0.1 Tools for CM 1250**

## **14.0 Circular, Technical Information (on CD)**

## **15.0 Equipment from suppliers**