

**DIAGNOSTIC ERRORS FOR E-Z MOP**

E-Z MOP ERRORS Ver. 02.03.08			
ID	Messaggio LCD	Descrizione	Causa
1	ERR1 ASP	Errore motore aspirazione	A causa del aumento assorbimento del motore di aspirazione, la potenza erogata è stata ridotta del 50%
2	ERR2 SPZ	Errore motori spazzole	A causa del aumento assorbimento dei motori spazzole, la potenza erogata è stata ridotta del 50%
3	ERR3 TMP	Errore temperatura	La temperatura dell' elettronica ha superato 67 gradi
Table des erreurs E-Z Mop Ver. 02.03.08			
ID	Message LCD	Description	Cause
1	ERR1 ASP	Erreur moteur aspiration	A cause de l' augmentation absorbement du moteur d'aspiration, la puissance fournie a été réduite de 50%
2	ERR2 SPZ	Erreur moteur de brosse	En raison de l'absorption accrue des moteurs de brosses, la puissance fournie a été réduite de 50%
3	ERR3 TMP	Erreur de temperature	La temperature sur la platine electronique a dépassé 67 degré C°
Table of errors E-Z MOP Ver. 02.03.08			
ID	Message LCD	Description	Cause
1	ERR1 ASP	Suction motor error	Due to the increased absorption of the suction motor, the power delivered has been reduced by 50%
2	ERR2 SPZ	Brush motor error	Due to the increased absorption of brushes motors, the power delivered has been reduced by 50%
3	ERR3 TMP	Temperature error	The temperature of the electronics has exceeded 152.6 degrees fahrenheit.



**Minuteman<sup>®</sup>**  
*Excellence Meets Clean*