

### Quick guide

	action	pause-button	charger response
1	plug in mains plug (without batterie)	-	standby-mode (white LED lights)
2	switch off charger	3s	Off-State (white LED flashes all 4 seconds)
3	programming mode	10s	programming mode active
4	select characteristic curve until desired characteristic curve is displayed (according to characteristic curve table)	short	active program flashes quickly, inactive slowly
5	save characteristic curve	5s	program flashes quickly and is saved
6	exit programming mode (alternatively wait 60s)	1,5s...3s	Off-State (white LED flashes all 4 seconds)
7	activate standby mode (alternatively wait 15s)	short	standby-mode (white LED lights)
8	connect battery	-	charging with set program is started

