- Remove SD Card from control panal
- Connect SD Card with a SD Card Reader with the Computer
- Connect your Computer with the B175R
- Open the current version (Main Setup 2019 Update1) of the Hako Diagnosis
- Open the CAN Flasher B175 R

📕 HakoDiagnose - Start	seite Diagnose				- 0	×
Startseite Diagnose	?	[DE]				
		5	Startseite		Hak	7
		CM 2000 Euro 3		Scrubmaster B75 R		
		CM 2000 Euro 4		Scrubmaster B90 CL		
		CM 2000 Euro 5		Scrubmaster B115 R		
		CM 600		CAN Flasher B75 R / B120 R		
		CM 1600		CAN Flasher B175 R		
		CM 2200		Sweepmaster 1500 RH		

## Open the Menu "System"

👭 HakoDiagnose - Information					- • ×
281 1 53534101-2	ubmaster B175R H	lakoDiagnose	- Information		Clean ahead
Information Settings	System ?	Exit	[EN]		
Overview	Operating hours Eve	ent memory	Documents		
Machine data		Setting	s and options		
Hako model:	Scrubmaster B175R		Data	Conten	its
Hako serial number:	71821123zkb4	SOW,	3.2.	0	<b>^</b>
Software version:	Mod St-36-BM V18.06.27.01	SOW,	3.4	0	
Hardware version:	97155519	SOW.	3.5.	1	
		SOW,	3.6.	1	
		SOW,	3.7.	0	
Machine Type:	nicht belegt	SOW,	3.8.	1	
Brush deck:	Plate brush deck 1080mm	SOW,	3.9.	0	
LDS type (Battery type):	PzS oder PzB	SOW,	3.A.	0	
Battery charger (Battery type):	w/o battery charger	SOW,	3.B.	0	
Charging characteristic:	Ladekennlinie 0	SOW,	3.C.	1	
Travel drive:	Front	SOW,	3.D.	0	
External Memory	SD Card	SOW,	3.E.	0	
External memory	3D-Curu	SOW,	3.F.	0	
		Param	1, 4.0.	3	
Lasterror	3/12	Param	1, 4, 1.	3	
Lustenon	3712	Param	1, 4.2.	2	
Date, Time	08-04-19, 09:57:34	Param	1, 4.4	1	
ServiceWecker:		Param	1. 4.5.	1	
Abgelaufen in 0 Stunden oder 0	Tagen	Param	1, 4.6.	3	
	- Daakun Pattaria	Param	1, 4.7.	2	
-	Backup Batterie	Param	10	<u></u>	<b></b>

👭 HakoDiagnos	se - System					- 🗆 ×
<b></b>	24101-2	Scrubmaster B175R	HakoDiagnose	- System		Hako
Information	Settings	System ?	Exit	[EN]		citan anead
Flash soft	ware	Maintenance	Write micro-SD Card	-	Configuration	

## Start application Write micro-SD Card

Check at device that the letter is correct for the SD Card otherwise you can lose important information at your computer.

Go on with while.	Go oi	า with	write.
-------------------	-------	--------	--------

👒 Win32 Disk Imager - 1.0	_		×
Image File		Dev	vice
C:/MDT/Hako/B160_B250/Flasher/Display/V910026_1.003.img		[D: <sup>1</sup>	V -
Hash			
None  Generate Copy			
Read Only Allocated Partitions			
Progress			
Cancel Read Write Verify Only	,	Evi	+
Write data from 'Image File' to 'Device'		2.4	
while data nonn image rife to Device			

Follow the description on following windows.

After Flashing of the SD card it is necessary to flash tone software of the control board

HakoDiagnose - System			ale			– – ×
281 1 53534101-2	Scrubmaster B17	5R	HakoDiagnose	- System		<b>Hako</b> Clean ahead
Information Setting	s System	?	Exit	[EN]		
Flash software	Maintenance	W	Write micro-SD Card		Configuration	
# HakoDiagnose - System	Scrubmaster B17	5R	HakoDiagnose	- System		×
HakoDiagnose - System	Scrubmaster B175 s System	5R ?	HakoDiagnose Exit	- System [EN]		- Clean abred
HakoDiagnose - System HakoDiagnose - System 1 53534101-2 Information Setting: Flash software	Scrubmaster B175 s System Maintenance	5R ?	HakoDiagnose Exit Vrite micro-SD Card	- System [EN]	Configuration	- Clean abcod
HakoDiagnose - System	Scrubmaster B17: s System Maintenance	5R ? 	HakoDiagnose Exit Vrite micro-SD Card	- System [EM]	Configuration	- Clean abead
HakoDiagnose - System HakoDiagnose - System HakoDiagnose - System Stating: Flash software Flash software Flashing must not be inte Ensure that the power su	Scrubmaster B17: s System Maintenance rrupted: pply of the	5R ? 	HakoDiagnose Exit Vitte micro-SD Card Flasher Flasher	- System [EN] Flashvorbere	Configuration Contents itung	- · · ×
HakoDiagnose - System         1       53534101-2         Information       Setting:         Flash software         Flashing must not be inte         Ensure that the power su PC and machine work co the cable is not disconne	Scrubmaster B17: s System Maintenance rrupted! pply of the rrectly and cted!	5R ?	HakoDiagnose Exit Vitte micro-SD Card Flasher HW/-Version Service-Level	- System [EN] Flashvorbere 97155519 1	Configuration Contents itung	- Clean abead
HakoDiagnose - System HakoDiagnose - System HakoDiagnose - System Flash software Flash software Flashing must not be inte Ensure that the power su PC and machine work co the cable is not disconne Select software : T180.00.001.010 COptional hex-file	Scrubmaster B17: s System Maintenance rrupted! pply of the rrectly and cted!	2 2 2 3 4 4 5 8 5 8 5 8 5 8 5 8 5 8 5 8 5 8 5 8	HakoDiagnose Exit Virte micro-SD Card	EN EN Flashvorbere 97155519 1	Configuration Contents itung	

Open Application Flash Software

Follow the description on following windows

After all, switch off the machine. Put SD Card back into the control panel. Switch on the machine and check all funktions.